


# DIRECT-VENT CHASSIS OWNER'S INSTALLATION INSTRUCTIONS



### **Patent Pending**





### MODELS (V)DVC36(B)(H) AND (V)DVC42(B)(H) FOR USE WITH DVM SERIES BURNER MODULES

Installation and service must be performed by a qualified installer, service agency or the gas supplier.

WARNING: Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual for correct installation and operational procedures. For assistance or additional information consult a qualified installer, service agency or the gas supplier.

This appliance may be installed in an aftermarket,\* permanently located, manufactured (mobile) home, where not prohibited by local codes.

\* Aftermarket: Completion of sale, not for purpose of resale, from the manufacturer

State of Massachusetts: The installation must be made by a licensed plumber or gas fitter in the Commonwealth of Massachusetts.

INSTALLER: Leave this manual with the appliance. CONSUMER: Retain this manual for future reference.

### TABLE OF CONTENTS

Safety Information	Venting Installation Instructions
Local Codes3	Replacement Parts16
Product Identification3	Technical Service17
Product Features 3	Accessories
Pre-Installation Preparation4	Illustrated Parts Breakdown and Parts List 18
Location of Termination Cap	Warranty InformationBack Cove

### SAFETY INFORMATION

IMPORTANT: Read this owner's manual carefully and completely before trying to assemble, operate or service this fireplace. Improper use of this fireplace can cause serious injury or death from burns, fire, explosion, electrical shock and carbon monoxide poisoning.

WARNING: Any change to this fireplace or it's controls can be dangerous. Do not modify this fireplace under any circumstances. Any parts removed for servicing must be replaced prior to operating fireplace.

WARNING: Do not use a blower insert, heat exchanger insert or other accessory not approved for use with this fireplace.

WARNING: Do not allow fans to blow directly into the fireplace. Avoid any drafts that alter burner flame patterns.

Due to high temperatures, the appliance should be located out of traffic and away from furniture and draperies.

Do not place clothing or other flammable material on or near the appliance. Never place any objects on the appliance.

Do not use this fireplace to cook food or burn paper or other flammable material.

This fireplace reaches high temperatures. Keep children and adults away from hot surface to avoid burns or clothing ignition. Fireplace will remain hot for a time after shutdown. Allow surface to cool before touching.

Carefully supervise young children when they are in the room with fireplace.

Keep the area around your fireplace clear of combustible materials, gasoline and other flammable vapor or liquids. Do not run fireplace where these are used or stored.

- 1. Never install the fireplace
  - in a recreational vehicle
  - in windy or drafty areas where curtains or other combustible (flammable) objects can make contact with the fireplace front
  - · in high traffic areas
- Turn appliance off and let cool before servicing, installing or repairing. Only a qualified service person should install, service or repair this fireplace. Have fireplace inspected annually by a qualified service person.

## **SAFETY INFORMATION**

#### Continued

- You must keep control compartments, burners and circulating air passages clean. More frequent cleaning may be needed due to excessive lint and dust from carpeting, bedding material, etc. Turn off the gas valve and pilot light before cleaning fireplace.
- Have venting system inspected annually by a qualified service person. If needed, have venting system cleaned or repaired.
- Do not use any solid fuels (wood, coal, paper, cardboard, etc.) in this fireplace. Use only the gas type indicated on fireplace nameplate.
- This appliance, when installed, must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code. ANSI/NFPA 70.
- Do not use fireplace if any part has been exposed to or under water. Immediately call a qualified service person to arrange for replacement of the unit.
- 8. Do not operate fireplace if any log is broken.
- 9. Do not operate fireplace with glass door removed, cracked or broken.
- 10. Provide adequate clearances around air openings.

### **LOCAL CODES**

Install and use fireplace with care. Follow all local codes. In the absence to local codes, use the current *National Fuel Gas Code ANSI Z223.1/NFPA 54\**. \*Available from:

American National Standards Institute, Inc. 1430 Broadway

New York, NY 10018

National Fire Protection Association, Inc. Batterymarch Park Quincy, MA 02269

# PRODUCT IDENTIFICATION




Figure 1 - Direct-Vent Fireplace

### **PRODUCT FEATURES**

These are a few facts that can help you understand and enjoy your direct-vent fireplace:

- The venting system may be routed to the outside of your home in several ways. It may vent through the roof (vertical) or it may vent to an outside/exterior wall (horizontal). The vent pipe installation is very important to allow for proper operation. You must follow the venting instructions very carefully for either vertical or horizontal applications.
- This fireplace may be installed in any room of your house provided all local codes and these installation instructions are followed.
- This fireplace requires a wall switch, hand-held remote or wall thermostat (millivolt) for operation (see Accessories, page 42).
- The use of a blower requires electricity if installed. If you plan to install the blower at a later date, outlet at bottom of fireplace must be wired during framing.
- Your direct-vent gas fireplace system (fireplace and venting) is a balanced and sealed gas operating unit. It requires approximately 10-20 minutes of operating time before the flame pattern stabilizes.

# PRE-INSTALLATION PREPARATION

# LOCATION AND SPACE REQUIREMENTS

Determine the safest and most efficient location for your FMI PRODUCTS, LLC direct-vent fireplace. Make sure that rafters and wall studs are not in the way of the venting system. Choose a location where the heat output is not affected by drafts, air conditioning ducts, windows or doors. Figure 2 shows some common locations. Be aware of all restrictions and precautions before deciding the exact location for your fireplace and termination cap.

When deciding the location of your fireplace, follow these rules:

- Do not connect this fireplace venting to a chimney flue serving a separate solid-fuel burning fireplace or appliance.
- Due to high temperatures, do not locate this fireplace in high traffic areas, windy or drafty areas or near furniture or draperies.
- · Proper clearances must be maintained.
- If your fireplace is to be installed directly on carpeting, vinyl tile or any combustible material other than wood, it must be installed on a metal or wood panel extending the full width and depth of the fireplace. See Figure 3.
- Your fireplace is designed to be used in zero clearance installations. Wall or framing material can be placed directly against any exterior surface on the back, sides or top of your fireplace, except where standoff spacers are integrally attached. If standoff spacers are attached to your fireplace, these spacers can be placed directly against wall or framing material. See framing details on page 5.
- If you plan on installing a television or entertainment center recessed above your fireplace, it is recommended that you maintain a minimum 18" above top of louver opening.
- When locating termination cap, it is important to observe the minimum clearances shown in Figure 7, page 8.
- If recessing into a wall, you can avoid extra framing by positioning your fireplace against an already existing framing member.
- Do not recess termination cap into a wall or siding.
- You may paint the termination cap with 450°F heat-resistant paint to coordinate with the ex-

terior finish.

- There must not be <u>any</u> obstruction such as bushes, garden sheds, fences, decks or utility buildings within 24" from the front of the termination cap.
- Do not locate termination cap where excessive snow or ice build up may occur. Be sure to clear vent termination area after snow falls to prevent accidental blockage of venting system. When using snow blowers, do not direct snow towards vent termination area.




Figure 2 - Common Fireplace Locations




Figure 3 - Fireplace Bottom Dimensions

#### **CLEARANCES**

Minimum clearances to combustibles for the fireplace are as follows:

*Back and sides	0"
Perpendicular walls	6"
Floor	0"
Ceiling to louver opening	42"
Front	36"
Top of Standoffs	0"

Vent (See venting instructions for specific venting clearances.)

Combustible material with a maximum thickness of 5/8" may be flush with the top front of fireplace.

\* For back and sides of fireplace, do not pack with insulation or other materials. Zero inch clearance to combustible materials are for framing purpose only.

# PRE-INSTALLATION PREPARATION

Continued

NOTICE: This fireplace is intended for use as supplemental heat. Use this fireplace along with your primary heating system. Do not install this fireplace as your primary heat source. If you have a central heating system, you may run system's circulating blower while using fireplace. This will help circulate the heat throughout the house. In the event of a power outage, you can use this fireplace as a heat source.

### FRAMING AND FINISHING

Figure 4 shows typical framing of this fireplace. Figure 5 shows framing for corner installation. All minimum clearances must be met.

For available accessories for this fireplace, see *Accessories* on page 17. If you are using a separate combustible mantel piece, refer to Figure 6 for proper installation height. You can install noncombustible mantels at any height above the fireplace.

Note: Noncombustible mantels may discolor!




Figure 4 - Framing Clearances for Installation Against an Exterior Wall




Figure 5 - Framing Clearances for Corner Installation




Figure 6 - Clearances for Combustible Mantels

C

D

E

F

G

3

4

5

6

7

10"

8"

6"

4"

2"

12"


10"

8"

6"

4"

### LOCATION OF TERMINATION CAP



- A = clearance above grade, veranda, porch, deck, or balcony [\*12" (30.5 cm) minimum]
- clearance to window or door that may be opened [6" (15 cm) min. for 10,000 Btu or less; 9" (23 cm) in US if between 10,000 and 50,000, 12" (30 cm) in Canada if between 10,000 and 100,000; 12" (30 cm) in US if greater than 50,000, 36" (91 cm) in Canada if greater than 100 0001
- C = clearance to permanently closed window [minimum 12" (30.5 cm) recommended to prevent condensation on windowl
- D = vertical clearance to ventilated soffit located above the terminal within a horizontal distance of 24" (61 cm) from L = the center-line of the terminal [18" (45.7 cm) minimum]
- E = clearance to unventilated soffit [12" (30.5 cm) minimum] M = clearance under veranda, porch, deck
- F = clearance to outside corner (see below)
- G = clearance to inside corner (see below)
- H = \*not to be installed above a meter/regulator assembly within 36" (91.4 cm) horizontally from the center line of the regulator

- I = clearance to service regulator vent outlet [\*72" (182.9 cm) minimum]
  - clearance to non-mechanical air supply inlet to building or the combustion air inlet to any other fireplace [6" (15 cm) min. for 10,000 Btu or less; 9" (23 cm) in US if between 10,000 and 50,000, 12" (30 cm) in Canada if between 10,000 and 100,000; 12" (30 cm) in US if greater than 50,000, 36" (91 cm) in Canada if greater than 100,000]
- K = clearance to a mechanical air supply inlet [\*In Canada, 6 ft. (1.83m) minimum; In US 3 ft. (91 cm) above if within 10 ft. (3 m) horizontally]
- † clearance above paved side-walk or a paved driveway located on public property [\*84" (213.3 cm) minimum]
- [\*12" (30.5 cm) minimum ‡] N = clearance above a roof shall extend a minimum of 24" (61 cm) above the highest point when it passes through the roof surface and any other obstruction within a horizontal distance of 18" (45.7 cm)
- vent shall not terminate directly above a side-walk or paved driveway which is located between two single family dwellings and serves both dwellings'
- only permitted if veranda, porch, deck or balconey is fully open on a minimum of 2 sides beneath the floor\*
- as specified in CAN/CSA B149 (.1 or .2) Installation Codes (1991) for Canada and U.S.A.

Note: Local codes or regulations may require different clearances

#### Termination Clearances for Buildings with Combustible and Noncombustible Exteriors Inside Corner Recessed Location **Outside Corner**




Figure 7 - Minimum Clearances for Termination Cap

NOTICE: Read these instructions completely before attempting installation.

These models are tested and approved for use with FMI PRODUCTS, LLC (direct-vent) pipe components and terminations.

The venting system must terminate on the outside of the structure and can not be attached to a chimney or flue system serving a separate solid fuel or gas burning appliance. A direct-vent appliance must have its own venting system. DO NOT common vent this appliance.

These models are approved to be vented either horizontally through an outside wall or vertically through a roof or chase enclosure using the following guidelines:

- When venting system terminates horizontally on an outside wall, you may install a standoff if the termination cap is to be installed directly on a combustible finish such as vinyl, wood, stucco, etc.
- Never run the vent downward as this may cause excessive temperatures which could cause a fire.
- Vent pipe air space clearances to combustibles are 1" on all sides except on the horizontal sections, which requires 2" clearance from the top of the pipe. Where the termination cap penetrates a combustible wall, 1" air space clearance is required.
- Snorkel terminations are required when minimum clearance to grade cannot be met (see Figure 16 on page 11).
- Have fireplace and selected vent components on hand to help determine the exact measurements when elbowing or offsetting. Always use wall firestops when penetrating walls and firestops when penetrating ceilings or attic spaces.
- If using a venting configuration of only horizontal venting with no vertical run, a 1/4" rise for every 12" of run toward the termination is required.
- For installation of fireplace at elevations of 4000 feet or greater, pay special attention to venting requirement recommendations.

WARNING: Read all instructions completely and thoroughly before attempting installation. Failure to do so could result in serious injury, property damage or loss of life.

NOTICE: Failure to follow these instructions will void the warranty.

NOTICE: Do not seal termination cap to vent pipe. Cap must be removable for vent inspection and maintenance.

#### INSTALLATION PRECAUTIONS

- · Wear gloves and safety glasses for protection
- Use extreme caution when using ladders or when on roof tops
- Be aware of electrical wiring locations in walls and ceilings

The following actions will void the warranty on your venting system:

- Installation of any damaged venting component
- Unauthorized modification of the venting system (Do not cut or alter vent components)
- Installation of any component part not manufactured or approved by FMI PRODUCTS, LLC
- Installation other than as instructed by these instructions

WARNING: This gas fireplace and vent assembly must be vented directly to the outside. The venting system must NEVER be attached to a chimney serving a separate solid fuel burning appliance. Each direct-vent gas appliance must use a separate vent system. Do not use common vent systems.

WARNING: Vent pipe air space clearances to combustibles are 1" on all sides except on the horizontal sections, which require 2" clearances from the top of the pipe. Where the termination cap penetrates a combustible wall, 1" air space clearance is required.

Continued

### INSTALLATION PLANNING

There are two basic types of direct-vent installation:

- · Horizontal Termination
- Vertical Termination

#### **Horizontal Termination Installation**

*IMPORTANT*: Horizontal square terminations require only inner portion of wall firestop. Horizontal installations using round termination require exterior portion of wall firestop (see Figure 14, page 10.

- 1. Set the fireplace in its desired location and determine the route your horizontal venting will take. Do not secure the fireplace until all venting has been installed. Some installations require sliding the fireplace in and out of position to make final venting connections. Figures 14 through 18 on pages 10 through 12 show different configurations for venting with horizontal termination that will help you decide which application best suits your installation. Check to see if wall studs or roof rafters are in the path of your desired venting route. If they are, you may want to adjust the location of the fireplace.
- Direct vent pipe sections and components are designed with special twist-lock connections.
   Twist-Lock Procedure: The female ends of the pipes have locking lugs (indentations). These lugs will slide straight into matching slots on the male ends of adjacent pipes. Push pipe sections together and twist one section clockwise approximately one-quarter turn until the sections are fully locked (see Figure 8). Note: Horizontal runs of vent must be supported every three feet. Use wall straps for this purpose.
- Use a 45° elbow to connect venting system
  to fireplace flue collar. The elbow is designed
  to be twist-locked onto the flue collar as
  described in step 2. IMPORTANT: Do not
  attempt to alter the configuration of the elbow
  by cutting, twisting, bending, etc.
- Assemble the desired combination of pipe and elbows to the fireplace flue collar. If there are long portions of venting run, pre-assembled pipe sections may be installed as subassemblies for convenience.

5. Carefully determine the location where the vent pipe assembly will penetrate the outside wall. The center of the hole should line up with the center-line of the horizontal vent pipe. Mark the wall for a 11 <sup>1</sup>/2" x 11 <sup>1</sup>/2" square hole. Cut and frame the square hole in the exterior wall where the vent will be terminated. If the wall being penetrated is constructed of noncombustible material, such as masonry block or concrete, a 8 <sup>1</sup>/2" hole with zero clearance is acceptable (see Figure 9).



Figure 8 - Vent Pipe Connections




Figure 9 - Vent Opening Requirements

Continued

WARNING: Do not recess vent termination into any wall. This will cause a fire hazard.

6. Noncombustible Exterior Wall: Position the horizontal vent cap in the center of the 8 <sup>1</sup>/<sub>2</sub>" round hole and attach to the exterior wall with four wood screws provided. Before attaching the vent cap to exterior wall, run a bead of non-hardening mastic (pliable sealant) around the outside edges to make a seal between it and the outside wall. Note: The four wood screws provided should be replaced with appropriate fasteners for stucco, brick, concrete or other types of sidings.

Combustible Exterior Wall: For vinyl siding, stucco or wood exteriors, a siding standoff may be installed between the vent cap and exterior wall. The siding standoff prevents excessive heat from damaging the siding materials. Siding material must be cut to accommodate standoff. Bolt the vent cap to the standoff. Apply non-hardening mastic around outside edge of standoff. Position the standoff/cap assembly in the center of the 11 ½" square hole and attach to exterior wall with wood screws provided (see Figure 11). The siding standoff must sit flush against the exterior fascia material.

- 7. Connecting Vent Cap with Horizintal Vent Pipe: Slide the wall firestop over the vent pipe before connecting horizontal run to vent cap (see Figure 12).
- 8. Carefully move fireplace, with vent assembly attached, toward wall and insert vent pipe into horizontal termination. The pipe overlap should be a minimum of 1<sup>1</sup>/<sub>4</sub>" (see Figure 13, page 10).
- Combustible Exterior Wall Only: Slide wall firestop against interior wall surface and attach with screws provided. See Figure 13, page 10, for horizontal termination details.
- 10. Place fireplace into position and shim with noncombustible material if needed. Nail or screw side flanges to framing to secure unit in place. *IMPORTANT*: Make sure fireplace is level before securing. If fireplace is not level it will not work properly.




Figure 10 - Installing Horizontal Vent Cap (Noncombustible Exterior)




Figure 11 - Installing Siding Standoff (Combustible Exterior Wall)




Figure 12 - Connecting Vent Cap with Horizontal Vent Pipe

Continued Minimum Pipe Siding Standoff Overlap 11/4" Direct-Vent Pipe Screws Wall Firestop Maintain 1" Minimum Air Space Around High Wind Outer Pipe When Termination Penetrating a Wall Apply Mastic to Outside 111/2" X 111/2" Edge of

Exterior Wall with Vinvl Siding Figure 13 - Typical Horizontal Termination Cap Mounting with Additional Siding Standoff Installed

Standoff

### **Horizontal Termination Configurations**

Frame Opening

Figures 14 through 18 show different configurations and alternatives for venting with horizontal termination. Each figure includes a chart with critical minimum and maximum dimensions which MUST be met. IMPORTANT: If using a venting configuration of only horizontal venting with no vertical run, a 1/4" rise for every 12" of run toward the termination is required.


NOTICE: Do not seal termination cap to vent pipe. Cap must be removable for vent inspection and maintenance.


**WARNING:** Never run vent downward as this may cause excessive temperatures which could cause a fire. Operation of improperly installed and maintained venting system could result in serious injury, property damage or loss of life.

### **GROUND FLOOR INSTALLATION**

Recommended Applications:

- · Installation using cabinet surrounds
- Through the wall using round or square termination (up to 12" Adjustable pipe)
- NOT FOR CORNER INSTALLATION





\* If installing this fireplace at altitudes of 4000 feet and above, it is recommended that an additional vertical height of 6" be added to the vent system.


Figure 14 - Horizontal Termination Configuration for Square or Round Terminations


### Continued

### **CORNER INSTALLATION**

Recommended Applications:

- · Corner ground floor installation
- Ground floor installation where pipe vents horizontally through wall (over 12" horizontal pipe)
- Basement installation where one foot clearance from ground to termination is possible





	Required	
Vertical (V)	Vertical Pipe	Horizontal (H)
*43 <sup>1</sup> / <sub>2</sub> " min.	None	30" max.
54 <sup>1</sup> / <sub>2</sub> " min.	1 ft.	48" max.
66 <sup>1</sup> /2" min.	2 ft.	60" max.
78 <sup>1</sup> /2" min.	3 ft.	84" max.
90 <sup>1</sup> / <sub>2</sub> " min.	4 ft.	20' max.
* Ground Floor C	orner Venting	

Figure 15 - Horizontal Termination Configuration for Corner Installation Using One 90° Elbow

### SNORKEL TERMINATION INSTALLATION

Recommended Applications:

118197-01D

- Installations requiring a vertical rise on building exterior
- · Any installation using snorkel termination to achieve one foot above ground

Snorkel terminations are available for installations requiring a vertical rise on the exterior of the building. If installing snorkel termination below grade, you must provide proper drainage to prevent water from entering snorkel termination (see Figure 16). Do not back fill around snorkel termination.




Figure 16 - Snorkel Termination Configurations for Below Ground Installation

Continued




Figure 17 - Horizontal Termination Configuration for Venting Using Two 90° Elbows




Figure 18 - Horizontal Termination Configuration for Venting Using Two 90° Elbows with Termination at 90° with Fireplace

Continued

# INSTALLATION FOR VERTICAL TERMINATION

*Note:* Vertical restrictor must be installed in all vertical installations.

- Determine the route your vertical venting will take. If ceiling joists, roof rafters or other framing will obstruct the venting system, consider an offset (see Figure 19) to avoid cutting load bearing members. Note: Pay special attention to these installation instructions for required clearances (air space) to combustibles when passing through ceilings, walls, roofs, enclosures, attic rafters, etc. Do not pack air spaces with insulation. Also note maximum vertical rise of the venting system and any maximum horizontal offset limitations.
- Set the fireplace in desired location. Drop a
  plumb line down from the ceiling to the position of the fireplace exit flue. Mark the center
  point where the vent will penetrate the ceiling.
  Drill a small locating hole at this point.

Drop a plumb line from the inside of the roof to the locating hole in the ceiling. Mark the center point where the vent will penetrate the roof. Drill a small locating hole at this point.





Figure 19 - Offset with Wall Strap and 45° Elbows

### Flat Ceiling Installation

- 1. Cut a 11 1/2" square hole in the ceiling using the locating hole as a center point. The opening should be framed to 11 1/2" x 11 1/2" (29.21 cm x 29.21 cm) inside dimensions, as shown in Figure 9 on page 8 using framing lumber the same size as the ceiling joists. If the area above the ceiling is an insulated ceiling or an attic space, nail firestop from the top side. This prevents loose insulation from falling into the required clearance space. If the area above the ceiling is a living space, install firestop below the framed hole. The firestop should be installed with no less than three nails per side (see Figure 20).
- 2. Assemble the desired lengths of pipe and elbows necessary to reach from the fireplace flue up through the firestop. Be sure all pipe and elbow connections are fully twist-locked (see Figure 8, page 8).
- 3. Cut a hole in the roof using the locating hole as a center point. (Cover any exposed open vent pipes before cutting hole in roof.) The 11 ¹/2" x 11 ¹/2" hole must be measured on the horizontal; actual length may be larger depending on the pitch of the roof. There must be a 1" clearance from the vent pipe to combustible materials. Frame the opening as shown in Figure 9, page 8.
- 4. Connect a section of pipe and extend up through the hole.

**Note:** If an offset is needed to avoid obstructions, you must support the vent pipe every 3 feet. Use wall straps for this purpose (see Figure 19). Whenever possible, use 45° elbows instead of 90° elbows. The 45° elbow offers less restriction to the flow of the flue gases and intake air.

If area above is an attic space or insulated area, install firestop above framed hole.



If area above is a living space, install firestop below framed hole.




Figure 20 - Installing Firestop

### Continued

- 5. Place the flashing over the pipe section(s) extending through the roof. Secure the base of the flashing to the roof and framing with roofing nails. Be sure roofing material overlaps the top edge of the flashing as shown in Figure 19, page 13. There must be a 1" clearance from the vent pipe to combustible materials.
- 6. Continue to add pipe sections until the height of the vent cap meets the minimum building code requirements described in Figure 7 on page 6. *Note*: You must increase vent height for steep roof pitches. Nearby trees, adjoining rooflines, steep pitched roofs and other similar factors may cause poor draft or down-drafting in high winds. Increasing the vent height may solve this problem.
- 7. Twist-lock the vent cap onto the last section of vent pipe.

**Note**: If the vent pipe passes through any occupied areas above the first floor, including storage spaces and closets, you must enclose pipe. You may frame and sheetrock the enclosure with standard construction material. Make sure and meet the minimum allowable clearances to combustibles. Do not fill any of the required air spaces with insulation.

### **Vertical Termination Configurations**

Figures 21 through 24 show four different configurations for vertical termination.




Figure 21 - Vertical Venting Configuration Using Two 90° Elbows with Two Horizontal Runs (Vertical Round High Wind Termination Shown)




Figure 22 - Vertical Venting Configuration Using One 90° Elbow (Vertical Round High Wind Termination Shown)

Continued




Figure 24 - Vertical Venting Configuration With No Horizontal Run (Vertical Round High Wind Termination Shown)

45° Elbow

**Vertical Venting** V = 40' max.

Note: Install

restrictor into

inner collar of

fireplace as shown.

8' min. Note: Vertical  $(V_1)$  + Vertical  $(V_2)$  = 40' max.

20' max.

Figure 23 - Vertical Venting Configuration Using Two 90° Elbows (Vertical Round High Wind Termination Shown)

	ING INSTALLATION INSTRUCTIONS Continued	Number HHT-58	Wall Firestop, 45° Elbow)  Description  High Wind Round Horizontal				
	LIST FOR VENTING KITS MPONENTS	HTS-58	Termination Kit, Galvanized Horizontal Square Termination, Galvanized				
FMI PRO Kits	DUCTS, LLC (5"/8") Pipe & Vent	HTKS-58	(Includes: Square Termination,				
<u>Number</u>	<u>Description</u>		Wall Firestop, 45° Elbow)				
P58-6	6" Section Double Wall Pipe, Galvanized	VT-58	Vertical Round Termination, Galvanized				
P58-12	12" Section Double Wall Pipe, Galvanized	ST-58-14	Galvanized				
P58-24	24" Section Double Wall Pipe, Galvanized	ST-58-36	Galvanized				
P58-36	36" Section Double Wall Pipe,	SC-58	Storm Collar, Galvanized				
	Galvanized	WF-58	Wall Firestop, Galvanized				
P58-48	48" Section Double Wall Pipe, Galvanized	RF-58-6	Roof Flashing - 0 to 6/12 Pitch, Galvanized				
PA58-712	P. Adjustable 7"-12" Section Double Wall Pipe, Galvanized		Roof Flashing - 6/12 to 12/12 Pitch, Galvanized				
E58-45	45° Elbow, Galvanized	VR-58	Vertical Restrictor, Galvanized				
E58-90	90° Elbow, Galvanized	S-58	Vinyl Siding Standoff,				
VKG-58	Ground Floor Vent Kit, Galvanized		Galvanized				
	(Includes: 45° Elbow, 7"-12"	WS-58	Wall Strap				
	Adjustable Pipe, Wall Firestop,	CS-58	Cathedral Ceiling Support				
	Horizontal Square Termination,	FP-58	Firestop Plate				
	16 Screws)	SF-58	Stucco Flashing -				
VKB-58	Basement Vent Kit, Galvanized		For use with HTS-58				
	(Includes: 45° Elbow, 7"-12"	RF-58	Flat Roof Flashing				
	Adjustable Pipe, Wall Firestop, Horizontal Square Termination,	REP	LACEMENT PARTS				
	4' Pipe, 90° Elbow, 20 Screws)		only original replacement parts. This				
VKS-58	Snorkel Vent Kit, Galvanized		ct your warranty coverage for parts				
	(Includes: 45° Elbow, 7"-12"	replaced ur	nder warranty.				
	Adjustable Pipe, Wall Firestop, 36" Snorkel Termination, 4' Pipe,	PARTS I	JNDER WARRANTY				
	1' Pipe, 90° Elbow, 26 Screws)	Contact at	thorized retailers of this product. If				
VKR-58	Roof Vent Kit, Galvanized		ot supply original replacement part(s),				
VIXIX-30	(Includes: 45° Elbow, 7"-12"	,u					
	Adjustable Pipe, Flue Restrictor,	<u></u>					
	Vertical High Wind Termination,	n, ·					
	2' Pipe, 4' Pipe, Wall Firestop,	,					
	Storm Collar, Roof Flashing	<ul> <li>your add</li> </ul>					
	[0/12 - 6/12], 26 Screws)	-	nd serial numbers of your fireplace				
VKC-58	Corner Vent Kit, Galvanized		eplace was malfunctioning				
	(Includes 45° Elbow, 7"-12"	" type of any yeard (propose) I D or notyrel and					
	Adjustable Pipe, Wall Firestop,	, , , , , , , , , , , , , , , , , , , ,					
		F					

Horizontal Termination, 6" Pipe,

90° Elbow, 18 Screws)

HHTK-58 High Wind Round Horizontal Termination Kit

Usually, we will ask you to return the part to the

factory.

### REPLACEMENT PARTS

Continued

### PARTS NOT UNDER WARRANTY

Contact authorized retailers of this product. If they can not supply original replacement part(s), call FMI PRODUCTS, LLC at 1-866-328-4537 for referral information.

When calling, have ready

- · model number of your fireplace
- · the replacement part number

### TECHNICAL SERVICE

You may have further questions about installation, operation or troubleshooting. If so, contact FMI PRODUCTS, LLC's Customer Service Department at 1-866-328-4537. When calling, please have your model and serial numbers of your heater ready.

Youcan also visit FMIPRODUCTS, LLC's website at www.fmiproducts.com.

### **ACCESSORIES**

### NOTICE: All accessories may not be available for all fireplace models.

Purchase these fireplace accessories from your local retailer. If they can not supply these accessories, call FMI PRODUCTS, LLC's Sales Department at 1-866-328-4537 for information. You can also write to the address listed on the back page of this manual.

#### **BRICK LINER KIT**

(Not Shown)

**BL36DA** - Textured Refractory

**BL36DSA** - Standard Refractory

**BL36DHA** - Textured Refractory Herringbone

**BL36DHSA** - Standard Refractory Herringbone

**BL42DA** - Textured Refractory **BL42DSA** - Standard Refractory

**BL42DHA** - Textured Refractory Herringbone

**BL42DHSA** - Standard Refractory Herringbone

This brick liner adds a touch of style to your directvent fireplace. Complete installation instructions included in this manual.

### FACE/I OUVER PANEL KIT

### (Not Shown)

FPD36 - Filigree, Black

FPD36B - Filigree, Brushed Brass

FPD36P - Filigree, Platinum

RLD42 - Rolled Louver, Black

FPD42 - Filigree, Black

FPD42B - Filigree, Brushed Brass

FPD42P - Filigree, Platinum

### **LOUVER TRIM KIT**

### (Rolled Louvers Only) (Not Shown)

LT36B - Brushed Brass

LT36P - Platinum

LT42B - Brushed Brass

LT42P - Platinum

## **DEFLECTION HOODS**

### (Not Shown)

**HD36** - Black (2" Brow)

HD42 - Black (2" Brow)

## PERIMETER TRIM KIT

### (Not Shown)

PT36 - Black

PT36B - Brushed Brass

PT36P - Platinum

PT42 - Black

PT42B - Brushed Brass

PT42P - Platinum

#### MANUAL BLOWER KIT - BK

Manual variable control blower accessory provides better heat distribution. Complete installation and operation instructions


included in this manual.



Provides better heat distribution. Blower turns off and on automatically, as needed. Complete installation and operation instructions included in this manual.

## **ILLUSTRATED PARTS BREAKDOWN**

MODELS (V)DVC36(B)(H) AND (V)DVC42(B)(H)



## **PARTS LIST**

## MODELS (V)DVC36(B)(H) AND (V)DVC42(B)(H)

This list contains replaceable parts used in your fireplace. When ordering parts, follow the instructions listed under *Replacement Parts* on page 16 of this manual.

KEY				
NO.	(V)DVC36(B)(H)	(V)DVC42(B)(H)	DESCRIPTION	QTY.
1	**	**	Firebox Assembly	1
2	**	**	Face Weldment	1
3	108010-01	108328-01	Door Assembly	1
	_	108328-02	Door Assembly (V Models Only)	1
4	108011-01	108331-01	Top Louver Assembly	1
5	108011-02	108331-02	Bottom Louver Assembly	1
6	**	**	Fireplace Top	1
7	**	**	Fireplace Top Insulation	1
8	**	**	Fireplace Surround	1
9	109082-01	109082-02	Heat Shield	1
10	24460	24460	Gas Conduit Assembly	1
11	See Below	See Below	Left Refractory Brick Panel	1
12	See Below	See Below	Rear Refractory Brick Panel	1
13	See Below	See Below	Right Refractory Brick Panel	1
14	108719-01	108455-01	Screen Rod	1
15	12105	107840-01	Screen	2
16	11418	11418	Push-On Nut	2
17	14123	14123	Strain Relief	1
18	21171	21171	Gas Knock-Out Cover	2
19	24353	24353	Handy Box Assembly	1
		PARTS AVAILAB	BLE - NOT SHOWN	
	27253	27253	Notice Label	1
	55240	55240	Vent Label	1

<sup>\*\*</sup> Part not available for field replacement.

rait not available for field replacement.									. ,	
	9	ב מ	5 9	ב מ	5 8	8 5	E S	2 2	Ž,	
REFRACTORY BRICK PANELS	33	ිද්ද	8	8	ن '	ي ر	ن ر	્યુ	7	
PART NO. DESCRIPTION	ð	ð	Ã	ð	ē	ē	ē	VDVCAN	QTY	
110989-02 Left Refractory Brick Panel	•								1	
111215-02 Left Refractory Brick Panel		•							1	
111299-02 Left Refractory Brick Panel			٠						1	
111302-02 Left Refractory Brick Panel				٠					1	
110989-01 Left Refractory Brick Panel					•				1	
111215-01 Left Refractory Brick Panel						•			1	
111299-01 Left Refractory Brick Panel							•		1	
111302-01 Left Refractory Brick Panel								•	1	ı
110991-02 Rear Refractory Brick Panel	•								. 1	
111217-02 Rear Refractory Brick Panel		•							. 1	
111297-02 Rear Refractory Brick Panel			•						. 1	
111330-02 Rear Refractory Brick Panel				•					. 1	
110991-01 Rear Refractory Brick Panel					•				. 1	
111217-01 Rear Refractory Brick Panel						•			. 1	
111297-01 Rear Refractory Brick Panel 111300-01 Rear Refractory Brick Panel							•		. 1	
110990-02 Right Refractory Brick Panel								·	1	i
	Ť									
111216-02 Right Refractory Brick Panel		•							1	
111298-02 Right Refractory Brick Panel			٠						1	
111301-02 Right Refractory Brick Panel				•					1	
110990-01 Right Refractory Brick Panel					•				1	
111216-01 Right Refractory Brick Panel						•			1	
111298-01 Right Refractory Brick Panel							•		1	
111301-01 Right Refractory Brick Panel								•	1	

### WARRANTY

#### **KEEP THIS WARRANTY**

Model (located on product or identification tag)
Serial No. (located on product or identification tag)
Date Purchased
Keep receipt for warranty verification.

### **FMI PRODUCTS, LLC LIMITED WARRANTIES**

#### New Products

Standard Warranty: FMI PRODUCTS, LLC warrants this new product and any parts thereof to be free from defects in material and workmanship for a period of two (2) years from the date of first purchase from an authorized dealer provided the product has been installed, maintained and operated in accordance with FMI PRODUCTS, LLC's warnings and instructions.

For products purchased for commercial, industrial or rental usage, this warranty is limited to 90 days from the date of first purchase.

#### **Factory Reconditioned Products**

Limited Warranty: FMI PRODUCTS, LLC warrants factory reconditioned products and any parts thereof to be free from defects in material and workmanship for 30 days from the date of first purchase from an authorized dealer provided the product has been installed, maintained and operated in accordance with FMI PRODUCTS, LLC's warnings and instructions.

#### Terms Common to All Warranties

The following terms apply to all of the above warranties:

Always specify model number and serial number when contacting the manufacturer. To make a claim under this warranty the bill of sale or other proof of purchase must be presented.

This warranty is extended only to the original retail purchaser when purchased from an authorized dealer, and only when installed by a qualified installer in accordance with all local codes and instructions furnished with this product.

This warranty covers the cost of part(s) required to restore this product to proper operating condition and an allowance for labor when provided by a FMI PRODUCTS, LLC Authorized Service Center or a provider approved by FMI PRODUCTS, LLC. Warranty parts must be obtained through authorized dealers of this product and/or FMI PRODUCTS, LLC who will provide original factory replacement parts. Failure to use original factory replacement parts voids this warranty.

Travel, handling, transportation, diagnostic, material, labor and incidental costs associated with warranty repairs, unless expressly covered by this warranty, are not reimbursable under this warranty and are the responsibility of the owner.

Excluded from this warranty are products or parts that fail or become damaged due to misuse, accidents, improper installation, lack of proper maintenance, tampering, or alteration(s).

This is FMI PRODUCTS, LLC's exclusive warranty, and to the full extent allowed by law; this express warranty excludes any and all other warranties, express or implied, written or verbal and limits the duration of any and all implied warranties, including warranties of merchantability and fitness for a particular purpose to two (2) years on new products and 30 days on factory reconditioned products from the date of first purchase. FMI PRODUCTS, LLC makes no other warranties regarding this product.

FMI PRODUCTS, LLC's liability is limited to the purchase price of the product, and FMI PRODUCTS, LLC shall not be liable for any other damages whatsoever under any circumstances including indirect, incidental, or consequential damages.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

For information about this warranty contact:

