INSTALLER / CONSUMER SAFETY INFORMATION

PLEASE READ THIS MANUAL BEFORE INSTALLING AND USING APPLIANCE.

WARNING! IF THE INFORMATION IN THIS MANUAL IS NOT FOLLOWED EXACTLY, A FIRE OR EXPLOSION MAY RESULT CAUSING PROP-ERTY DAMAGE, PERSONAL IN-JURY OR LOSS OF LIFE.

FOR YOUR SAFETY

Installation and service must be performed by a qualified installer, service agency or the gas suppler.

WHAT TO DO IF YOU SMELL GAS:

- Do not try to light any appliance.
- Do not touch any electric switch; do not use any phone in your building.
- Immediately call your gas supplier form your neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

DO NOT STORE OR USE GASO-LINE OR OTHER FLAMMABLE VAPORS AND LIQUIDS IN THE VICINITY OF THIS OR ANY OTHER APPLIANCE.

This appliance may be installed in an after market permanently located manufactured (mobile) home where not prohibited by local codes.

This appliance is only for use with the type of gas indicated on the rating plate.

This appliance is not convertible for use with other gases unless a certified kit is used.



Jefferson® Direct Vent/Natural Vent Gas Heater Model JDV: 2820, 2822, 2823,

2825, 2827, 2828



Homeowner's Installation and Operation Manual





Tested and listed to ANSI Z21.88b-2001 and CSA-2.33b-2001

Vermont Castings, Majestic Products

410 Admiral Blvd. • Mississauga, Ontario, Canada L5T 2N6 • 905-670-7777 www.majesticproducts.com • www.vermontcastings.com

	Table Of Contents	
PLEAS	E READ THE INSTALLATION & OPERATING INSTRUCTIONS BEFORE USING	G APPLIANCE.
	Thank you and congratulations on your purchase of a Vermont Castings	stove.
ORTANT:	Read all instructions and warnings carefully before starting installation. Fa	ailure to follow the
	instructions may result in a possible fire hazard and will void the warranty	•
Installa	tion & Operating Instructions	
	Stove Dimensions	
	Installation Requirements	5 5
	Clearance Requirements	
	Parallel Installation	
	Corner Installation	6
	Wall and Ceiling Clearances	6
	Hearth Requirements	6
	Gas Specifications	7 7
	Gas met and Manifold Pressures	
	Horizontal Termination - Direct Vent ONLY	7
	Vertical Termination - Direct Vent ONLY	
	Vent Termination Clearances - Direct Vent Only	9
	General Venting Information - Termination Location	10
	Termination Clearances	
	Venting Requirements - Natural Vent ONLY	
Assom	venting Requirements and Options - Direct Vent ONLY	1Z
Assem	Tools Required	13
	Unpack the Stove	
	Install Optional Fan	
	Venting System Assembly - Direct Vent	14
	Install Vent Adapter Pipe (CFM Components)	14
	Install Vent Adapter Pipe (Simpson Dura-Vent Components)	
	Side Wall Termination Assembly	
	Vertical (Through the Roof) Vent Assembly	
	Venting System Assembly - Natural Vent	
	Install the Vent Pipe	19
	Install the Log Set	20
	Connect Gas Supply Line	
	Burner Information	
	Air Snutter Adjustment	
	Install ON/OFF Switch	23
	Install the Stove Front	
	Thermostat Connection (Optional)	
Operati	on	
	Your First Fire	
	Pilot and Burner Inspection	
	Flame & Temperature Adjustment	
	Lighting and Operating Instructions	
	Troubleshooting - Honevwell #8420 Gas Control System	
	Fuel Conversion Instructions	
Mainter	nance	
	Annual System Inspection	30
	Logset and Burner/Cleaning and Inspection	
	Classing the Class	
	Cleaning the Glass	 20
	Gasket Replacement	
	Inspect the Vent System Annually	
	Check the Gas Flame Regularly	
	Stove Dissasembly	31
	Wiring Diagrams	32
	Replacement Parts	
Option	al Accessories	
Warran	ty	

Installation & Operating Instructions

The Jefferson Direct Vent/Natural Vent Room Heater, Model Nos. 2820, 2822, 2823, 2825, 2827 and 2828, is a vented gas appliance listed to the ANSI Standard Z21.88b-2001 and CSA-2.33b-2001 for Vented Room Heaters, and CSA 2.17-M91, Gas-Fired Appliances For Use at High Altitudes.

The installation of the Jefferson Direct Vent/Natural Vent Room Heater must conform with local codes, or in the absence of local codes, with National Fuel Gas Code, ANSI Z223.1 — latest edition and CSA B-149.1 Installation Code. (EXCEPTION: Do not derate this appliance for altitude. Maintain the manifold pressure at 3.5 inches w.c. for Natural Gas and 10 inches w.c. for LP gas at maximum input.)

This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases unless a certified kit is used.

Installation and replacement of gas piping, gas utilization equipment or accessories, and repair and servicing of equipment shall be performed only by a qualified agency. The term "qualified agency" means any individual, firm, corporation, or company that either in person or through a representative is engaged in and is responsible for (a) installation or replacement of gas piping, or (b), the connection, installation, repair, or servicing of equipment, who is experienced in such work, familiar with all precautions required, and has complied with all the requirements of the authority having jurisdiction.

The Jefferson Direct Vent/Natural Vent Room Heater should be inspected before use and at least annually by a qualified service agency. It is imperative that control compartments, burners, and circulating air passageways of the appliance be kept clean.

The Jefferson Direct Vent/Natural Vent Room Heater and its individual shut-off valve must be disconnected from the gas supply piping during any pressure testing of that system at test pressures in excess of 1/2 psig (3.5 kPa).

The Jefferson Direct Vent/Natural Vent Room Heater must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig.

'Direct Vent' describes a sealed combustion system in which incoming outside air for combustion and outgoing exhaust enter and exit through two separate concentric passages within the same sealed vent system. The system does not use room air to support combustion. The Direct Vent system permits the gas appliance to be vented directly to the outside atmosphere through the side of the house or vertically through the roof. Conventional venting systems (Natural Vent) take air from the room for combustion and vent the exhaust vertically through the roof to the atmosphere.

This appliance is approved for bedroom installations in the U.S. and Canada.

This appliance may be installed in an aftermarket* manufactured (mobile) home, where not prohibited by state or local codes.

WARNING: Operation of this heater when not connected to a properly installed and maintained venting system can result in carbon monoxide (CO) poisoning and possible death.

The Jefferson Direct Vent/Natural Vent Room Heater, when installed, must be electrically grounded in accordance with local codes or, in the absence of local codes, with the National Electrical Code ANSI/NFPA 70, (latest edition), or of the current Canadian Electrical Code C22.1.

Due to high temperatures this appliance should be located out of traffic and away from furniture and draperies.

WARNING: This appliance is hot while in operation. Keep children, clothing, and furniture away. Contact may cause burns or ignition of combustible materials.

Children and adults should be alerted to the hazards of high surface temperatures and should stay away to avoid burns or clothing ignition. Young children should be carefully supervised when they are in the same room as the appliance.

Clothing or other flammable materials should not be placed on or near the appliance.

Any safety screen, glass or guard removed for servicing an appliance must be replaced prior to operating the appliance.

The appliance area must be kept clear and free from combustible materials, gasoline, and other flammable vapors and liquids.

The flow of combustion and ventilation air must not be obstructed. The installation must include adequate accessibility and clearance for servicing and proper operation.

WARNING: Do not operate the Room Heater with the glass panel removed, cracked or broken. Replacement of the panel should be done by a licensed or qualified service person.

Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.

Do not burn wood, trash or any other material for which this appliance was not designed. This appliance is designed to burn either natural gas or propane only.

This gas appliance must not be connected to a chimney flue serving a separate solid-fuel burning appliance.

CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

Verify proper operation after servicing.

Proposition 65 Warning: Fuels used in gas, woodburning or oil fired appliances, and the products of combustion of such fuels, contain chemicals known to the State of California to cause cancer, birth defects and other reproductive harm.

California Health & Safety Code Sec. 25249.6

* *Aftermarket:* Completion of sale, nor for purpose of resale, from the manufacturer.

Jefferson Direct Vent/ Natural Vent Stove Dimensions



Fig. 1 Jefferson dimensions.

Attention

The Jefferson stove is shipped from the factory as a Direct Vent Gas Heater. This heater may be converted into a Natural Vent unit in the field. If a Natural Vent heater is desired, the Vermont Castings Z31D00 FSDHAG Draft Hood must be directly installed to the top of the unit according to the installation instructions. The Draft Hood Adapter is available in the 7FSKHASK stove kit or as a separate item.

When the Jefferson stove is converted to Natural Vent, it uses 4" vent pipe. For aesthetic purposes the CFM direct vent system may be used up to the ceiling.

Installation Requirements

The installation must conform with local codes or, in the absence of local codes, with the National Fuel Gas Code, ANSI Z223.1 - latest edition. (EXCEPTION: Do not derate this appliance for altitude. Maintain the manifold pressure at 3.5 inches w.c. for Natural Gas, and 10 inches w.c. for Propane).

In Canada, installation must be in accordance with the current CSA B-149.1 Installation Codes and/or local codes.

The installation should be done by a qualified service person who is familiar with the building codes and installation techniques appropriate for your area to accomplish a safe and effective installation.

Your dealer or your local gas supplier will be able to refer a qualified service person.

WARNING: Due to high temperatures, the HEATER should be located out of traffic and away from furniture and draperies.

The surface of the Heater Is hot when it is in use. Young children should be watched carefully when they are in the same room when the Heater is in use, and they should be taught to avoid the hot surface. Keep any objects that can burn well away from the Heater, and observe the recommended clearances that follow.

Locating the Stove

In choosing a location for the stove, consider:

- The location of outside walls;
- Where additional heat is needed:
- Where family members gather most often;
- The vent system requirements.

NOTE: We do not recommend the use of wallpaper next to this stove. Over time, radiant heat may cause the wallpaper to shrink, or may adversely affect the binders in the wallpaper adhesive.



Fig. 2 Possible stove locations.

Clearance Requirements

Minimum Clearances to Combustible Materials

Measure side clearances as shown in Figures 3 and 4 from the outer edge of the cast iron stove top. Measure rear clearances from the outermost surface of the steel rear skirt.

The Jefferson heater is approved for installation into an alcove constructed of combustible materials to the dimensions and clearances shown on the next page.

The same clearances apply in a standard parallel installation.

WARNING: • Always maintain required clearances (air spaces) to nearby combustibles to prevent fire hazard. Do not fill air spaces with insulation. All venting components must maintain a 1" (25mm) clearance to combustible materials. Maintain a 6" (150mm) clearance when using single wall pipe.

- The gas appliance and vent system must be vented directly to the outside of the building and never be attached to a chimney serving a separate solid fuel or gas-burning appliance.
- Refer to the manufacturer's instructions included with the venting system for complete installation procedures.





Fig. 4 Corner installation, minimum corner clearances and flue centerline.



Hearth Requirements

The Jefferson Heater must be installed on rigid flooring. When the heater is installed directly on any combustible surface other than wood flooring, a metal or wood panel extending the full width and depth of the unit must be used as the hearth. There are no other hearth requirements.

Gas Specifications							
	Max. Input	Min. Input					
Model	Fuel	Gas Control	BTU/h	BTU/h			
JDVRN	Nat	Millivolt	28,000	20,000			
JDVRP	Prop	Millivolt	28,000	19,000			

Weight: Fully assembled; 350 lbs.

Gas Inlet and Manifold Pressures					
Natural LP (Propane)					
Inlet Minimum	5.5" w.c.	11.0" w.c.			
Inlet Maximum	14.0" w.c.	14.0" w.c.			
Manifold Pressure	3.5" w.c.	10.0" w.c.			

Jefferson Direct Vent/Natural Vent Certified to: ANSI Z21.88b-2001 / CSA 2.33b-2001 Vented Gas Fireplace Heaters

The installation of your Vermont Castings stove must conform with local codes, or in the absence of local codes, with the National Fuel Gas Code ANSI Z223.1 - latest edition, or CSA B149.1 Installation code. (EXCEPTION: Do not derate this appliance for altitude up to 4,500 feet (1,370m). Maintain the manifold pressure at 3.5" w.c. for Natural Gas and 10.0" w.c. for LP Gas.

High Elevations

Input ratings are shown in BTU per hour and are certified without deration for elevations up to 4,500 feet (1,370m) above sea level.

For elevations above 4,500 feet (1,370m) in USA, installations must be in accordance with the current ANSI Z223.1 and/or local codes having jurisdiction.

In Canada, please consult provincial and/or local authorities having jurisdiction for installations at elevations above 4,500 feet (1,370m).

WARNING: Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to this manual for correct installation and operational procedures. For assistance or additional information consult a qualified installer, service agency, or the gas supplier.

Horizontal Termination -Direct Vent ONLY

The vent must rise vertically a minimum of 24" (610mm) off the top of the unit, before the first elbow. The horizontal run may extend up to 20' (6m) and include a vertical rise of up to 40' (12m). (Fig. 7) Horizontal termination must also meet the criteria shown in Figures 10 through 12.

- Approved vent systems must terminate above and including the heavy line in Figure 7.
- Two 45° elbows may be substituted for each single 90° elbow.
- With a rise between 2' 6', one 90° or two 45° elbows may be used.



Fig. 7 Horizontal vent termination window.

Vertical Termination - Direct Vent ONLY

A vertical vent system must terminate no less than 8' (2.44m) and no more than 40' (12m) above the appliance flue collar. A 21/4" restrictor plate (supplied) must be used, where specified, in all vertically terminated vent systems. (Refer to Figure 8) **NOTE: The restrictor plate supplied with the vertical termination should be discarded. Install restrictor plate supplied with the stove directly at stove outlet.** A vertically terminated vent system must also conform to the following criteria:

- No more than two 90° elbows may be used.
- Two 45° elbows may be substituted for one 90° elbow. No more than six elbows may be used.
- Vent must rise a minimum of 2 feet before offset is used.
- Termination height must conform to roof clearance as specified in Figure 9.



Fig. 8 Vertical vent termination window.

*The Restictor Plate is used on Direct Vent installations only.

Vent Termination Clearances

When planning the installation, consider the location of the vent terminal and clearances. Some of the most common clearances to keep in mind are shown in Figure 10.

Important: All vent clearances must be maintained. Check your vent termination clearances against Figures 10 and 11.

The vent should be placed so that people cannot be burned by accidentally touching the vent surfaces when the stove is operating.

The vent termination should be located where it cannot be damaged by such things as automobile doors, lawn mowers or snowblowers and it should be located away from areas where it could become blocked by snow, etc.

Some considerations are:

- Obstructions or impediments to venting.
- Nearby combustible materials that could come into contact with combustion exhaust gases.
- Other nearby openings {within 9" (230mm)} through which exhaust gas could reenter the building.
- All vegetation within 3' (.9m) that may interfere with the draft.

Other factors that influence where the installation will be sited include the location of outside walls, where additional heat may be desired in the home, where the family members gather most regularly, and perhaps most importantly, the distance limitations of the venting system.



IMPORTANT Direct Vent Only

- The horizontal termination must not be recessed into the exterior wall or siding.
- Horizontal vent runs must be level toward the vent termination.
- Clearances around the vent termination must be maintained.
- For installations using Simpson DuraVent pipe, parallel installations with minimum wall clearance have restricted access for connecting the Horizontal Vent Cap straps to the vent pipe. See the maker's instructions for recommended installation procedures.

Vent Termination Clearances - Direct Vent ONLY

Your stove is approved to be vented either through the side wall, or vertical through the roof.

- Vermont Castings, Majestic Products does not require any opening for inspection of vent pipe.
- Only Vermont Castings, Majestic Products and Simpson DuraVent venting components specifically approved and labelled for this stove may be used.
- Minimum clearances between vent pipes and combustible materials is one (1") inch (25 mm), except where stated otherwise.
- Venting terminals shall not be recessed into a wall or siding.
- Horizontal venting must be installed on a level plane without an inclining or declining slope.

There must not be <u>any</u> obstruction such as bushes, garden sheds, fences, decks or utility buildings within 24" from the front of the termination hood.

Do not locate termination hood where excessive snow or ice build up may occur. Be sure to check vent termination area after snow falls, and clear to prevent accidental blockage of venting system. When using snow blowers, make sure snow is not directed towards vent termination area.

Location of Vent Termination

It is imperative the vent termination be located observing the minimum clearances as shown in Figure 9.



Fig. 9 Vent termination clearances.



Fig. 10 Termination clearances.



supplied with the stove is not used.

(1) Finishing plate (CG)

Venting Requirements and Options -**Direct Vent ONLY**

Approved Vent System Components

The Stardance Heater must be vented to the outdoors through an adjacent exterior wall or through the roof. The venting system must be comprised of the appropriate listed venting components specified on this page. These parts are available from DuraVent Corporation or your Vermont Castings Majestic Products Dealer.

See Figure 4 for dimensions relevant to the standard minimum-vent kits.

Simpson DuraVent Components

Minimum Horizontal Vent Kit			
Starter Pipe Assembly (incl. inner & outer sectio	ns)		
2768*			
90° Elbow, Blk.	990B*		
45° Elbow, Gal.	945		
6" Straight, Blk.	908B*		
9" Straight, Blk.	907B		
11" - 14%" Adjustable Straight Section	911B		
12" Straight	906		
24" Straight	904B*		
36" Straight	903B		
48" Straight	902		
Horizontal Vent Cap	984*		
Wall Plate*	940		
Vinyl Siding Shield	950		
Snorkel Termination - 14"	982		
Snorkel Termination - 36"	981		
Wall Strap	988		
Cathedral Ceiling Support Box	941		
Storm Collar	953		
Firestop Spacer	963		
Flashing 0/12 - 6/12	943		
Flashing 6/12 - 12/12	943S		
Vertical Termination Cap	991		
*Included in Minimum Horizontal Vent Kit #2792			

All DuraVent Straight vent pipe sections have a net length 11/2" (37mm) less than the nominal dimension; i.e., a 6" (152mm) Straight pipe section has an effective length of 41/2" (115mm).

CFM Vent Components

The following kits are available to meet the needs of most installations. All pipe has a 7" outer diameter and includes a 4" diameter inner section. A (CG) designation indicates the part is finished in Charcoal Gray paint. Consult your dealer about other vent parts that may be appropriate to complete the installation. 7TFSMSK

Min. Through the Wall Vent Kit

- (1) 90-Degree Elbow (CG)
- (1) 24" Straight pipe (CG)
- (1) 36" Straight pipe (CG)
- (1) Side Wall Termination
- (1) Firestop
- (1) Zero-clearance sleeve
- (1) Hardware package

(1) Finishing collar (CG)	
(4) Polished Brass flue pipe rings	
Through the Wall Vent Kit	7TFSDVSK
(1) 90-Degree Elbow (CG)	
(1) 24" Straight pipe (CG)	
(1) 48" Straight pipe (CG)	
(1) Side Wall Termination	
(1) Firestop	
(1) Zero-clearance sleeve	
(1) Hardware package	
(1) Finishing plate (CG)	
(1) Finishing collar (CG)	
(4) Polished Brass flue pipe rings	
Through the Wall Vent Kit for	
Below-Grade Termination	7TFSDVSKS
Includes all of the above parts plus	
(1) Snorkel Termination	
Vertical Termination Kit, 1/12-6/12 Pitch	7TDVSKVA
(1) Combination Horizontal Offset / Roof Supp	port
(1) Vertical Termination	
(1) Storm Collar	
(1) 1/12-6/12 Flashing	
(1) Finishing Plate (CG)	
(1) Finishing Collar (CG)	
(1) Polished Brass Flue Pipe Ring	
(1) Hardware Package	
Vertical Termination Kit, 7/12-12/12 Pitch	7TDVSKVB
(1) 7/12 - 12/12 Flashing	
and all of the other Vertical Termination parts.	
Vertical Termination, Flat Roof	7DVSKVF
(1) Flat Flashing	
and all of the other Vertical Termination parts.	
Twist Lock 24" Straight Pipe (CG)	7TFSDVP24
(1) 24" Non-adjustable Pipe	
(1) Polished Brass Flue Pipe Ring	
Twist Lock 48" Straight Pipe (CG)	7TFSDVP48
(1) 48" Nonadjustable Pipe	
(1) Polished Brass Flue Pipe Ring	
Twist Lock 45-Degree Elbow (CG)	7TFSDVT45
for vertical offsets	
(1) 45-degree Elbow	
(1) Polished Brass Flue Pipe Ring	
Draft Hood Adapter	FSDHAG
NV Stove Kit	7FSSK
(1) 7" Diameter Polished Brass Trim Ring	7FSSK
 (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) 	7FSSK
 (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) 	7FSSK
 (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Plate 	7FSSK
 (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) Dependent States 	7FSSK
 (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) 	7FSSK
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit 	7FSSK 7FSDHASK
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit Includes all parts in the 7FSSK plus the Draft I 	7FSSK 7FSDHASK Hood Adapter
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit Includes all parts in the 7FSSK plus the Draft I FSDHAG 	7FSSK 7FSDHASK Hood Adapter
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit Includes all parts in the 7FSSK plus the Draft I FSDHAG Combination Offset/Roof Support 	7FSSK 7FSDHASK Hood Adapter 7DVCS
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit Includes all parts in the 7FSSK plus the Draft I FSDHAG Combination Offset/Roof Support Attic Insulation Shield 	7FSSK 7FSDHASK Hood Adapter 7DVCS 7DVAIS
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit Includes all parts in the 7FSSK plus the Draft I FSDHAG Combination Offset/Roof Support Attic Insulation Shield 7" Charcoal Gray Pipe Rings, (4) 	7FSDHASK Hood Adapter 7DVCS 7DVAIS 7FSDRG
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit Includes all parts in the 7FSSK plus the Draft I FSDHAG Combination Offset/Roof Support Attic Insulation Shield 7" Polished Brass Pipe Rings (4) 	7FSSK 7FSDHASK Hood Adapter 7DVCS 7DVAIS 7FSDRG 7FSDRP
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit Includes all parts in the 7FSSK plus the Draft I FSDHAG Combination Offset/Roof Support Attic Insulation Shield 7" Charcoal Gray Pipe Rings, (4) 7" Polished Brass Pipe Rings (4) Wall Thimble 	7FSDHASK Hood Adapter 7DVCS 7DVAIS 7FSDRG 7FSDRP 942G
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit Includes all parts in the 7FSSK plus the Draft I FSDHAG Combination Offset/Roof Support Attic Insulation Shield 7" Charcoal Gray Pipe Rings, (4) 7" Polished Brass Pipe Rings (4) Wall Thimble NOTE: Direct vent pipe may be used on the first of the f	7FSDHASK Hood Adapter 7DVCS 7DVAIS 7FSDRG 7FSDRP 942G he Natural
 NV Stove Kit (1) 7" Diameter Polished Brass Trim Ring (1) 48" Nonadjustable Pipe (CG) (1) 24" Nonadjustable Pipe (CG) (1) Finishing Plate (1) Finishing Collar (CG) (1) 90 Degree Elbow (CG) Stove Kit Includes all parts in the 7FSSK plus the Draft I FSDHAG Combination Offset/Roof Support Attic Insulation Shield 7" Charcoal Gray Pipe Rings, (4) 7" Polished Brass Pipe Rings (4) Wall Thimble NOTE: Direct vent pipe may be used on the Vent system from the top of the draft hood 	7FSDHASK TFSDHASK Hood Adapter 7DVCS 7DVAIS 7FSDRG 7FSDRG 942G he Natural d adapter to

Assembly Procedures



WARNING

Failure to position the parts in accordance with these diagrams or failure to use only parts specifically

approved for use with this heater may result in property damage or personal injury.

This heater and components are heavy. Have help available for assembly.

Tools Required

- Phillips screwdriver (stub) power drill
- utility knife
 - knife reciprocating saw
- metal drill bit: size 28 (.140"/3.5mm)

Unpack the Stove

The parts bag containing this manual also includes the following parts:

- Remote Switch
- Switch Bracket
- Switch Wire
- Three 1/4-20 x 3/8" screws
- Cement
- Restrictor Plate
- (2) #10 sheet metal screws

The Logset and 4" Inner Vent Starter Pipe are packed inside the firebox. Use the following procedure to unpack these parts.

- Lift the Stove Front up and then swing the bottom out and away to disengage it from the stove body. Refer to Figure 37, Page 22.
- 2. Swing open the swiveling latches at the top left and right corners of the glass frame. (Fig. 12)



Fig. 12 Swivel the latches to release the glass frame from the firebox.

- 3. Pull the top edge of the glass and frame assembly away from the firebox, and lift it off its supports on the bottom of the firebox face. Place the assembly out of the way on a flat, padded surface such as a counter protected by a towel.
- 4. Take the logset and all other loose parts out of the firebox, and set them aside in a protected area for installation after the venting is complete.

NOTE: Verify the two relief doors (located on top of the firebox) are properly seated on the gasket. The doors should sit flush on the gasket, and should lift easily from the seal around the opening.

Install the Optional Fan

If you are installing the optional convection Fan Kit #2960 (FK28), continue here. If you will not install a Fan Kit, go to page 14, Venting System Assembly.

- The fan kit includes a Blower Assembly and a Rheostat Assembly, connected by a cable. (Fig. 14) The Blower Assembly and the Rheostat mount to the rear shroud of the stove. The assembly includes a 'snapstat' which automatically turns the fan ON (or OFF) above (or below) approximately 109°F (43°C). The Rheostat also provides a range of fan speed settings from Off (which overrides the snapstat function) to HIGH. Unpack and inspect the Blower assembly. Confirm that the fan spins freely.
- 2. Attach the snapstat assembly to the snapstat bracket with two sheet metal screws. (Fig. 18) Remove the 1/4-20 x 3/8" hex head bolt installed in the hole in the right rear ledge of the firebox. Use that bolt to secure the snapstat bracket to the firebox. The mounting hole is slotted to let you adjust the bracket so that the snapstat bracket head makes contact with the firebox. (Fig. 13)



Fig. 13 Snapstat assembly and installation.

- 3. Attach the fan to the rear shroud by engaging the upper flange of the fan skirt under the lower edge of the shroud and secure the skirt with the four screws and one star washer provided. (Fig. 14)
- 4. The rheostat control switch attaches to the left side of the valve bracket at the front of the stove.
 - Remove the plug from the rheostat bracket.

• Insert the switch box shaft through the hole in the back of the right side of the valve bracket, aligning the locator pin with the smaller hole in that bracket.

- Attach the retaining nut to the switch control shaft to secure it to the plate.
- Attach the Control Knob to the rheostat shaft.

• Use the wire tie to secure the fan and rheostat wire harnesses together.



Fig. 19 The upper flange of the fan skirt should be located behind the lower edge of the shroud.



Fig. 20 Correct position of fan skirt installation.

Venting System Assembly - Direct Vent General Information

The Jefferson is approved for installation only with the vent components listed on Page 12. Follow the vent component instructions exactly.

For U.S. installations: The venting system must conform with local codes and/or the current National Fuel Gas Code, ANSI Z223.1

For Canadian installations: The venting system must conform to the current CSA B149.1 installation code.

Install the Vent Adapter Pipe

(CFM Vent Components)

1. Install the Restrictor Plate. Consult the 'Vent Run Specifications' on page 8 to determine whether the restrictor plate is needed. If so, put the restrictor plate in place within the inner flue collar as shown in Figure 16. NOTE: The restrictor plate supplied with the vertical termination should be discarded. Install restrictor plate supplied with the stove directly at stove outlet.



Fig. 16 Install the restrictor plate only if required for the venting configuration. Refer to page 8.

2. Attach Inner Starter Pipe, (found in with the logset), to the next section of inner pipe.

• Run a bead of sealant about 1/2" from the upper end of the Inner starter pipe and join the two sections together.

• Drill three pilot holes into the Inner Starter and secure the assembly with three sheet metal screws. (Fig. 17)

3. Dry fit the Inner pipe assembly to the stove and determine the required vent length.

• Insert the vent assembly into the flue collar, but do not attach. Measure to determine the correct length required for your installation and cut the upper end of the pipe as necessary.

• Dry fit the outer vent section and cut to match the height of the Inner assembly.

• **Side Wall Terminations:** Dry fit the inner elbow with the vertical inner vent and confirm the centerline alignment with the wall thimble opening.

4. Attach the Inner Vent Assembly to the stove.

• Run a bead of sealant around the bottom end of the starter pipe and attach the assembly to the stove using three $1/4-20 \times 3/8$ " Phillips screws provided in the parts bag. (Fig. 18)

5. Install the Outer Adapter Pipe. Apply a 1/4" bead of cement around the inside wall of the pipe, about 1" from the end. Insert the pipe over the stove flue collar, keeping the vertical seam oriented to the back of the stove. Also, be sure to align holes on the pipe with the holes on the flue collar of the firebox. Fasten the pipe to the holes in the flue collar with the #12 x 1/2" sheet metal screws provided. (Fig. 19)



Fig. 17 Connect the inner starter with the next section of inner vent pipe.



Fig. 18 Attach inner assembly to flue collar.



Fig. 19 Fasten outer pipe with #12 x 1/2" sheet metal screw.

Install the Vent Adapter Pipe

(Simpson Dura-Vent Components)

- 1. Install the Restrictor Plate. Consult the 'Vent Run Specifications' on page 8 to determine whether the restrictor plate is needed. If so, put the restrictor plate in place within the inner flue collar as shown in Figure 16.
- 2. Discard the inner starter pipe shipped with the logset. Using the starter pipe assembly listed on page 7, slide the inner section out to allow access.
 Run a bead of sealant around the bottom end of the starter pipe and attach the assembly to the stove using three 1/4-20 x 3/8" Phillips screws provided in the parts bag. (Fig. 20)
- **3.** Install the Outer Adapter Pipe. Apply a 1/4" bead of cement around the outside surface, about one inch from the crimped end. (Fig. 21) Orient the vertical seam to the rear, and insert the crimped end of the outer pipe into the flue collar. Fasten with three sheet metal screws provided.



Fig. 20 Simpson Dura-Vent - install inner adapter pipe.





Side Wall Termination Assembly

 Locate the vent opening on the wall. Refer to Figure 5, Page 6, to determine the opening centerline. It may be necessary to first position the stove and measure to find the hole location. Depending on whether the wall is made of combustible materials, cut the opening to the size shown in Figure 22. Combustible wall openings must be framed as shown in Figure 22.



Fig. 22 Locate vent opening.

- Measure the wall thickness and cut the wall sleeve sections to proper length (MAXIMUM 12"). Assemble the sleeve with the #8 sheet metal screws supplied. Attach the firestop plate to the sleeve end with the holes. (Fig. 23) NOTE: The wall sleeve is required in combustible walls only.
- 3. Install the Wall Firestop/Sleeve assembly into the wall cutout and fasten the firestop to the wall cutout framing members. (Fig. 23)



Fig. 23 Assemble the wall sleeve and firestop.

- *For DuraVent pipe only:* Install vent pipe by aligning the locking system together, sliding the pipes together and twisting clockwise.
 - \bullet Install 90° elbow. Twist lock as before.
 - Slide the wall plate over horizontal run before attaching the horizontal run to the elbow. Fasten wall plate to wall.
- 4. For CFM Vent Pipe only: If necessary, measure to determine the vertical length (X) of pipe required from the adapter pipe to the wall cutout centerline, including a 2" overlap at the joint. (Fig. 24) use a hacksaw or tin snips to trim the pipe as needed.



Fig. 24 Determine the vertical pipe length.

5. Install first the inner then the outer straight pipe section(s), trimmed end down, to the point of the elbow. Drill 3 holes through each joint and fasten with sheet metal screws.

- 6. Seal and install the elbow using 3 sheet metal screws at each joint.
- Measure, and cut if needed, the appropriate length of pipe section needed to make the connection through the wall. Include a 2" overlap; i.e. from the elbow to the outside wall face, about 2" or the distance required if installing a second 90° elbow. (Fig. 25)
- 8. Slip the wall plate and trim collar over the interior end of the horizontal pipe and install into the wall sleeve. Seal the joint inside the wall plate if needed to keep cold air from being drawn into the home.
- 9. Seal the ends and connect the horizontal pipe to the elbow. Fasten the wall plate to the pipe with three sheet metal screws. Slide the trim collar up against the wall plate to cover the screws. (Fig. 26)



Fig. 25 Measure the horizontal length.



Fig. 26 Install the horizontal pipe and wall plate parts.

10. For both CFM and DuraVent Systems: Install the vent terminal. (Fig. 27) Apply high temperature sealant one inch from the ends of the inner and outer collars. Guide the inner and outer vent termination collars into the adjacent pipes. Double check that the vent pipes overlap the collars by 2". Fasten the termination to the wall with the screws provided, and caulk the joint with weatherproof sealant.

11. For CFM only: Install Charcoal Gray Pipe Rings (#7FSDRG) or Polished Brass Pipe Rings (#7FSDRP) at pipe joints, if desired.





Vent Termination Below Grade

Install Snorkel Kit #7FSDVSKS when it is not possible to meet the required vent termination clearances of 12" (305mm) above grade level. The snorkel kit will allow installation depth of down to 7" (178mm) below grade level. The seven inches is measured from the center of the horizontal vent pipe as it penetrates the wall. If the venting system is installed below grade, a window well must be installed with adequate and proper drainage. (Fig. 28)

NOTE: Be sure to maintain side wall clearances and vent run restrictions. Refer to Figures 3, 4, 7, and 8.

- 1. Establish the vent hole through the wall.
- Remove soil to a depth of approximately 16" (400mm) below the base of the snorkel. Install a window well (not supplied). Refill the hole with 12" (305mm) of coarse gravel and maintain a clearance of at least 4" (100mm) below the snorkel. (Fig. 28)
- 3. Install the vent system as described on pages 15-18.
- 4. Be sure to make a watertight joint around the vent pipe joint at the inside and outside wall joints.
- 5. Apply high temperature sealant around the inner and outer snorkel collars. Join the pipes and fasten the snorkel termination to the wall with the screws provided.
- 6. Level the soil to maintain a 4" clearance below the snorkel.

If the foundation is recessed, use extension brackets (not supplied) to fasten the lower portion of the snorkel. Fasten the brackets to the wall first, and then fasten to the snorkel with self-tapping #8 x 1/2" sheet metal screws. Extend the vent pipes out as far as the protruding wall face. (Fig. 29)



Fig. 28 Snorkel kit installation.



Fig. 29 Use extension brackets to mount snorkel against recessed wall.

Vertical (Through the Roof) Vent Assembly

Note that all vertically terminated installations must include the restrictor plate included with the stove. Refer to Figure 8, Page 8.

Make certain the vent system conforms to all other requirements for vertical termination as specified on Page 8.

This installation will require you to first determine the roof pitch and use the appropriate vent components. Refer to Figures 8 and 9 on pages 8 and 9.

- 1. Locate the final position of the stove, observing all clearances for both the vent and the stove.
- 2. Plumb to the center of the inner (4") flue collar from the ceiling above, and mark that location.
- Cut the opening: CFM System: 9%" x 9%" (240mm x 240mm) DuraVent System: 10" x 10" (254mm x 254mm)
- 4. Plumb any additional opening through the roof or other construction that may be needed. In all cases, the opening must provide a minimum of 1" (25mm) clearance to the vent pipe.
- 5. Place the stove in its final position.
- Install firestop(s) #7DVFS and Attic Insulation Shield #7DVAIS as needed. (Fig. 30) If there is a room above ceiling level, a firestop must be installed on both the bottom and top sides of the ceiling joists. If an attic is above ceiling level, an attic insulation shield must be installed.



Fig. 30 Install firestops and attic insulation shield.

- 7. Install the appropriate roof support and flashing, making certain that the upper flange of the flashing base is below the shingles. (Fig. 31)
- 8. Install appropriate pipe sections until the vent run reaches above the flashing. The enlarged ends of the vent sections always face downward.

- Install the storm collar and seal around the joints. (Fig. 31)
- 10. Add additional vent lengths to achieve the proper overall height.
- 11. Apply cement to the inner and outer termination collars and install the terminal cap.



Fig. 31 Roof support and flashing.

Venting System Assembly - Natural Vent General Information

The Jefferson Heater is shipped from the factory as a Direct Vent Heater. It may be converted to a Natural Vent heater by installing the Vermont Castings Model Z31D00 FSDHAG Draft Hood Adapter.

The Jefferson Heater is approved for installation as a Natural Vent. CFM Direct Vent pipe could be used directly after the Draft Hood Adapter up to the ceiling, then B-vent pipe must be used. Do not mix types of Bvent pipe; use components from one maker or the other. Follow the vent component maker's instructions exactly. The heater will also accept standard or enamelled 7" (150mm) diameter pipe, around the Type B venting, for decorative purposes only. (Fig. 32)

NOTE: The restrictor plate supplied with the stove is not used for Natural Vent applications.

The Jefferson stove, when installed as a Natural vent heater, includes a vent safety switch. (Fig. 64, Page 33)



Fig. 32 Decorative 7" pipe may be fitted around the B-vent pipe.

Operating the stove when it is not connected to a properly installed and maintained venting system, or tampering with or disconnecting the vent safety switch, can result in carbon monoxide (CO) poisoning and possible death.

For U.S. installations: The venting system must conform with local codes and/or the current National Fuel Gas Code, ANSI Z22.1.

For Canadian installations: The venting system must conform to the current CSA B149.1 installation code.

Install the Vent Pipe

Apply a bead of sealant around bottom end of inner starter pipe (found in bag with logset) and attach to stove. Apply a bead of sealant around top of inner starter pipe and install the Z31D00 FSDHAG Draft Hood according to Draft Hood instructions. (Fig. 33)

Attach the first section of venting to the draft hood. Depending on the length of the individual venting sections and the lengths of the decorative pipe (if installed), you may need to slip the decorative pipe over the venting sections before attaching upper sections to lower ones. The sections of decorative pipe should be oriented with their seams (if any) toward the wall; sections usually do not need to be fastened at each joint, other than slip sections. If the layout includes a slip section, this should be the last section of pipe visible in the room, at the ceiling. Complete the venting according to the vent maker's instructions.



Fig. 33 Install draft hood adpater.

Install the Log Set

- 1. Remove the logs from their packaging, and inspect each piece for damage. DO NOT INSTALL DAM-AGED LOGS.
- Install the rear log 1 by centering it side to side on the sheet metal shelf at the back of the firebox. (Fig. 34)
- 3. Install the left (2) and right (3) middle logs by engaging holes on their bottoms with pins on the burner brackets. (Fig. 34)
- Loosely sprinkle the lava rocks directly on top of the burner between the decorative grate and the middle logs. Do not place any ember material behind the middle logs. (Fig. 35)
- Engage the upper log 4 with the rear log and the right middle log as shown in Figure 35. Engage the top log 5 with the upper log and the left middle log. (Fig. 35)



Fig. 34 Install the back, left and right logs.



Fig. 35 Install lava rock and upper logs.



Fig. 36 Completed log installation.

Connect the Gas Supply Line

Check the Rating Plate attached by a steel cable to the firebox, to confirm that you have the appropriate firebox for the type of fuel to be used. The Jefferson may be converted from one gas to another using the appropriate Fuel Conversion Kit listed on page 34.

In the U.S.; Gas connection should be made in accordance with current National Fuel Gas Code, ANSI Z223.1. Since some municipalities have additional local codes, be sure to consult you local authority.

In Canada; consult the local authority and CSA-B149.1 installation code.



Always check for gas leaks with a mild soap and water solution. Do not use an open flame for leak testing.

Light the pilot according to the directions on page 26, before going to the next step.

CAUTION

This appliance should only be connected by a qualified gas technician. Test to confirm manifold pressures as specified below.

The Jefferson Heater and its individual shutoff valve must be disconnected from the gas supply piping during any pressure testing of that system at test pressures in excess of 1/2 psig (3.5 kPa).

The Jefferson Heater must be isolated from the gas supply piping system by closing its individual manual shutoff valve during any pressure testing of the gas supply piping system at test pressure equal to or less than 1/2 psig.

There must be a gas shutoff between the stove and the supply.

In order to connect Natural Gas, use a fitting with 3/8" NPT nipple on the valve side and 1/2" natural gas supply line with an input of 28,000 BTUs at a manifold pressure of 3.5" and minimum inlet supply for adjustment of 5.5" w.c.

In order to connect Propane, use a fitting with 3/ 8" NPT nipple on the valve side and 1/2" propane gas supply line with an input of 28,000 BTUs at a manifold pressure of 10.0" and minimum inlet supply for adjustment of 11.0" w.c.

Burner Information

The appliance must only use the gas specified on the rating plate, unless converted using a Vermont Castings Fuel Conversion Kit. To convert from LP to Natural Gas use Kit #000-5021. To convert from Natural Gas to LP use Kit #000-5022.

Conversion instructions are provided with each kit and beginning on Page 28 in this manual.

THIS APPLIANCE SHOULD BE CONNECTED TO THE GAS SUPPLY ONLY BY A QUALIFIED GAS SERVICE TECHNICIAN. FOLLOW ALL LOCAL CODES.

THERE MUST BE A GAS SHUT-OFF BE-TWEEN THE STOVE AND THE SUPPLY.

In order to connect Natural Gas, use a fitting with 3/8" NPT nipple on the valve side and 1/2" natural gas supply line with an input of 28,000 BTUs at a manifold pressure of 3.5" and minimum inlet supply for adjustment of 5.5" w.c.

In order to connect Propane, use a fitting with 3/8" NPT nipple on the valve side and 1/2" propane gas supply line with an input of 28,000 BTUs at a manifold pressure of 10.0" and minimum inlet supply for adjustment of 11.0" w.c.

Air Shutter Adjustment

The Jefferson is shipped from the factory with the air shutter adjusted to the minimum allowed opening. Refer to Table 1. Based on the altitude where the stove is located, a shutter adjustment is acceptable to provide a mixed balance of flame color/glow. To adjust the shutter opening, follow the steps below.

NOTE: The air shutter may only be adjusted to a more open position. The factory setting is the **minimum** allowable air shutter opening.

Table 1. Air Shutter Adjustment Minimum rear injector air inlet openings.

Model	Natural Gas	LP
Direct Vent	1⁄2"	1/2"
Natural Vent	1⁄2"	1"

Air Shutter Adjustment Instructions

To adjust the air shutter, the following procedures should be followed:

- 1. Remove stove front. Lift stove front up and then swing bottom out and away to disengage from the stove body. (Fig. 37)
- 2. Swing open the swiveling latches at the top left and right corners of the glass frame. (Fig. 12, Page 13)



Fig. 37 Remove stove front.

- 3. Pull the top edge of the glass and frame assembly away from the firebox, and lift it off its supports on the bottom of the firebox face. Place the assembly out of the way on a flat, padded surface such as a counter protected by a towel.
- 4. Take the logset out of the firebox if previously installed.
- 5. Remove the rear log bracket by unfastening the screw. (Fig. 38)
- 6. Remove the right and left log bracket assembly by unfastening the two screws which hold the burner in place. (Fig. 38)



Fig. 38 Remove rear log bracket and left and right log bracket assembly.

- 7. Hold the burner at the right hand side and lift to clear the right burner leg. Then pull to the right to clear the injectors on the left hand side.
- The air shutter is located on the bottom of the burner to the left. (Fig. 39) Unfasten the two nuts holding the shutter in place. The shutter may be adjusted between the factory adjusted 1/2" to fully open. Reassemble the shutter to allow the rear injector air

inlet to close from a minimum 1/2" opening to fully open. (Fig. 40) You may have to try more than once to find the correct air shutter opening for best results depending on your altitude.



Fig. 39 Air shutter in original from-the-factory position.



Fig. 40 Air shutter adjusted.

- 9. Refasten the two nuts and assemble the burner into the unit by sliding the burner in at an angle with the left side lower than the right side. Slide the left side onto the injectors. Lower the right hand side down into place. Make sure the burner is as far left as possible and the injector shoulders are inside the burner. **NOTE:** It is very critical to keep the left burner leg, which holds the injectors, at a 90° angle to the base. (Fig. 41) This keeps the orifices aligned with tubes on the inside of the burner. Failure to do so could affect the flame appearance and performance of the unit.
- 10.Refasten the right and left log bracket assembly.
- 11.Refasten the rear log bracket.
- 12.Replace logs.
- 13.Replace glass and stove front.

Follow lighting instructions on page 26. Check flame color appearance. **NOTE:** Allow stove to burn for at least 1/2 hour to establish full flame color.

Should color need further adjustment, repeat steps 1 - 12 for air shutter adjustment.





Complete the Assembly

- Open the swiveling latches (cams) on the top left and right corners of the glass frame.
- Position the glass and frame against the firebox by placing the bottom edge on the brackets on the bottom face of the firebox.
- Swing the assembly against the firebox, and close the latches firmly against the pins protruding from the firebox top.

Install ON/OFF Switch

The switch assembly parts are found in the parts bag.

- Attach switch assembly to left rear side of stove shroud using two screws and existing holes in shroud. (Fig. 42)
- 2. Run wires down back of stove, under bottom of rear shroud to valve.
- 3. Attach wires to valve terminals. (Fig. 43)



Fig. 42 Attach switch assembly to rear shroud.



Fig. 43 Attach switch wires to valve.

Install the Stove Front

The Front Plate attaches to the stove by four steel tabs that engage with corresponding cast ribs on the sides and bottom of the stove body. Position the Front about 3" down from stove top and lift the plate to engage the upper tabs behind the adjacent ribs on the sides. (Fig. 44) Then lower the plate into position, so that the lower tabs engage with the corresponding ribs at the bottom. (Fig. 45)

When properly installed, the bottom of the Stove Front cannot be pulled away from the sides without also lifting it.







Fig. 45 Engage with side ribs.

Thermostat Connection (optional)

Use only a thermostat rated for 500 millivolts.

Check the table below for the appropriate gauge thermostat wire to use for the length of lead required in your installation.

Thermostat Wire / Gauge	Maximum Run
18	20 feet
16	20 - 40 feet
14	up to 60 feet

1. Install the wall thermostat in the desired location and run the wires to the stove location. Terminate these leads with 1/4" female connectors.

2. Connect the thermostat wires to the valve. (Fig. 43)

This completes assembly of the Jefferson stove.

Operation

Your First Fire

Read these instructions carefully and familiarize yourself with the burner controls. Locate the pilot assembly, Figure 46. Follow the lighting instructions on Page 28 exactly.

During the first fire, it is not unusual to smell some odor associated with new logs, paint and metal being heated. Odors should dissipate within an hour or so, however, you can open a window to provide fresh air to alleviate the condition.

Pilot and Burner Inspection

Each time you light your heater check that the pilot flame and burner flame pattern are as shown in Figure 47 or Figure 48 and Figure 49. If flame patterns are incorrect, turn the heater off. Contact your dealer or a qualified gas technician for assistance. Do not operate the heater until the pilot flame is correct.

Follow regular maintenance procedures as described on Page 30.



Fig. 46 Pilot Assembly location.

Flame & Temperature Adjustment

For stoves equipped with HI/LO valves, flame adjustment is accomplished by rotating the HI/LO adjustment knob located near the center of the gas control valve. (Fig. 47)



Fig. 47 Flame adjustment knob for Honeywell valve.

Flame Characteristics

It is important to periodically perform a visual check of the pilot and the burner flames. Compare them to Figures 48 - 50. If any of the flames appear abnormal, call a service person.







Fig. 49 Correct pilot flame pattern. SIT Valve.



Fig. 50 Correct burner flame pattern.

Lighting And Operating Instructions FOR YOUR SAFETY READ BEFORE LIGHTING

WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

- A. This heater has a pilot which must be lit manually. When lighting the pilot follow these instructions exactly.
- B. BEFORE LIGHTING smell all around the heater area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any fireplace
- Do not touch any electric switch
- Do not use any phone in your building
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.

- If you cannot reach your gas supplier, call the Fire Department
- C. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, do not try to repair it, call a qualified service technician. Applying force or any attempted repair may result in a fire or explosion.
- D. Do not use this fireplace if any part has been under water. Immediately call a qualified service technician to inspect the heater and to replace any part of the control system and any gas control which has been under water.

Lighting Instructions

- 1. **STOP!** Read the safety information above.
- 2. Turn off all electrical power to the fireplace.
- For MN/MP/TN/TP appliances ONLY, go on to Step 4. For RN/RP appliances turn the On/Off switch to "OFF" position or set thermostat to lowest level.
- 4. Open control access panel.
- 5. Push in gas control knob slightly and turn clockwise row to "OFF".



- Wait five (5) minutes to clear out any gas. Then smell for gas, including near the floor. If you smell gas, STOP! Follow "B" in the safety information above. If you do not smell gas, go to the next step.
- 7. Remove glass door before lighting pilot. (See Glass Frame Removal section).
- 8. Visibly locate pilot by the main burner.
- Turn knob on gas control counterclockwise
 to "PILOT".

10. Push the control knob all the way in and hold. Immediately light the pilot by repeatedly depressing the piezo spark ignitor until a flame appears. Continue to hold the control knob in for about one (1) minute after the pilot is lit. Release knob and it will pop back up. Pilot should remain lit. If it goes out, repeat steps 5 through 8.



- If knob does not pop up when released, stop and immediately call your service technician or gas supplier.
- If after several tries, the pilot will not stay lit, turn the gas control knob to "OFF" and call your service technician or gas supplier.
- 11. Replace glass door.
- 12. Turn gas control knob to "ON" position.
- 13. For RN/RP appliances turn the On/Off switch to "ON" position or set thermostat to desired setting.
- 14. Turn on all electrical power to the fireplace.

To Turn Off Gas To Heater

- 1. Turn the On/Off switch to Off position or set the thermostat to lowest setting.
- 2. Turn off all electric power to the fireplace if service is to be performed.
- 3. Open control access panel.

- 4. Push in gas control knob slightly and turn clockwise _____ to "OFF". Do not force.
- 5. Close control access panel.

Troubleshooting / Honeywell #8420 Gas Control System

NOTE: Before troubleshooting the gas control system, be sure the external gas shutoff is in the "ON" position. WARNING: REMOVE THE GLASS PANEL BEFORE PERFORMING ANY GAS CONTROL SERVICE WORK.

SYMPTOM	POSSIBLE CAUSES	CORRECTIVE ACTION
 Spark ignitor will not light 	A. Defective or misaligned electrode at the pilot	Using a match, light pilot. If pilot lights, turn off pilot and push the ignitor button again. If pilot will not light, check gap at electrode and pilot - it should be 1/8" to have a strong spark.
	B. Defective ignitor (push button)	Push piezo ignitor button. Check for spark at electrode and pilot. If there is no spark at the pilot, and electrode wire is properly connected, replace ignitor.
2. Pilot will not stay lit after carefully following the lighting instructions	A. Defective pilot generator (thermocouple)	Check pilot flame. It must impinge on the thermocouple or thermopile. NOTE: This pilot burner assembly uses both a thermocouple and a thermopile. The thermo- couple operates the pilot flame. Tighten the thermo- couple. The thermopile operates the main valve (ON and OFF). Clean and/or adjust pilot for maximum flame impingement on thermocouple and thermopile.
	B. Defective automatic valve operator	Turn valve knob to 'Pilot'. Maintain flow to pilot; millivolt meter should read greater than 10mV. If the reading is okay and the pilot does not stay on, replace the gas valve. NOTE: An interrupter block (not supplied) must be used to conduct this test.
3. Pilot lights, no gas to burner, valve knob ON, remote switch (rocker	A. Remote switch or wires defective	Check rocker switch and wires for proper connection. Use jumper wires across terminals at rocker switch. If burner lights, replace rocker switch. If okay, use jumper wires across rocker switch wires at the valve; if burner lights, wires are faulty or connections are bad.
switch) ON	B. Thermopile may not gener- ate sufficient voltage	1. Be sure wire connections from thermopile at gas valve terminals are tight and thermopile is fully inserted into pilot bracket.
		 One of the rocker switch wires may be grounded. Remove rocker switch wires from valve terminals. If burner now stays lit, trace rocker switch wiring from ground. It may be grounded to the appliance or the gas supply line.
		3. Check the thermopile with a millivolt meter. Take reading at thermopile ("TP" and "TP/TH") terminals of gas valve. Should read 325 millivolts minimum while holding valve knob depressed in PILOT position and with rocker switch OFF. Replace faulty thermopile if reading is below specified minimum.
	C. Plugged burner orifice	Check burner orifices for debris, and remove.
	D. Defective automatic valve operator	Turn knob to ON, place rocker switch to ON, millivolt meter should read greater than 10 mV. If the reading is okay and the burner does not light, replace the valve.
4. Frequent pilot outage	A. Pilot flame may be too low or high, (blowing or lifting), causing the pilot to drop out	Clean and/or adjust pilot flame for maximum flame impingement on thermocouple and thermopile.
	 B. Possible blockage of the vent terminal 	Check the vent terminal for blockage.

Fuel Conversion Instructions

WARNING! This conversion kit shall be installed by a qualified service agency in accordance with the manufacturer's instructions and all applicable codes and requirements of the authority having jurisdiction. If the information in these instructions is not followed exactly, a fire, explosion or production of carbon monoxide may result causing property damage, personal injury or loss of life. The qualified service agency is responsible for the proper installation of this kit. The installation is not proper and complete until the operation of the converted appliance is checked as specified in the manufacturer's instructions supplied with the kit.

CAUTION: The gas supply shall be shut off prior to disconnecting the electrical power, before proceeding with the conversion.





Conversion Precautions

Before proceeding, turn control knob on valve to OFF and turn gas supply OFF. Turn OFF any electricity that may be going to the appliance.

Conversion Procedure

- Remove stove front. Lift stove front up and then swing bottom out and away to disengage from the stove body. (Fig. 59, Page 31)
- 2. Swing open the swiveling latches at the top left and right corners of the glass frame. (Fig. 60, Page 31)
- 3. Pull the top edge of the glass and frame assembly away from the firebox face. Place the assembly out of the way on a flat, padded surface such as a counter protected by a towel.
- 4. Remove the logset from the firebox.
- 5. Remove cap from Hi-Lo knob. This can be accomplished by lifting the plastic cap off the screw. (Fig. 52)
- 6. Remove the screw from center of Hi-Lo knob with small screwdriver turning counterclockwise. (Fig. 52)
- 7. Insert blue painted screw when converting to natural gas and red painted screw when converting to LP.



- Fig. 52 Remove center screw from Hi-Lo knob.
- 8. Tighten screw, replace cap.
- 9. Remove the rear log bracket by unfastening the screw. (Fig. 53)
- 10.Remove the right and left log bracket assembly by unfastening the two screws which hold the burner in place. (Fig. 53)
- 11.Hold the burner at the right hand side and lift to clear the right burner leg. Then pull to the right to clear the injectors on the left hand side.
- 12.Locate pilot. (Fig. 53)
- 13. Replace pilot orifice.



Fig. 53 Remove rear log bracket and left and right log bracket assembly.

Pilot Type 1

• Remove pilot hood by lifting up. (Fig. 54) **NOTE:** Do not remove snap ring to remove pilot hood. **NOTE:** It is not necessary to remove the pilot tube for conversion.

- Remove pilot orifice with allen wrench. (Fig. 55)
- Install the conversion orifice.
- Reinstall pilot hood. Be sure to align hood with index tab.

Pilot type 2

• Loosen pilot hood by turning counterclockwise using a 7/16" wrench. (Fig. 56) **NOTE:** You may use penetrating oil to prevent pilot hood threads from seizing up.



Fig. 54 Remove pilot hood.



Fig. 55 Remove pilot orifice.



Fig. 56 Remove pilot hood.

- Remove pilot orifice with needlenose pliers. (Fig. 57) **NOTE:** Use a wrench to hold pilot tube in place while removing the orifice.
- Install the conversion orifice.
- Reinstall pilot hood and tighten until mark on pilot hood aligns with mark on pilot bracket.
- 14.Remove injector orifices from left burner leg using 1/ 2" wrench. (Fig. 58)
- 15.Install conversion orifices. (Refer to Table 2)
- **NOTE:** Be sure burner leg remains at a 90° angle to firebox base after conversion.



Fig. 57 Remove pilot orifice.

- 16.Replace burner. Slide the burner in at an angle with left side lower than the right side. Slide the left side onto the injectors, making sure the burner leg remains at a 90° angle to the base. Lower the right hand side down in to place. Make sure the burner is as far left as possible and the injector shoulders are inside the burner.
- **NOTE:** It is very critical to keep the left burner leg, which holds the injectors, at a 90° angle to the base. (Fig. 58) This keeps the orifices aligned with the tubes inside burner. Failure to do so could affect the flame appearance and performance of the unit.
- 19.Place conversion label on valve.
- 20.Reinstall the right and left log bracket assembly.
- 21.Reinstall the rear log bracket.
- 22.Replace logs.

23.Replace glass and stove front.

Conversion is complete.



Fig. 58 Remove and replace injector orifices.

Table 2. Injector Orifice Size Matrix							
Conversion to Natural Gas Input (BTU/h)							
Kit # Front Part # Rear Part #					Minimum	Maxi,mum	
000-5021	#54 / .055"	20000130	#44 / .086"	30000334	19,000	28,000	
Conversion to LP Input (BTU/h)							
Kit #	Front	Part #	Rear	Part #	Minimum	Maximum	
000-5022	#69 / .029"	30000513	#54 / .055"	20000130	20,000	28,000	

Maintenance

Your Jefferson Gas Heater will provide years of service with minimal upkeep. The following procedures will help ensure that you stove continues to function properly.

Annual System Inspection

Have the entire heater and venting system inspected annually by a qualified gas technician. Replace any worn or broken parts.

Logset and Burner / Cleaning and Inspection

Cleanliness is critical to the proper function of the heater. The logset and burner must all be kept free of dust and unobstructed by debris. Inspect these areas before each use and clean as necessary.

- 1. Turn the burner OFF and let the heater cool completely before cleaning.
- 2. Lift the Stove Front up and then swing the bottom out to disengage it from the heater shell. (Fig. 59)
- 3. Carefully remove the glass and frame assembly and place it out of the way on a flat, padded surface such as a counter protected by a towel.
- Carefully inspect the Logs for damage. Contact your local dealer if any damage is evident. DO NOT OPERATE THE HEATER WITH DAMAGED LOGS.
- Use a soft bristled brush to sweep dust or debris from the Logs, Pilot and Burner. Use care as the logs are fragile and susceptible to damage. DO NOT USE A VACUUM TO CLEAN THE LOGS OR BURNER.
- 6. Replace the glass panel and frame assembly.
- 7. Replace the Stove Front.

Care of Cast Iron

An occasional dusting with a dry rag will help keep the *painted surfaces* looking new. Use high-temperature stove paints, available through your local dealer, to touch-up areas as needed. Clean areas to be painted with a wire brush and be sure to cover the logs, burner and valve assembly, glass and frame assembly. Apply the paint sparingly; two light coats of paint will give better results than a single heavy coat.

Clean *porcelain enamel surfaces* with a soft, damp cloth. Do not use abrasive cleaning agents. If necessary, use only a cleaning agent formulated especially for use on porcelain enamel surfaces.

CAUTION

TURN THE PILOT <u>OFF</u> BEFORE PAINTING. ALLOW THE HEATER TO COOL COMPLETELY BEFORE PAINTING.

Cleaning the Glass

WARNING: Let the glass cool completely before attempting to clean.

It will be necessary to clean the glass periodically. During start-up, condensation, which is normal, forms on the inside of the glass and causes lint, dust and other airborne particles to cling to the glass surface. Also, initial paint curing may deposit a slight film on the glass. It is therefore recommended that the glass be cleaned two or three times with a non-ammonia household cleaner and warm water (we recommend gas fireplace glass cleaner). After that the glass should be cleaned two or three times during each heating season depending on the circumstances present.



Clean glass after first two weeks of operation.

Glass Replacement

Replace glass only with Vermont Castings approved parts. Refer to Page 34 for Replacement Parts. Refer to Figure 60 and previous instructions for removal of the damaged glass frame.



Fig. 59 Remove the Stove Front.



Fig. 60 Release the latches to release the glass frame.

Gasket Replacement

The Jefferson Gas Heater uses a 'tadpole' type gasket to seal between the glass panel and the frame. In time, this gasket can become brittle and compressed and should be replaced. New gasket is available from your dealer.

Shut off the gas supply and allow the stove to cool. Wear safety goggles and a dust mask.

- Remove the Front, Glass Frame and Glass Panel. (Figs. 59 & 60) Remove the old gasket. Use a razor blade to separate the glass and gasket from the frame, and to clean the glass of any remaining cement or bits of gasket. Use a cold chisel if necessary.
- Determine the correct length of gasket by laying it out around the edge of the glass. Allow an extra 1 -2" (25-50mm). Mark the spot to be cut. Use a utility knife.
- 3. Starting on a long edge, remove about 6" of the protective paper strip and apply the flat adhesive face of the gasket around the outside-facing edge of the panel. Continue around the panel, applying a bout 6" at a time and being careful to not stretch the material. Do not overlap the gasket ends. (Fig. 61)
- 4. Apply a thin bead of high temperature silicone rubber sealant along the inside corner of the glass frame, all around the perimeter. Place the flat gasketed side of the glass panel back into the steel frame. Pinch the rounded inside-facing gasket material to bulk it up.
- 5. Replace the glass frame and front panel as previously described.



Fig. 61 Wrap the gasket material around the outside edge of the glass.

Inspect the Vent System Annually

Have the vent system inspected annually by a qualified technician. Shut off the main gas supply before inspecting the system. Both the inner exhaust pipe and the outer combustion supply pipe must be checked to confirm that they are unblocked and in good condition.

Check the Gas Flame Regularly

To ensure that the stove is operating properly, check the flames periodically to confirm that they match Figure 62. The flames will be blue during the first 15-20 minutes of operation, and will gradually turn to yellow after that.

Do not use your stove if the flame pattern differs from that shown here. Contact your Vermont Castings dealer or a qualified technician for help.





Stove Disassembly

If there is ever a need to remove the firebox assembly from the stove shell, support the firebox with solid stands about 6" (150mm) tall under the left and right outer edges of the firebox base. Do not set the firebox assembly directly on the floor; this can damage the control valve and/or the gas lines from the valve to the firebox.

Before removing the firebox from the shell, disconnect the on/off switch wires from the valve. If the assembly includes the optional fan, disconnect the fan rheostat. If the installation includes a wall thermostat, disconnect the thermostat leads from valve.

Disconnection and reconnection to the gas line should only be done by a qualified gas service technician.

Upon reinstallation, the vent system must be sealed to the firebox as shown in the installation section, Page 14. Also be sure the logs are placed in the firebox correctly, as shown on Page 20.



Fig. 64 Draft Hood Adapter wiring.



Fig. 65 Jefferson fan circuit.



Vermont Castings, Majestic Products reserves the right to make changes in design, materials, specifications, prices and discontinue colors and products at any time, without notice.

Jefferson Direct Vent/Natural Vent Gas Heater Models 2820, 2822, 2823, 2825, 2827, 2828

Ref.	Description	JDV
1.	Gas Log Set - JDV	20002182
1a.	Log, Back - JDV	20002183
1b.	Log, Left Upper - JDV	20002187
1c.	Log, Right Upper - JDV	20002186
1d.	Log, Left - JDV	20002185
1e.	Log, Right - JDV	20002184
2.	Grille, JDV	30000685
3.	Screen, Grille - JDV	30000665
4.	Furnace Cement	1206122
5.	Manifold Assembly	20003739
6.	Lava Rocks Burner	57897

Jefferson Direct Vent/Natural Vent Gas Heater (continued)

Models 2820, 2822, 2823, 2825, 2827, 2828

Ref.	Description	JDV
7.	Gasket, Glass - Med. Knit - RDV40	1203702
8.	Glass, JDV	20002120
9.	Glass Frame Assembly - JDV	20002117
10a.	Valve RN Honeywell VS8420E 2038	10001782
10b.	Valve RP Honeywell VS8420E 2020	10001759
11a.	Pilot Assembly 3Way N/DV RN 0.199.706	10002264
	Pilot Assembly 3Way N/DV RP 0.199.703	10002265
11b.	Pilot, PSE - NA175	20001115
	Pilot, PSE - LP1/5	20001116
12.	Thermocouple 24"	53373
10	Flastrada Ignitar w/ apple SIT24	10001207
13.	Dilet Tep Convertible	10001297
14.	Thermonile 10" PS	
15.		7533113
16	Nut Electrode SIT #0 974 144	57886
17.	Tubing Pilot w/Fittings 1/8 x 24"	10001296
18.	Burner Housing Assembly NG/LP	20002214
19.	Grate, Burner - JDV	20002167
20.	Wiring Harness - FSDV32RN/JDV	10002582
21.	Switch ON/OFF - RN/RP Models	30000874
22.	Front, JDV	Refer to Enamel Parts Chart Page 34
23.	Door, Control - JDV	30000686
24a.	Orifice Hood - #69 - Front - LP	30000513
24b.	Orifice Hood - #54 - Front - NG	20000130
24c.	Orifice Hood - #54 - Rear - LP	20000130
24d.	Orifice Hood - #44 - Rear - NG	30000334
25.	Bracket, Right Log - JDV	20002166
26.	Bracket, Left Log - JDV	20002165
27.	Front Handle Assembly - JDV/Parts	5004240
28.	Handle, Damper - Maplewood - BLK	1600664
29.	Gasket, Base Pan - JDV	20002282
30.	Gasket, Base Pan Inner	20002566
31.	Sensor 2450 CMG-8184-0032	10002013

Fuel Conversion Kits:

Conversion Kit, NG to LP - JDV/SDV30R Kit #000-5022 Conversion Kit, LP to NG - JDV/SDV30R Kit #000-5021

Shell Enamel Part Numbers							
Model Color		Тор	Left	Right	Front		
Number		-	End	End			
2820, 2825	Classic	30000680	30000682	30000681	30000683		
2822, 2827	Midnight	30000717	30000720	30000719	30000721		
2823, 2828	Green	30000753	30000726	30000725	30000727		

Optional Accessories

Fan Kits

FK28 Fan

The FK28 fan helps distribute heated air from within the firebox out into the room. The fan is controlled by a snapstat that turns power on and off as the firebox temperature rises above and falls below a preset temperature. A rheostat provides for variable fan speeds.

Specifications

115 Volt / 60Hz / .75 Amps

Maintenance

The fan itself does not require regular maintenance, however, periodic cleaning of the fan and the surrounding area is required.

Installation

Refer to Page 13 for installation instructions.

Remote Controls

The remote control allows you to turn the heater on or off from anywhere in the room. Refer to Page 40 for wiring diagrams.

Model	Functions Controlled
MRC1	ON/OFF
MRC2	ON/OFF and Temperature
MRC3	ON/OFF and Temperature control
	with a digital display and a
	programmable 24 hour clock
IMT	Wall mounted thermostat control

Decorative Rings

7" brass or charcoal gray rings are available to add a decorative touch to the exposed stove pipe.

Model	Description
7FSDRG/4	7" Charcoal Gray Rings (4)
7FSDRP/4	7" Polished Brass Rings (4)

LIMITED LIFETIME WARRANTY

PRODUCT COVERED BY THIS WARRANTY

All Vermont Castings gas stoves, gas inserts, and gas fireplaces, and all Majestic or Northern Flame brand gas fireplaces equipped with an Insta-Flame Ceramic Burner, or standard steel tube burner.

BASIC WARRANTY

The Vermont Castings, Majestic Products Company (hereinafter referred to collectively as the Company) warrants that your new Vermont Castings or Majestic Gas Fireplace/Stove is free from manufacturing and material defects for a period of one year from the date of purchase, subject to the following conditions and limitations.

EXTENDED LIFETIME WARRANTY

The heat exchanger, where applicable, and combustion chamber of every Vermont Castings *or* Majestic gas product is warranted for life against through wall perforation. All appliances equipped with an Insta-Flame Ceramic Burner have limited lifetime coverage on the ceramic burner plaque. Warrantees are made to the original owner subject to proof of purchase and the conditions and limitations listed on this Warranty Document

COMPONENT WARRANTY

CAST IRON: All external and internal cast iron parts are warranted for a period of three years.

Note: On porcelain enamel finished external parts and accessories The Company offers no Warranty on chipping of enamel surfaces. Inspect all product prior to accepting it for any damage to the enamel.

The salt air environment of coastal areas or a high humidity environment can be corrosive to the porcelain enamel finish. These conditions can cause rusting of the cast iron beneath the porcelain enamel finish, which will cause the finish to flake off.

Dye lot variations with replacement parts and/or accessories can occur and are not covered by warranty.

GLASS DOORS: Glass doors are covered for a period of one year. Glass doors are not warranted for breakage due to misuse or accident. Glass doors are not covered for discoloration or burned in stains due to environmental issues, or improper cleaning and maintenance.

BRASS PLATED PARTS AND ACCESSORIES: Brass parts should be cleaned with Lemon oil only. Brass cleaners cannot be used. Mortar mix and masonry cleaners may corrode the brass finish. The Company will not be responsible for, nor will it warrant any brass parts which are damaged by external chemicals or down draft conditions.

GAS VALVES: Gas valves are covered for a period of one year

ELECTRONIC AND MECHANICAL COMPONENTS: Electronic and mechanical components of the burner assembly are covered for one year. All steel tube burners are warranted for one year.

ACCESSORIES: Unless otherwise noted all components and Vermont Castings, Majestic Products company supplied accessories are covered for a period of one year.

CONDITIONS AND LIMITATIONS

- This new Vermont Castings or Majestic product must be installed by a competent, authorized, service contractor. A licensed technician, as prescribed by the local jurisdiction must perform any installation/ service work. It must be installed and operated at all times in accordance with the Installation and Operating instructions furnished with the product. Any alteration, willful abuse, accident, or misuse of the product shall nullify this warranty.
- This warranty is non-transferable, and is made to the original owner, provided that the purchase was made through an authorized supplier of the Company.
- The customer must pay for any Authorized Dealer in-home travel fees or service charges for in-home repair work. It is the dealers option whether the repair work will be done in the customer's home or in the dealer's shop.
- If upon inspection, the damage is found to be the fault of the manufacturer, repairs will be authorized at no charge to the customer parts and/or labor.

- Any part and/or component replaced under the provisions of this warranty is covered for six months or the remainder of the original warranty, whichever is longest.
- This warranty is limited to the repair of or replacement of part(s) found to be defective in material or workmanship, provided that such part(s) have been subjected to normal conditions of use and service, after said defect is confirmed by the Company's inspection.
- The company may, at its discretion, fully discharge all obligations with respect to this warranty by refunding the wholesale price of the defective part(s)
- Any installation, labor, construction, transportation, or other related costs/expenses arising from defective part(s), repair, replacement, or otherwise of same, will not be covered by this warranty, nor shall the Company assume responsibility for same. Further, the Company will not be responsible for any incidental, indirect, or consequential damages except as provided by law.
- SOME STATES DO NOT ALLOW FOR THE EXCLUSION OR LIMITATIONS OF INCIDENTAL AND CONSEQUENTIAL DAMAGES OR LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOUR CIRCUMSTANCES. THIS WARRANTY GIVES YOU SPECIFIC RIGHTS AND YOU MAY HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.
- All other warranties-expressed or implied- with respect to the product, its components and accessories, or any obligations/liabilities on the part of the Company are hereby expressly excluded.
- The Company neither assumes, nor authorizes any third party to assume on its behalf, any other liabilities with respect to the sale of this Vermont Castings, Majestic product
- The warranties as outlined within this document do not apply to chimney components or other non Vermont Castings, Majestic accessories used in conjunction with the installation of this product.
- Damage to the unit while in transit is not covered by this warranty but is subject to claim against the common carrier. Contact the dealer from whom you purchased your fireplace/stove (do not operate the appliance as this might negate the ability to process the claim with the carrier).
- The Company will not be responsible for:
 - a) Down drafts or spillage caused by environmental conditions such as near-by trees, buildings, roof tops, hills, or mountains.
 - b) Inadequate ventilation or negative air pressure caused by mechanical systems such as furnaces, fans, clothes dryers, etc.
- This warranty is void if:
 - a) The fireplace has been operated in atmospheres contaminated by chlorine, fluorine, or other damaging chemicals.
 - b) The fireplace has been subjected to prolonged periods of dampness or condensation
 - c) Any damages to the fireplace, combustion chamber, heat exchanger or other components due to water, or weather damage, which is the result of but not limited to, improper chimney/venting installation.
 - d) Any alteration, willful abuse, accident, or misuse of the product has occurred.

IF WARRANTY SERVICE IS NEEDED...

- Contact your supplier. Make sure you have your warranty, your sales receipt, and the model/serial number of your Vermont Castings, Majestic product.
- 2) DO NOT ATTEMPT TO DO ANY SERVICE WORK YOURSELF.