If you have questions or comments, contact us. Pour toute question ou tout commentaire, nous contacter. Si tiene dudas o comentarios, contáctenos.

1-877-FNA-GAS1 (1-877-362-4271)•www.dewaltpw.com

INSTRUCTION MANUAL GUIDE D'UTILISATION MANUAL DE INSTRUCCIONES

INSTRUCTIVO DE OPERACIÓN, CENTROS DE SERVICIO Y PÓLIZA DE GARANTÍA. **ADVERTENCIA:** LÉASE ESTE INSTRUCTIVO ANTES DE USAR EL PRODUCTO.



DXPW····· Pressure Washer Laveuse à pression Lavadora a presión

### DXPW·····PRE6SURE WASHER

J. Engine

N. Gas cap

R. Top handle

L. Choke control

M. Fuel valve lever

O. Handle assembly

P. High-pressure hose

Κ

Μ

- A. Panel assembly
- B. Nozzle holder
- C. Professional Spray gun
- D. Wheel
- E. Quick-connect spray wand
- F. Frame
- G. Engine dipstick/oil plug
- H. Engine switch
- I. Starter grip


### Engine

Refer to the engine instruction manual for location and operation of other engine controls.

### Pump

For best results, pump oil designed specifically for pressure washers is recommended, as these contain a rust inhibitor and an anti-foaming agent. If this oil is not available, an SAE 30W non-detergent oil may be used.

FIG. 1



#### **Specifications**

(1-877-362-4271)

MODEL WEIGHT HEIGHT WIDTH LENGTH **PSI\*\*** ENGINE GPM\*\* 22" 21" 34" **DXPW("("%** 90 lbs 3200 2,8 HONDA GX200\*\*\* (40.8 kg) (22063 kPa) (10.6 L/min)) 196 cc (55.9 cm) (53.3 cm) (86.4 cm) \*\* PSI and GPM ratings Pressure Washers Manufacturers determined in accordance with the Association (PWMA) standard PW101.

\*\*\* HONDA™ is a registered trademarks of the HONDA MOTOR CO., LTD used under license from AMERICAN HONDA MOTOR CO. INC.

### **Definitions: Safety Guidelines**

The definitions below describe the level of severity for each signal word. Please read the manual and pay attention to these symbols.

**ADANGER:** Indicates an imminently hazardous situation which, if not avoided, **will** result in **death or serious injury**.

**AWARNING:** Indicates a potentially hazardous situation which, if not avoided, **could** result in **death or serious injury**.

**ACAUTION**: Indicates a potentially hazardous situation which, if not avoided, **may** result in **minor or moderate injury**. **NOTICE:** Indicates a practice **not related to personal injury** which, if not avoided, **may** result in **property damage**.

IF YOU HAVE ANY QUESTIONS OR COMMENTS ABOUT THIS CONTACT US AT: www.dewaltpw.com or 1-877-FNA-GAS1

### Important Safety Instructions

**ADANGER:** Carbon Monoxide. Using an engine indoors can kill you in minutes. Engine exhaust contains high levels of carbon monoxide (CO), a poisonous gas you cannot see or smell. You may be breathing CO even if you do not smell engine exhaust. **AWARNING:** This product and its exhaust contain chemicals known to the State of California to cause cancer, and birth defects and other reproductive harm.

- **NEVER** use an engine inside homes, garages, crawlspaces or other partly enclosed areas. Deadly levels of carbon monoxide can build up in these areas. Using a fan or opening windows and doors does **NOT** supply enough fresh air.
- **ONLY** use outdoors and far away from open windows, doors and vents. These openings can pull in engine exhaust.
- Even when the engine is used correctly, CO may leak into your home. ALWAYS use a battery-powered or battery backup CO alarm in your house. Read and follow all directions for CO alarm before using. If you feel sick, dizzy or weak at anytime, move to fresh air immediately. See a doctor. You could have carbon monoxide poisoning.

**AWARNING:** Do not operate this unit until you read this instruction manual and the engine instruction manual for safety, operation and maintenance instructions.

**AWARNING:** When using this product basic precautions should always be followed, including the following:

- 1. Read all instructions before using the product.
- 2. To reduce the risk of injury, close supervision is necessary when a product is used near children.
- 3. Know how to stop the product and bleed pressures quickly. Be thoroughly familiar with the controls.
- 4. Stay alert-watch what you are doing.
- 5. Do not operate the product when fatigued or under the influence of alcohol or drugs.
- 6. Keep operating area clear of all persons.
- 7. Do not overreach or stand on unstable support. Keep good footing and balance at all times.
- 8. Follow the maintenance instructions specified in the manual.

#### ADANGER: RISK OF INJECTION OR SEVERE INJURY. KEEP CLEAR OF NOZZLE. DO NOT DIRECT DISCHARGE STREAM AT PERSONS. THIS PRODUCT IS TO BE USED ONLY BY TRAINED OPERATORS.

**AWARNING:** This product may not be equipped with a sparkarresting muffler. If the product is not equipped and will be used around flammable materials or on land covered with materials such as agricultural crops, forest, brush, grass or other similar items, then an approved spark arrester must be installed and is legally required in the state of California. It is a violation of California statutes section 130050 and/or sections 4442 and 4443 of the California Public Resources Code, unless the engine is equipped with a spark arrester, as defined in section 4442, and maintained in effective working order. Spark arresters are also required on some U.S. Forest Service land and may also be legally required under other statutes and ordinances.

**AWARNING:** This product and its exhaust contain chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm. In addition, some cleaning products and dust contain chemicals known to the State of California to cause cancer, and birth defects or other reproductive harm. Wash hands after handling.

### SAVE THESE INSTRUCTIONS



#### ADANGER: RISK OF EXPLOSION OR FIRE WHAT CAN HAPPEN HOW TO PREVEN

- Spilled gasoline and it's vapors can become ignited from cigarette sparks, electrical arcing, exhaust gases and hot engine components such as the muffler.
- Heat will expand fuel in the tank which could result in spillage and possible fire explosion.

 HOW TO PREVENT IT
 Shut off engine and allow it to cool before adding fuel

- to the tank.
  Use care in filling tank to avoid spilling fuel. Move pressure washer away from fueling area before starting engine.
- Keep maximum fuel level 1/2" (12.7 mm) below bottom of filler neck to allow for expansion.

- Operating the pressure washer in an explosive environment could result in a fire.
- Materials placed against or near the pressure washer can interfere with its proper ventilation features causing overheating and possible ignition of the materials.
- Muffler exhaust heat can damage painted surfaces, melt any material sensitive to heat (such as siding, plastic, rubber, vinyl or the pressure hose, itself), and damage live plants.
- Improperly stored fuel could lead to accidental ignition.
   Fuel improperly secured could get into the hands of children or other unqualified persons.

- Operate and fuel equipment in well-ventilated areas free from obstructions. Equip areas with fire extinguisher suitable for gasoline fires.
- Never operate pressure washer in an area containing dry brush or weeds.
- Always keep pressure washer a minimum of 4' (1.2 m) away from surfaces (such as houses, automobiles or live plants) that could be damaged from muffler exhaust heat.
- Store fuel in an OSHA approved container, in a secure location away from work area.

- Use of acids, toxic or corrosive chemicals, poisons, insecticides, or any kind of flammable solvent with this product could result in serious injury or death.
- Do not spray flammable liquids.



#### ADANGER: RISK TO BREATHING (ASPHYXIATION) WHAT CAN HAPPEN HOW TO PREVENT IT

- Breathing exhaust fumes will cause serious injury or death! Engine exhaust contains carbon monoxide, an odorless and deadly gas.
- Some cleaning fluids contain substances which could cause injury to skin, eyes or lungs.

- Operate pressure washer in a well-ventilated area. Avoid enclosed areas such as garages, basements, etc.
- Never operate unit in or near a location occupied by humans or animals.
- Use only cleaning fluids specifically recommended for high-pressure washers.
   Follow manufacturers recommendations. Do not use chlorine bleach or any other corrosive compound.



#### ADANGER: RISK OF FLUID INJECTION AND LACERATION WHAT CAN HAPPEN HOW TO PREVENT IT

- Your pressure washer operates at fluid pressures and velocities high enough to penetrate human and animal flesh, which could result in amputation or other serious injury. Leaks caused by loose fittings or worn or damaged hoses can result in injection injuries. DO NOT TREAT FLUID INJECTION AS A SIMPLE CUT! See a physician immediately!
- Inspect the high-pressure hose regularly. Replace the hose immediately if it is damaged, worn, has melted from contacting the engine, or shows any signs of cracks, bubbles, pinholes, or other leakage. Never grasp a high-pressure hose that is leaking or damaged.
- Never touch, grasp or attempt to cover a pinhole or similar water leak on the high-pressure hose. The stream of water IS under high pressure and WILL penetrate skin.
- Never place hands in front of nozzle.
- Direct spray away from self and others.
- Make sure hose and fittings are tightened and in good condition. Never hold onto the hose or fittings during operation.

 Injuries can result if system pressure is not reduced before attempting maintenance or disassembly.

- Do not allow hose to contact muffler.
- Never attach or remove wand or hose fittings while system is pressurized.
- When using replacement lances or guns with this pressure washer, DO NOT use a lance and/or lance/ gun combination that is shorter in length than what was provided with this pressure washer as measured from the nozzle end of the lance to the gun trigger.
- To relieve system pressure, shut off engine, turn off water supply and pull gun trigger until water stops flowing.
- Use only accessories rated equal to or higher than the rating of the pressure washer.



### ADANGER: RISK OF INJURY FROM SPRAY

#### WHAT CAN HAPPEN

- High-velocity fluid spray can cause objects to break, propelling particles at high speed.
- Light or unsecured objects can become hazardous projectiles.

### HOW TO PREVENT IT

- Always wear ANSI-approved Z87.1 safety glasses. Wear protective clothing to protect against accidental spraying.
- Never point wand at or spray people or animals.
- Always secure trigger lock when wand is not in service to prevent accidental operation.
- Never permanently secure trigger in pull-back (open) position.

# ADANGER: RISK OF UNSAFE OPERATION

- WHAT CAN HAPPEN
- Unsafe operation of your pressure washer could lead to serious injury or death to you or others.

### HOW TO PREVENT IT

- Do not use chlorine bleach or any other corrosive compound.
- Become familiar with the operation and controls of the pressure washer.
- Keep operating area clear of all persons, pets and obstacles.
- Do not operate the product when fatigued or under the influence of alcohol or drugs. Stay alert at all times.
- Never defeat the safety features of this product.
- Do not operate machine with missing, broken or unauthorized parts.
- Never leave wand unattended while unit is running.

 The spray gun/wand is a powerful cleaning tool that could look like a toy to a child.

If proper starting procedure

kickback causing serious

hand and arm injury.

is not followed, engine can

 Reactive force of spray will cause gun/wand to kickback, and could cause the operator to slip or fall or misdirect the spray. Improper control of gun/ wand can result in injuries to self and others.

- If engine does not start after two pulls, squeeze trigger of gun to relieve pump pressure. Pull starter cord slowly until resistance is felt. Then pull cord rapidly to avoid kickback and prevent hand or arm injury.
- Keep children away from the pressure washer at all times.
- Do not overreach or stand on an unstable support.
- Do not use pressure washer while standing on a ladder.
- Grip gun/wand firmly with both hands. Expect the gun to kickback when triggered.

#### ADANGER: RISK OF INJURY OR PROPERTY DAMAGE WHEN TRANSPORTING OR STORING

#### WHAT CAN HAPPEN

- Fuel or oil can leak or spill and could result in fire or breathing hazard. Serious injury or death can result. Fuel or oil leaks will damage carpet, paint or other surfaces in vehicles or trailers.
- Oil could fill the cylinder and damage the engine if the unit is not stored or transported in an upright position.

#### HOW TO PREVENT IT

- If pressure washer is equipped with a fuel shutoff valve, turn the valve to the OFF position before transporting to avoid fuel leaks. If pressure washer is not equipped with a fuel shutoff valve, drain the fuel from tank before transporting. Only transport fuel in an OSHAapproved container. Always place pressure washer on a protective mat when transporting to protect against damage to vehicle from leaks. Alwavs transport and store
  - unit in an upright position. Remove pressure washer from vehicle immediately upon arrival at your destination.



#### WHAT CAN HAPPEN

#### HOW TO PREVENT IT

- Over inflation of tires could result in serious injury and property damage.
- Use a tire pressure gauge to check the tires pressure before each use and while inflating tires: see the tire sidewall for the correct tire pressure.

**NOTE:** Air tanks. compressors and similar equipment used to inflate tires can fill small tires similar to these very rapidly. Adjust pressure regulator on air supply to no more than the rating of the tire pressure. Add air in small increments and frequently use the tire gauge to prevent over inflation.

- High-velocity fluid sprav directed at pneumatic tire sidewalls (such as found on automobiles, trailers and the like) could damage the sidewall resulting in serious injury.
- On pressure washers rated above 1600 psi (11032 kPa) use the widest fan sprav (40° nozzle) and keep the spray a minimum of 8" (20 cm) from the pneumatic tire sidewall. Do not aim spray directly at the joint between the tire and rim.



#### **AWARNING: RISK OF HOT SURFACES** WHAT CAN HAPPEN

 Contact with hot surfaces, such as engines exhaust components, could result in serious burn.

#### HOW TO PREVENT IT

• During operation, touch only the control surfaces of the pressure washer. Keep children away from the pressure washer at all times. They may not be able to recognize the hazards of this product.



#### AWARNING: RISK OF CHEMICAL BURN WHAT CAN HAPPEN HOW TO PREVENT IT

- Use of acids, toxic or corrosive chemicals, poisons, insecticides, or any kind of flammable solvent with this product could result in serious injury or death.
- Do not spray acids, gasoline, kerosene, or any other flammable materials with this product. Use only household detergents, cleaners and degreasers recommended for use with pressure washers.
- Wear protective clothing to protect eyes and skin from contact with sprayed materials.



AWARNING: RISK OF ELECTRICAL SHOCK WHAT CAN HAPPEN HOW TO PREVENT IT

- Spray directed at electrical outlets or switches, or objects connected to an electrical circuit, could result in a fatal electrical shock.
- Unplug any electrically operated product before attempting to clean it. Direct spray away from electric outlets and switches.



#### **AWARNING: RISK OF INJURY FROM LIFTING**

#### WHAT CAN HAPPEN

 Serious injury can result from attempting to lift too heavy an object.

#### HOW TO PREVENT IT

 The pressure washer is too heavy to be lifted by one person. Obtain assistance from others before lifting.

### SAVE THESE INSTRUCTIONS FOR FUTURE USE


### INSTALLATION

### Pressure Washer Assembly (Fig. 1)


1. Slide the handle assembly (O) onto the frame (F). **ACAUTION:** Risk of personal injury. Avoid placing hands between handle and frame when assembling to prevent pinching.



- 2. Align holes in the top handle (R) with the mounting holes in the handle assembly (O).
- Insert saddle bolts (DD) through aligned holes and secure top handle to handle assembly with knobs (EE). Tighten until snug.



4. Attach high-pressure hose (P) to spray gun. Make sure it is secure.5. Connect wand (E) to spray gun. Make sure connection is secure.



- 6. Place the nozzle holder (B) onto the panel assembly (A) and push each nozzle holder into place.
- 7. Remove the five colored quickconnect nozzles from the plastic bag and insert them into correct grommet on



the nozzle holder. Nozzles are color coded to match colored nozzles on panel assembly. **NOTE:** The high-pressure pump was filled with oil at the factory. Always check oil level before using (refer to *Maintenance* for more information).

**AWARNING:** Risk of bursting. Use a tire pressure gauge to check the tires pressure before each use and while inflating tires; see the tire sidewall for the correct tire pressure.

**NOTE:** Air tanks, compressors and similar equipment used to inflate tires can fill small tires similar to these very rapidly. Adjust pressure regulator on air supply to no more than the rating of the tire pressure. Add air in small increments and frequently use the tire gauge to prevent over inflation.

### OPERATION

### **Pressure Adjustments**

The pressure setting is preset at the factory to achieve optimum pressure and cleaning. To lower the pressure, follow these instructions.

- 1. Back away from the surface to be cleaned. The further away you are, the less the pressure will be on the surface to be cleaned.
- 2. Change to the 40° nozzle (white). This nozzle delivers a less powerful stream of water and a wider spray pattern. Refer to **Spray Wand Nozzles**.

**NOTICE:** DO NOT attempt to increase pump pressure. A higher pressure setting than the factory set pressure may damage pump.

3. Reduce the speed of the gasoline engine (RPM). Slow the engine down and the water pressure will go down with it.

### Spray Wand Nozzles (Fig. 1)

The nozzles for the spray wand are stored in the nozzle holder (B) on the panel assembly (A). Colors on the panel identify nozzle location and spray pattern. Refer to the following chart to choose the correct nozzle for the job to be performed.

| Nozzle Color   | Spray Pattern | Uses  | Surfaces*                                      |
|--|---------------|---|--|
| Red  | 0°            | powerful<br>pinpoint for very<br>intense cleaning | metal or<br>concrete;<br>DO NOT use on<br>wood |
| Yellow   | 15°           | intense cleaning<br>of small areas                | metal, concrete<br>or wood                     |
| Green  | 25°           | intense cleaning<br>of larger areas               | metal, concrete<br>or wood                     |
| White  | 40°           | covers wide<br>areas of<br>cleaning               | metal, concrete,<br>wood or vinyl              |
| Black  | low pressure  | applies cleaning<br>solutions                     | metal, concrete,<br>wood or vinyl              |
| * <b>NOTICE:</b> The high-pressure spray from your pressure washer<br>is capable of causing damage to surfaces such as wood, glass,<br>automobile paint, auto striping and trim, delicate objects such<br>as flowers and shrubs. Before spraying, check the item to<br>be cleaned to assure yourself that it is strong enough to resist<br>damage from the force of spray. |               |   |  |

#### CHANGING NOZZLES ON SPRAY WAND

**ADANGER:** Risk of fluid injection. Do not direct discharge stream toward persons, unprotected skin, eyes or any pets or animals. Serious injury will occur.

**AWARNING:** Flying objects could cause risk of serious injury. DO NOT attempt to change nozzles while pressure washer is running. Turn engine off before changing nozzles.

- 1. Pull quick-connect coupler back and insert nozzle.
- 2. Release quick-connect coupler and twist nozzle to make sure it is secure in coupler.

**AWARNING:** Flying object could cause risk of serious injury. Ensure nozzle is completely inserted in quick-connect socket and quickconnect snap ring is fully engaged (forward) before squeezing gun trigger.




### **Chemicals and Cleaning Solvents**

Applying chemicals or cleaning solvents is a low-pressure operation. **NOTE:** Use only soaps and chemicals designed for pressure washer use. **Do not use bleach.** 

### TO APPLY CHEMICALS AND SOLVENTS

- 1. Press chemical hose (S) onto barbed fitting located near high pressure hose connection of pump as shown.
- 2. Place the other end of chemical hose with filter on it into the container holding chemical/ cleaning solution.

**NOTE:** For every 10 gallons (38 liters) of water pumped 1 gallon (3.8 liters) of chemical/ cleaning solution will be used.



- Install low-pressure (black) nozzle into quick connect fitting of spray wand, refer to Spray Wand Nozzles. NOTE: Chemicals and soaps will not siphon if the black soap nozzle is not installed on the spray wand.
- 4. After use of chemicals, place chemical hose into container of clean water and draw clean water through chemical injection system to rinse system thoroughly. If chemicals remain in the pump it could be damaged. Pumps damaged due to chemicals will not be covered under warranty.

### Starting

**AWARNING:** To reduce the risk of injury, read the pressure washer instruction manual and the engine instruction manual before starting pressure washer.

**ADANGER:** Risk of fluid injection and laceration. When using the high-pressure setting, DO NOT allow the high-pressure spray to come in contact with unprotected skin, eyes, or with any pets or animals. Serious injury will occur.

 Your washer operates at fluid pressures and velocities high enough to penetrate human and animal flesh, which could result in amputation or other serious injury. Leaks caused by loose fittings or worn or damaged hoses can result in injection injuries. DO NOT TREAT FLUID INJECTION AS A SIMPLE CUT! See a physician immediately!

**ADANGER:** Carbon Monoxide. Using an engine indoors can kill you in minutes. Engine exhaust contains high levels of carbon monoxide (CO), a poisonous gas you cannot see or smell. You may be breathing CO even if you do not smell engine exhaust.

 Breathing exhaust fumes will cause serious injury or death! Engine exhaust contains carbon monoxide, an odorless and deadly gas.

- Operate pressure washer in a well-ventilated area. Avoid enclosed areas such as garages, basements, etc.
- Never operate unit in or near a location occupied by humans or animals.

**AWARNING:** Risk of fire, asphyxiation and burning. Never fill fuel tank when engine is running or hot. Do not smoke when filling fuel tank.

- NEVER fill fuel tank completely. Fill tank to 1/2" (12.7 mm) below bottom of filler neck to provide space for fuel expansion. Wipe any fuel spillage from engine and equipment before starting engine.
- DO NOT let hoses come in contact with very hot engine muffler during or immediately after use of your pressure washer. Damage to hoses from contact with hot engine surfaces will NOT be covered by warranty.

**NOTICE:** NEVER pull water supply hose to move pressure washer. This could damage hose and/or pump inlet.

- DO NOT use hot water, use cold water only.
- NEVER turn water supply off while pressure washer engine is running or damage to pump will result.
- DO NOT stop spraying water for more than two minutes at a time. Pump operates in bypass mode when spray gun trigger is not pressed. When the temperature inside the pump rises too high the thermal relief valve (T) will open and release a gush of water in an effort to lower the temperature inside the pump. The thermal



relief valve will then close. If pump is left in bypass mode for more than two minutes internal components of the pump can be damaged.

#### START-UP PROCEDURE

- 1. In a well-ventilated outdoor area, add fresh, high-quality, unleaded gasoline with a pump octane rating of 86 or higher. Do not overfill. Wipe up spilled fuel before starting the engine. Refer to engine instruction manual for correct procedure.
- 2. Check engine oil level. Refer to the engine instruction manual for correct procedure.
- 3. Connect the water hose to the water source. Turn the water source on to remove all air from the hose. When a steady stream of water is present, turn the water source off.
- 4. Verify the filter screen (U) is in water inlet of pump. The cone side faces out.
- 5. Connect the cold water source (V) to pump inlet. **NOTE:** Water source must provide a minimum of 5 gallons per minute at 20 psi (138 kPa).




**AWARNING:** To reduce the possibility of contamination always protect against backflow when

connected to a potable water system.

- 6. Connect high-pressure hose (P) to pump outlet.
- 7. If applying a chemical or cleaning solution, refer to Chemicals and Cleaning Solvents.
- 8. Turn the water source on.

NOTICE: Risk of property damage. Failure to do so could cause damage to the pump.

- 9. Remove all air from the pump and high pressure hose by depressing trigger until a steady stream of water is present.
- 10. Turn the engine ON/OFF switch (H) to the ON position.
- 11. Place the fuel valve lever (M) in the ON position.
- 12. If the engine is cold, move the choke (L) to the CLOSED position as shown.



13. **AWARNING:** Risk of unsafe operation. Pull starter grip slowly until resistance is felt. Then pull starter grip (I) rapidly to avoid kickback and prevent hand or arm injury.

**NOTE:** Do not allow the starter grip to snap back. Return it gently by hand.

**AWARNING:** Risk of unsafe operation. If engine does not start after two pulls, squeeze trigger of gun to relieve pump pressure. Pull starter cord slowly until resistance is felt. Then pull cord rapidly to avoid kickback and prevent hand or arm injury.

NOTE: If the oil level in the engine is low, the engine will not start. If the engine does not start, check the oil level and add oil as needed.

- 14. As the engine warms up, move the choke to the OPEN position.
- 15. Depress trigger on gun to start water flow. **AWARNING:** Risk of unsafe operation. Stand on a stable surface and grip gun/wand firmly with both hands. Expect the gun to kickback when triaaered.



16. Release trigger to stop water flow.

ADANGER: Risk of injury from spray. Engage the trigger lock (X) when gun is not in use to prevent accidental spraying.





17. Adjust spray for the task being performed by changing quick connect nozzle. Refer to Spray Wand Nozzles.

### Shutting Down

1. If chemicals were applied, place the chemical hose into a container of clean water and draw clean water through chemical injection system to rinse system thoroughly.

NOTICE: Risk of property damage Failure to do so could cause damage to the pump.

- 2. Place the engine ON/OFF switch (H) to the OFF Position.
- 3. Place the fuel valve lever (M) in the OFF position.

**NOTICE:** Risk of property damage. NEVER turn water supply off while pressure washer engine is running or damage to pump will result.

- 4. Turn water source off.
- 5. Pull trigger on spray gun to relieve any water pressure in hose or spray gun.
- 6. Refer to **Storage** for proper storage procedures.

### MAINTENANCE

**AWARNING:** Risk of burning. When performing maintenance, you may be exposed to hot surfaces, water pressure or moving parts that can cause serious injury or death.

**AWARNING:** Risk of fire. Always disconnect, spark plug wire, let the engine cool and release all water pressure before performing any maintenance or repair. The engine contains flammable fuel. Do not smoke or work near open flames while performing maintenance.

To ensure efficient operation and longer life of your pressure washer, a routine maintenance schedule should be prepared and followed. If the pressure washer is used in unusual conditions, such as high temperatures or dusty conditions, more frequent maintenance checks will be required.

### Engine

Consult the engine instruction manual for the manufacturer's recommendations for any and all maintenance.

**NOTE:** The pressure washer frame is equipped with an oil drain hole to help make changing the engine oil easier.

### Pump


**NOTE:** The pump was filled with oil at the factory. Change pump oil after the first 50 hours of operation and every 300 hours thereafter, or every 3 months. If using a 30W non-detergent oil, change oil every 150 hours thereafter.

### TO CHECK OIL

The oil level should come to the dot in the middle of the sight glass (AA).

### HOW TO CHANGE PUMP OIL


- 1. Loosen pump oil fill plug (BB).
- 2. Place a container under the oil drain plug (CC).
- 3. Remove pump oil drain plug.
- 4. After oil is drained, replace oil drain plug. Tighten securely.
- 5. Remove pump oil plug and fill with pump oil. An oil designed specifically for pressure washers is recommended as these contain a rust inhibitor and an anit-foaming agent. If this oil is not available, an SAE 30W non-detergent oil may be used.
- 6. Replace pump oil plug and tighten securely.



### **Nozzle Cleaning**

If the nozzle becomes clogged with foreign materials, such as dirt, excessive pressure may develop. If the nozzle becomes partially clogged or restricted, the pump pressure will pulsate. Clean the nozzle immediately using the nozzle kit supplied and the following instructions:

- 1. Shut off the pressure washer and turn off the water supply.
- 2. Pull trigger on gun handle to relieve any water pressure.
- 3. Disconnect the spray wand from the gun.
- Remove the high-pressure nozzle from the spray wand. Remove any obstructions with the nozzle cleaning tool (Y) provided and back flush with clean water.



- 5. Direct water supply into spray wand to back flush loosened particles for 30 seconds.
- 6. Reassemble the nozzle to the wand.
- 7. Reconnect spray wand to gun then turn on water supply.
- 8. Start pressure washer and place spray wand into high pressure setting to test.

### To Clean the Water Inlet Filter

This filter screen (U) should be checked periodically and cleaned if necessary.

- 1. Remove the filter screen (U) by grasping the end and removing it from water inlet of pump.
- 2. Clean filter by flushing it with water on both sides.
- 3. Reinsert filter into water inlet of pump. Cone side faces out.



**NOTE:** Do not operate pressure washer without filter properly installed.

### STORAGE

### Engine

Consult the engine instruction manual for the manufacturer's recommendations for storage.

### Pump

The manufacturer recommends using a pump protector/ winterizer when storing the unit for more than 30 days and/or when freezing temperatures are expected. If a pump protector/ winterizer is not available, RV antifreeze can be used as outlined in the following steps.

**NOTE:** Using a pump protector/ winterizer or RV antifreeze helps to provide proper lubrication to the internal seals of the pump regardless of temperature or environment.

 Obtain a funnel, 6 oz. (170 mL) of RV antifreeze and 16–36" (40– 91cm) of garden hose with a male hose connector attached to one end.

**NOTICE:** Risk of property damage. Use only RV antifreeze. Any other antifreeze is corrosive and can damage pump.

2. Disconnect spark plug wire.



- 3. Connect length of garden hose to water inlet of pump.
- 4. Add RV antifreeze to hose as shown.
- 5. Pull engine starter rope slowly several times until antifreeze comes out of high-pressure hose connection of pump.
- 6. Remove garden hose from water inlet of pump.
- 7. Reconnect spark plug wire.

#### **Pressure Washer**

- 1. Drain all water from high-pressure hose, coil it and store it in cradle of the pressure washer handle.
- 2. With nozzle pointed down and the spray gun and wand in a vertical position, squeeze trigger to drain all water from spray gun and wand. Store in gun holder.
- 3. Store chemical hose so it is protected from damage.

**ACAUTION:** Risk of personal injury. Avoid placing hands between handle and frame when assembling to prevent pinching.

**NOTICE:** Risk of property damage. Always store and transport unit in an upright position.

### ACCESSORIES

Recommended accessories for use with your tool are available for purchase from your local dealer or authorized service center. If you need assistance in locating any accessory for your tool, please contact the FNA Group at www.dewaltpw.com, 1825 Greenleaf Avenue, Elk Grove Village, II 60007, or call (877) FNA-GAS1. **ADANGER:** Risk of fluid injection. When using replacement lances or guns with this pressure washer, DO NOT use a lance and/or lance/ gun combination that is shorter in length than what was provided with this pressure washer as measured from the nozzle end of the lance to the gun trigger.

**AWARNING:** The use of any other accessory not recommended for use with this tool could be hazardous. Use only accessories rated equal to or higher than the rating of the pressure washer.

### SERVICE INFORMATION

| Please have the following  | information | available | for all | service | calls: |
|----------------------------|-------------|-----------|---------|---------|--------|
| Model Number               | Se          | erial Nu  | mber    |         |        |
| Date and Place of Purchase | Э           |           |         |         |        |

### **Repairs**

To assure product SAFETY and RELIABILITY, repairs, maintenance and adjustment should be performed by a FNA factory service center, a FNA authorized service center or other qualified service personnel. Always use identical replacement parts.

### **Limited Warranty**

The manufacturer of this product agrees to repair or replace designated parts that prove defective within the warranty period listed below at the manufacturer's sole discretion. Specific limitations/extensions and exclusions apply.

This warranty covers defects in material and workmanship and not parts failure due to normal wear, depreciation, abuse, accidental damage, negligence, improper use, maintenance, or storage. To make a claim under the terms of the warranty, all parts said to be defective must be retained and available for return upon request to a designated Warranty Service Center for warranty inspection. The judgments and decisions of the manufacturer concerning the validity of warranty claims are final.

These warranties pass through to the end user and are nontransferable. As a factory authorized and trained Warranty Service Center, the factory will honor the terms of all component warranties and satisfy claims of the appropriate warranty provisions.

Normal wear items include, but are not limited to, valves and seals, which are not covered by this warranty.

This warranty replaces all other warranties, express or implied, including without limitation any warranties of merchantability or fitness for a particular purpose and all such warranties are hereby disclaimed and excluded by the manufacturer. The manufacturer's warranty obligation is limited to repair and replacement of defective products as provided herein and the manufacturer shall not be liable for any further loss, damages, or expenses – including damages from shipping, accident, abuse, acts of God, misuse, or neglect. Neither is damage from repairs using parts not purchased from the manufacturer or alterations performed by non-factory authorized personnel. Failure to install and operate equipment according to the guidelines put forth in the instruction manual shall void warranty.

This warranty does not cover the following: machines used for rental purposes, damage resulting from shipping (claims must be filed with freighter), accident, abuse, act of God, misuse, or neglect. Neither is damage from repairs or alterations performed by nonfactory authorized personnel or failure to install and operate equipment according to the guidelines put forth in the instruction manual.

The manufacturer will not be liable to any persons for consequential damage, for personal injury, or for commercial loss.

#### ENGINE

Covered by engine manufacturer warranty. See engine manual.

### HIGH PRESSURE PUMP (DEFECTS IN MATERIAL AND WORKMANSHIP)

Two (2) years from date of purchase.

#### WARRANTY DOES NOT APPLY TO FAILURES DUE TO:

- Freight damage
- Freeze damage
- Damage caused by parts or accessories not obtained from an authorized dealer or not approved by the manufacturer.
- Normal wear of moving parts or components affected by moving parts.

#### FRAME (DEFECTS IN MATERIAL AND WORKMANSHIP)

One (1) year from date of purchase.

## ACCESSORIES (DEFECTS IN MATERIAL AND WORKMANSHIP)

Includes nozzles, hoses, spray guns, wands Ninety (90) days from date of purchase.

### Glossary

Bypass mode: Allows water to re-circulate within pump when the gun trigger is not pulled.

Chemical hose: Feeds cleaning agents into the pump to mix with the water. Refer to Chemicals and Cleaning Solvents.

Chemical injection system: Mixes cleaners or cleaning solvents with water to improve cleaning effectiveness.

**Choke control:** Opens and closes carburetor choke valve.

**CU:** Cleaning Units. GPM multiplied by psi. (GPM x PSI = CU)

Fuel valve lever: Opens/closes connection between fuel tank and carburetor.

**GPM**: Gallons Per Minute. The unit of measure for the flow rate of water.

PSI: Pounds per Square Inch. The unit of measure for water pressure. Also used for air pressure, hydraulic pressure, etc.

kPa (kilopascal): Metric pressure measurement. 1 kilopascal equal 1000 pascals.

Quick-connect spray wand: Allows the user to quickly change out high-pressure nozzles. Refer to Spray Wand Nozzles.

**Thermal relief valve:** When the temperature inside the pump rises too high the valve will open and release a gush of water in an effort to lower the temperature inside the pump. The valve will then close.

Water supply: All pressure washers must have a source of water. The minimum requirements for a water supply are 20 psi (138 kPa) and 5 gallons per minute.

### **Troubleshooting Guide**

This section provides a list of the more frequently encountered malfunctions, their causes and corrective actions. The operator or maintenance personnel can perform some corrective actions, and others may require the assistance of a qualified FNA technician or your dealer.

| Problem   | Code                       |
|---|----------------------------|
| Engine will not start   | 1, 2, 3, 4, 5, 6, 7, 8, 36 |
| (refer to the engine's instruction manual for further engine troubleshooting) |                            |
| No or low pressure (initial use)  |                            |
| Will not draw chemicals   |                            |
| No or low pressure (after period of normal use)                               |                            |
| Water leaking at gun/spray wand connection                                    |                            |
| Water leaking at pump   |                            |
| Oil leaking at pump   |                            |
| Pump Pulsates   | 12                         |

### **Troubleshooting Codes**

| CODE | POSSIBLE CAUSE  | POSSIBLE SOLUTION                               |
|------|---|---|
| 1    | No fuel.  | Add fuel.                                       |
| 2    |   | Add required amount of oil.                     |
| 3    | Pressure builds up after two pulls on the recoil starter or after initial use.  | Squeeze gun trigger to relieve pressure.        |
| 4    | Choke lever in the NO CHOKE position.   | Move choke to the CHOKE position.               |
| 5    | Spark plug wire not attached.   | Attach spark plug wire.                         |
| 6    | Engine ON/OFF switch in OFF position.   | Place engine ON/OFF switch in ON position.      |
| 7    | Choke lever in the CHOKE position on a hot engine or an engine that has been exposed to thermal heat for a long period of time. | Move choke to the NO CHOKE position.            |
| 8    | Fuel valve CLOSED.  | Move the fuel valve lever to the OPEN position. |
| 9    | Spray wand not in high pressure.  | See Spray Wand Nozzles under Operation.         |

#### (Troubleshooting Codes cont.)

| CODE | POSSIBLE CAUSE                            | POSSIBLE SOLUTION  |
|------|---|--|
| 10   | Low water supply.                         | Water supply must be at least 5 GPM @ 20 psi (138 kPa).  |
| 11   | Leak at high-pressure hose fitting.       | Repair leak. Apply sealant tape if necessary.  |
| 12   | Nozzle obstructed.                        | See Nozzle Cleaning under Maintenance.   |
| 13   | Water filter screen clogged.              | Remove and clean filter.   |
| 14   | Air in hose.                              | Turn off the engine, then the water source. Disconnect the water source from the pump inlet and turn the water source on to remove all air from the hose. When there is a steady stream of water present, turn water source off. Reconnect water source to pump inlet and turn on water source. Squeeze trigger to remove remaining air. |
| 15   | Choke lever in the CHOKE position.        | Move choke to the NO CHOKE position.   |
| 16   | High-pressure hose is too long.           | Use high-pressure hose under 100 feet (30.48 m). Lengthen water supply hose instead of high-pressure hose.   |
| 17   | Spray wand not in low pressure.           | See Spray Wand Nozzles under Operation.  |
| 18   | Chemical filter clogged.                  | Clean filter.  |
| 19   | Chemical screen not in cleaning solution. | Make sure end of chemical hose is fully submerged into cleaning solution.  |
| 20   | Chemical too thick.                       | Dilute chemical. Chemical should be the same consistency as water.   |
| 21   | Worn seal or packing.                     | Have parts cleaned or replaced by authorized service center.   |
| 22   | Chemical build up in chemical injector.   | Have replaced by an authorized service center.   |
| 23   | Worn or obstructed valves.                | Have replaced by authorized service center.  |
| 24   | Worn unloader piston.                     | Have replaced by authorized service center.  |
| 25   | Worn or broken o-ring.                    | Check and replace.   |
| 26   | Loose hose connection.                    | Tighten.   |
| 27   | Piston packings worn.                     | Have replaced by authorized service center.  |
| 28   | Pump head or tubes damaged from freezing. | Have replaced by authorized service center.  |

#### (Troubleshooting Codes cont.)

| CODE | POSSIBLE CAUSE         | POSSIBLE SOLUTION   |
|------|------------------------|---|
| 29   | Oil seals worn.        | Have replaced by authorized service center  |
| 30   | Loose drain plug.      | Tighten.  |
| 31   | Worn drain plug o-ring | Check and replace.  |
| 32   | Worn fill plug o-ring. | Check and replace.  |
| 33   | Pump overfilled.       | Check for correct amount.   |
| 34   | Incorrect oil used.    | Drain and fill with correct amount and type of oil.   |
| 35   |                        | Clean vent plug; blow air through it to remove any blockage. If problem persists, replace plug. |
| 36   |                        | Clean air filter element. Refer to engine instruction manual for correct procedure.             |