


OWNER'S MANUAL

ILLUSTRATED PARTS LIST

CABINET ASSEMBLY 25,000 BTU/HR MODEL

This list contains replaceable parts used in your furnace. When ordering parts, follow the instructions listed under *Replacement Parts* on page 19 of this manual.



KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	030643	Front Cover Assembly	1
2	121520	Screw, #8 x 3/8" **	2
3	191240	Front Cover Trim*	1
4	160912	Thermostat	1
5	100892	Cabinet Assembly	1
6	070509	Cabinet Insulation (right and left sides)	1
7	121224	Screw, #10 x 3/4" **	4
8	062242	Thermostat Mounting Plate	1
Δ	070542	Cabinet Insulation (back)	1
Δ	070508	Cabinet Insulation (top)	1
Δ	191244	Operating Instructions Decal (English)	1
Δ	191246	Operating Instructions Decal (French)	1
Δ	531010	Warning Decal	1
Δ	191262	Nameplate	1

Δ Parts available, not shown.

* You must order nameplate and operating instructions decal separately.


** Standard hardware, can be picked up at local hardware store.

OWNER'S MANUAL

ILLUSTRATED PARTS LIST

COMBUSTION CHAMBER ASSEMBLY 25,000 BTU/HR MODEL

This list contains replaceable parts used in your furnace. When ordering parts, follow the instructions listed under *Replacement Parts* on page 19 of this manual.



KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	121357	Screw, #6 x 5/8" **	4	14	020983	Combustion Chamber/ Heat Shield Assembly	1
2	231955	Wire Harness and Ignition Control	1	15	070606	Heat Shield Gasket	1
3	062461	Ignition Control Mounting Bracket	1	16	070398	Burner Access Door Gasket	1
4	121372	Screw, #6 x 1/2" **	2	17	290141	Cover Plate	1
5	230625	Time Delay Relay	1	18	310026	Glass Disc	1
6	230218	Bushing	1	19	030893	Burner Access Door	1
7	120158	Screw, #8 x 3/8" **	4	20	230844	Bushing with Terminals	1
8	230825	Limit Switch	1	21	231950	Flame Sensing Probe	1
9	231144	Terminal Block	1	22	121502	Screw, #6 x 3/8" **	2
10	121224	Screw, #10 x 3/4" **	2	23	090211	Junction Box Cover	1
11	070537	Gasket	1	24	121388	Screw, #10 x 1/2" **	4
12	231143	Transformer Assembly	1	25	063018	Glo-Bar Retainer	1
13	121252	Screw, #10 x 3/8" **	6	26	100980-01	Glo-Bar	1
				27	070909	Glo-Bar Gasket	1


** Standard hardware, available at your local hardware store.

OWNER'S MANUAL

ILLUSTRATED PARTS LIST

BURNER ASSEMBLY 25,000 BTU/HR MODEL

This list contains replaceable parts used in your furnace. When ordering parts, follow the instructions listed under *Replacement Parts* on page 19 of this manual.



KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	120717	Hex Nut, #10-24 **	2
2	121459	Screw, #10-24 x 1/2" **	2
3	010701	Burner Assembly	1
4	180220	Main Burner Orifice	1
5	121388	Screw, #10 x 1/2" **	4
6	070408	Manifold Gasket	1
7	171174	Manifold Assembly	1
8	170545	Reducer Fitting, 3/8" NPT to 1/8" NPT **	1
9	160968	Valve	1
10	170012	90° Street Elbow **	1
11	171170	Gas Inlet Pipe	1
12	170082	90° Elbow **	1


** Standard hardware, available at your local hardware store.

OWNER'S MANUAL

ILLUSTRATED PARTS LIST

BLOWER ASSEMBLY 25,000 BTU/HR MODEL

This list contains replaceable parts used in your furnace. When ordering parts, follow the instructions listed under *Replacement Parts* on page 19 of this manual.



KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	350086	Room Air Wheel	1	16	070386	Combustion Air Housing	
2	121252	Screw, #10 x 3/8" **	5			Gasket	1
3	121247	Screw, #2-56 x 5/8" **	2	17	231389	Motor with Bushings	1
4	230510	Microswitch Assembly	1	18	062307	Motor Support Bracket	1
5	070537	Intake Tube Gasket	1	19	120717	Hex Nut, #10-24 (keps) **	2
6	121661	Tinnerman Nut	2	20	121712	Tinnerman	1
7	390260	Blower Housing (room air)	1	21	350117	Combustion Air Wheel	1
8	121421	Hex Lock Nut, #10-24 **	3	22	390240	Combustion Air Housing (outside)	1
9	050751	Crossover Tube	1	23	120615	Screw, #8 x 1/2" **	10
10	121388	Screw, #10 x 1/2" **	4	24	231036	Capacitor	1
11	070385	Crossover Tube Gasket	2	25	062633	Capacitor Clamp	1
12	121227	Screw, #10-24 x 1/2" **	2	Δ	161093	Equipment Shutoff Valve	1
13	070362	Universal Bushing	1				
14	231231	Capacitor Boot	1				
15	390296	Combustion Air and Motor Cover Assy. Housing	1				

Δ Part available, not shown.

** Standard hardware, available at your local hardware store.