

ILLUSTRATED PARTS LIST

KEY NO.	DESCRIPTION	QTY. REQD.	PART NUMBER	
			MODEL VP-17-A	MODEL VN-19-A
R-1	Body Assembled Includes R-35, R-36, R-37 and R-38	1	2.99.001	2.99.001
R-2	Regulator Mounting Screws	4	1.54.101	1.54.101
R-3	Side Moldings	2	2.04.389	2.04.389
R-4	Screws, Burner Surround and Base Plate	8	1.54.182	1.54.182
R-5	Base Plate	1	2.04.734	2.04.734
R-6	Clip, Side Moldings	2	2.99.002	2.99.002
R-7	Inlet Regulator	1	1.57.503	1.57.502
R-8	Inlet Adaptor (3/8" x 1/2")	1	2.04.831	2.04.831
R-9	L. H. Burner Pipe	1	2.05.465	2.05.465
R-10	Center Burner Pipe	1	2.05.452	2.05.452
R-11	Pressure Test Fitting	1	2.99.033	2.99.033
R-12	Connection, Inlet Regulator To Valve	1	2.05.711	2.05.711
R-13	Lower Front Panel	1	2.99.013	2.99.013
R-14	Connection, Valve To Pilot Regulator	1	—	2.05.405
R-15	Pilot Regulator With Fittings	1	—	2.99.012
R-16	Connection, Pilot Regulator To Pilot	1	—	2.05.405
R-17	Connection, Valve To Pilot	1	2.05.455	—
R-18	Injector and Washer	3	2.99.005	2.99.004
R-19	Injector Holder	3	2.11.067	2.11.067
R-20	O.D.S. Ass. and Bracket	1	2.99.014	2.99.006
R-21	Ignitor	1	1.46.202	1.46.202
R-22	Thermocouple	1	1.43.401	1.43.401
R-23	O.D.S. and Sup. Bracket Screws	5	1.54.101	1.54.101
R-24	Grill Guard, With Side Deflectors	1	2.99.011	2.99.010
R-25	Burner Surround	1	2.99.015	2.99.015
R-26	Pilot Bracket	1	2.02.573	2.02.573
R-27	Chamber and Burner Assembly	1	2.99.008	2.99.007
R-28	R.H. Burner Pipe	1	2.05.465	2.05.465
R-29	Valve	1	1.41.122	1.41.122
R-30	Valve Nut	1	2.04.805	2.04.805
R-31	Regulator Outlet Fitting	1	2.04.844	2.04.844
R-32	Control Rod Pin	1	1.53.302	1.53.302
R-33	Control Rod	1	2.05.950	2.05.950
R-34	Control Knob	1	2.07.201	2.07.201
R-35	Rubber Pads For Back	4	1.50.401	1.50.401
R-36	Control Position Decal	1	1.58.004	1.58.004
R-37	Operating Instructions Decal	1	1.58.005	1.58.005
R-38	Warning Label	1	1.58.002	1.58.002
R-39	Owner's Manual (not shown)	1	1.60.610	1.60.610
R-40	Wall Mounting Screws and plugs (not shown)	4	2.99.032	2.99.032
R-41	L.P. Label Protector	1	1.58.006	—
R-42	Adaptor, Pilot Regulator	1	—	2.04.818
R-43	Wall template (not shown)	1	1.58.403	1.58.403

REPLACEMENT PARTS

Contact authorized dealers of this product. If they are unable to supply original replacement part(s), call DESA International at 1-800-323-5190. Be prepared to indicate name, address, model number, and how heater was malfunctioning, type of gas used and purchase date. In most cases, the defective part will be requested to be returned to the factory.

ILLUSTRATED PARTS LIST

