





Parts Manual

Mfg. No: 104M02-0126-F1




Air Cleaner Group

REF NO	PART NO	QTY	DESCRIPTION
11	590522		TUBE, Breather
318	793480		SCREW -(Mounting Bracket)
445	593260		FILTER, A/C Cartridge
875	594107		Base-Air Cleaner
968	594106		Cover-Air Cleaner
971	590552		SCREW -(Air Cleaner Base to Carburetor/Throttle Body)










Blower Housing Group

REF NO	PART NO	QTY	DESCRIPTION
304C	596471		Housing-Blower
305	590586		Screw -(Blower Housing)
1036			LABEL, Emissions -(Available from a Briggs & Stratton Authorized Dealer)
1319	794467		LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)
1319A	797669		LABEL, Warning -(REQUIRED When Replacing Parts With Warning Labels Affixed)




Carburetor Group

REF NO	PART NO	QTY	DESCRIPTION
104	590558		Pin-Float Hinge
105	594581		Valve-Float Needle
117	594060		Jet-Main -(Standard)
118	594063		Jet-Main -(High Altitude)
121			KIT, Carburetor Overhaul -(Part information located in Service Parts and Tools Group.)
122	590549		Spacer-Carburetor
125	594058		Carburetor
133	591120		Float-Carburetor
137	594633		Gasket-Float Bowl
163	799580		Gasket-Air Cleaner
216			LINK, Choke -(Part information located in Controls Group)
217	590740		Spring-Choke Return
493	593330		Bracket-Mounting
623	799581		Seal-O Ring -(Carburetor Spacer)
724	697478		Retainer-Seal
951	591104		Lever-Choke
975	594632		Bowl-Float
1127	590554		Screw -(Float Bowl to Carburetor Body)
1218	270344S		Seal-O Ring -(Carburetor)
1238	590562		SCREW -(Carburetor Spacer)




Controls Group

REF NO	PART NO	QTY	DESCRIPTION
188	793480		SCREW -(Control Bracket)
202	590517		Link-Mechanical Governor
209	595176		Spring-Governor
216	590547		Link-Choke
222	596754		BRACKET, Control -Used After Code Date 17040600
222	590560		Bracket-Control -Used Before Code Date 17040700
227	590520		Lever-Governor Control
268	691025		CASING, Control Wire
269	691026		WIRE, Control
270	691027		NUT -(Control Wire Casing)
271	691028		Lever-Control
347A	592694		Switch-Rocker
505	793515		NUT -(Governor Control Lever)
562	793514		Bolt -(Governor Control Lever)





Crankcase Cover/Sump and Lubrication Group

REF NO	PART NO	QTY	DESCRIPTION
3			SEAL, Oil -(Part information located in Cylinder Group.)
4	594101		Sump-Engine
7			GASKET, Cylinder Head -(Part information located in Cylinder Head Group.)
12	799587		Gasket-Crankcase
20	399781S		Seal-Oil -(PTO Side)
22	692551		Screw -(Crankcase Cover/Sump)
22A	590763		Screw -(Crankcase Cover/Sump)
43	594560		Slinger-Governor/Oil -Used After Code Date 17092600
43	697799		Slinger-Governor/Oil -Used Before Code Date 17092700
163			GASKET, Air Cleaner -(Part information located in Carburetor Group.)
358			GASKET SET, Engine -(Part information located in Service Parts and Tools Group.)
523	796503		DIPSTICK
524	691876		Seal-O Ring -(Dipstick Tube)
623			SEAL, O-Ring -(Part information located in Carburetor Group.)
718	690959		PIN, Locating
842	691031		SEAL, O-Ring -(Dipstick Cap)
847	596092		DIPSTICK/TUBE ASSEMBLY
868			SEAL, Valve -(Part information located in Cylinder Head Group.)
1022			GASKET, Rocker Cover -(Part information located in Cylinder Head Group.)





Crankshaft Group

REF NO	PART NO	QTY	DESCRIPTION
16	595501		Crankshaft
24	222698S		KEY, Flywheel
25	594099		Piston Assembly
26	594098		Ring Set
27	691588		Lock-Piston Pin
28	298909		Pin-Piston
29	594089		Rod-Connecting
32	691664		Screw -(Connecting Rod)
46	594090		Camshaft
598	592587		Shims-End Play Kit -(Crankshaft or Camshaft Bearing)
741	594105		Gear-Timing




Cylinder Group

REF NO	PART NO	QTY	DESCRIPTION
1	594100	1	CYLINDER ASSEMBLY
3	299819S	1	SEAL, Oil -(Magneto Side)
7		1	GASKET, Cylinder Head -(Part information located in Cylinder Head Group.)
12		1	GASKET, Crankcase -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
20		1	SEAL, Oil -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
163		1	GASKET, Air Cleaner -(Part information located in Carburetor Group.)
358		1	GASKET SET, Engine -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
404	690272	1	WASHER -(Governor Crank)
524		1	SEAL, O-Ring -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
615	690340	1	RETAINER, Governor Shaft
616	590516	1	CRANK, Governor
623		1	SEAL, O-Ring -(Part information located in Carburetor Group.)
718	690959	2	PIN, Locating
842		1	SEAL, O-Ring -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
850		1	SEALANT, Liquid -(Part information located in Service Parts and Tools Group.)
868		1	SEAL, Valve -(Part information located in Cylinder Head Group.)
1022		1	GASKET, Rocker Cover -(Part information located in Cylinder Head Group.)
1263	697124	1	REED, Breather
1264	793453	1	SCREW -(Breather Reed)




Cylinder Head Group

REF NO	PART NO	QTY	DESCRIPTION
3			SEAL, Oil -(Part information located in Cylinder Group.)
5	594091		HEAD-CYLINDER
7	592358		Gasket-Cylinder Head
12			GASKET, Crankcase -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
13	590512		Screw -(Cylinder Head)
20			SEAL, Oil -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
33	594095		Valve-Exhaust
34	594094		Valve-Intake
35	590532		Spring-Valve -(Intake)
36	590532		Spring-Valve -(Exhaust)
40	594092		Retainer-Valve
45	590514		Tappet-Valve
155	594093		Plate-Cylinder Head
163			GASKET, Air Cleaner -(Part information located in Carburetor Group.)
192	590535		Adjuster-Rocker Arm
238	594097		Cap-Valve
337	491055S		PLUG, Spark
358			GASKET SET, Engine -(Part information located in Service Parts and Tools Group.)
524			SEAL, O-Ring -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
623			SEAL, O-Ring -(Part information located in Carburetor Group.)
842			SEAL, O-Ring -(Part information located in Crankcase Cover/Sump and Lubrication Group.)
850			SEALANT, Liquid -(Part information located in Service Parts and Tools Group.)
868	594096		Seal-Valve
914	591103		Screw -(Rocker Cover)
1022	595342		Gasket-Rocker Cover
1023	595352		Cover-Rocker
1026	264137		ROD, Push
1029	590526		Arm-Rocker
1029A	590527		Arm-Rocker





Exhaust Group

REF NO	PART NO	QTY	DESCRIPTION
300D	594108	1	MUFFLER
613	590562	2	SCREW -(Muffler)
832A	594109	1	GUARD, Muffler
836	690661	3	SCREW -(Muffler Guard)






Flywheel, Ignition, and Starter Group

REF NO	PART NO	QTY	DESCRIPTION
23	595185		Flywheel
37	594573		Guard-Flywheel
58	591108		Rope-Starter
60A	281434S		Grip-Starter Rope
78	793480		SCREW -(Flywheel Guard)
332	690662		Nut -(Flywheel)
333	595009		Armature-Magneto
334	691061		SCREW -(Magneto Armature)
356A	596469		Wire-Stop
356H	596470		Wire-Stop
363			PULLER, Flywheel -(Part information located in Service Parts and Tools Group.)
455A	596466		Cup-Flywheel
608	596468		Starter-Rewind
635	692076		BOOT, Spark Plug
668	590546		Spacer
1005A	595184		Fan-Flywheel



Fuel Supply Group

REF NO	PART NO	QTY	DESCRIPTION
187	791766		LINE, Fuel
601	791850		CLAMP, Hose
957	594061		Cap-Fuel Tank
972B	594112		TANK, Fuel



Service Parts and Tools Group

REF NO	PART NO	QTY	DESCRIPTION
121	594636		KIT, Carburetor Overhaul -(Service Kits may include extra parts not specific to this engine.)
358	595354		SET, Engine Gasket -(Service Kits may include extra parts not specific to this engine.)
363	19619		PULLER, Flywheel
383	19576S		WRENCH, Spark Plug
850	100106		SEALANT, Liquid