

GAS RESIDENTIAL HEATER

Illustrated Parts List

GRH-39



Issued: June, 1990

VANGUARD VP1600TC


IMPORTANT: Do not use key numbers when ordering service parts. Always order components by part number and description. Include model and serial numbers.

KEY NO.	PART NUMBER	DESCRIPTION	QTY.	KEY NO.	PART NUMBER	DESCRIPTION	QTY.
1	098304-01	Screw, #10 x 3/8"	2	23-2	098508-01	Valve Retainer Nut	1
2	098742-01	Front Panel	1	23-3	099056-01	Injector	3
3	098460-01	Grill Guard Assembly	1	23-4	099186-03	Tubing-Valve to solenoid	1
4	098342-01	Clip-Grill Guard	2	23-5	099049-01	Tubing-Valve to plaque B	1
5	098198-01	Apron	1	23-6	099057-01	Pressure Tap Fitting	1
6	M11084-26	Screw, #10 x 3/8"	9	23-7	099186-02	Tubing-Solenoid to plq A & C	1
7	098462-01	Control Rod Assembly	1	23-8	098932-06	Control Valve	1
8	098457-01	Reflector Assembly	1	23-9	099043-01	Pilot Tubing-Valve to pilot	1
9	098867-06	Regulator	1	23-10	099051-01	Inlet Tubing	1
10	M11084-38	Screw, #8 x 3/8"	4	23-11	099059-02	ODS/Pilot	1
11	098455-03	Cabinet Assembly	1	23-12	097803-01	Solenoid Valve	1
12	098324-01	Control Knob	1	23-13	099058-02	Male Connector	2
13	098656-01	Thermostat (includes bulb)	1	23-14	M11084-37	Screw, #8 x 1/4"	3
14	098658-01	Thermostat Bracket	1	23-15	M11084-26	Screw, #10 x 3/8"	2
15	M12461-1	Screw, #6 x 1/4"	2	23-16	098593-01	Thermocouple	1
16	098657-01	Thermostat Knob	1	23-17	098594-01	Ignitor Electrode	1
17	098739-01	Circuit Board Assembly	1	24	099066-01	Mounting Bracket	1
18	098870-01	Splice Connector	2	PARTS AVAILABLE - NOT SHOWN			
19	M51122-01	Circuit Board Support	3		099143-01	Owner's Manual	1
20	098788-01	Receptacle Outlet	1		098466-01	Operating Instructions Label	1
21	M11143-1	Strain Relief Bushing	1		098305-02	Control Position Label	1
22	098789-01	Power Cord Assembly	1				
23	See Detail	Burner Assembly	1				
23-1	099218-01	Burner	1				

HEATER EXPLODED VIEW



ODS/PILOT



BURNER ASSEMBLY