


PARTS

MODELS BLP55VA, REM55PVA, RLP55VA, SPC-55A AND TB115A



PARTS


MODELS BLP55VA, REM55PVA, RLP55VA, SPC-55A AND TB115A

KEY			
NO.	PART NO.	DESCRIPTION	QTY
1	121246-01	Grill Assembly	1
2	121247-01	Motor Mounting Bracket	1
3	121206-01	Motor Assembly	1
4	121209-01	Fan	1
5	121406-01	Outer Cylinder, Red (RLP55VA)	1
	121406-04	Outer Cylinder, Black (REM55PVA)	1
	121406-02	Outer Cylinder, Orange (TB115A)	1
	121406-03	Outer Cylinder, Yellow (BLP55VA)	1
6	121216-01	Handle	1
7	121217-01	Clip Handle Mounting	2
8	121205-01	Hose/Regulator Assembly	1
9	113864-01	Power Cord	1
10	113865-01	Strain Relief Bushing	1
11	113887-01	Male E bow Fitting	1
12	121213-01	Spark Plug	1
13	121244-01	High Limit Switch Control Assembly	1
14	113886-01	Nut, Spark Plug	2
15	121224-01	Flame Holder Assembly	1
16	113888-02	Nut orifice Mounting	1
17	121245-01	Orifice, LP Assembly	1
18	**	Middle Cylinder Assembly	1
19	113884-01	Thermocouple	1
20	121212-01	Fuel Tube Assembly	1
21	113875-01	Relay Assembly	1
22	121235-01	Ignitor	1
23	113872-01	Terminal Board	1
24	121230-01	Control Valve Assembly	1
	113870-01	Elbow Street Fitting	2
	113869-01	Coupling Fitting	2
	113868-01	Male Connector Fitting	1
	113876-01	Female Connector Fitting	1
	113873-01	Ball Valve	1
	113871-01	Valve	1
25	121410-01	Control Box Assembly	1
26	121411-01	Bottom Panel	1
PARTS AVAILABLE - NOT SHOWN			
	121238-01	Pressure Ignition Wire	1
	121237-03	High Limit Wire	1
	121236-01	Ground Wire	1
	121215-01	Knob	

** Not a field replaceable part.

ILLUSTRATED PARTS BREAKDOWN

MODELS 85-FACA, BLP85VA, REM85PVA, RLP85VA AND SPC-85



PARTS LIST


MODELS 85-FACA, BLP85VA, REM85PVA, RLP85VA AND SPC-85

KEY			
	NO.	PART NO. DESCRIPTION	QTY.
1	121407-01	Outer Cylinder Assembly, Red (RLP85VA)	1
	121407-02	Outer Cylinder Assembly, Red (85-FACA)	1
	121407-03	Outer Cylinder Assembly, Yellow (BLP85VA)	1
	121407-04	Outer Cylinder Assembly, Black (REM85PVA)	1
	121407-05	Outer Cylinder Assembly, Orange (SPC-85A)	1
2	121209-01	Fan	1
3	121207-01	Motor Assembly	1
4	121246-02	Motor Grill	1
5	121225-03	Flame Holder Assembly	1
6	**	Middle Cylinder Assembly	1
7	113888-02	Nut Orifice Mounting 3/4-16	1
8	113931-01	Male Elbow Fitting	1
9	113884-01	Thermocouple	1
10	121244-01	High Limit Control Assembly	1
11	121213-02	Spark Plug, 1/8 Gap	1
12	113886-01	Nut-Spark Plug	2
13	121245-03	Orifice Assembly	1
14	121357-01	Control Box Assembly	1
15	113924-01	Ignition Relay Bracket	1
16	113872-01	Terminal Board	1
17	121235-01	Spark Ignition, 115V Hi-Lo Mini Ignitor	1
18	121212-02	Fuel Tube Assembly	1
19	121230-02	Control Valve Assembly	1
	113869-01	Fitting, Coupling	1
	113868-01	Fitting, Male Connector	1
	113871-01	Valve	1
	113928-01	Ball Valve, Variable Rate	1
	113929-01	Female Connector Fitting	1
	113870-01	Fitting, Elbow	2
20	121248-01	Spacer, TC Bracket	1
21	121410-04	Control Panel Assembly	1
22	113865-01	Strain Relief Bushing	1
23	113864-01	Power Cord	1
24	121205-01	Hose/Regulator Assembly	1
25	121217-01	Clip Handle Mounting	2
26	121216-01	Handle	1
27	113875-01	Relay	1
28	113923-01	Bracket, TC	1
29	121411-04	Access Panel	1
PARTS AVAILABLE - NOT SHOWN			
	121238-01	Pressure Ignition Wire	1
	121237-03	High Limit Wire	1
	121236-01	Ground Wire	1
	121215-01	Knob	

** Not a field replaceable part.

PARTS

MODELS 125-FA, BLP125VA, REM125PVA, RLP125VA AND SPC-125A



PARTS

MODELS 125-FA, BLP125VA, REM125PVA, RLP125VA AND SPC-125A

KEY NO.	PART NO.	DESCRIPTION	QTY
1	113919-01	Grill Assembly	1
2	121207-01	Motor Assembly	1
3	121210-01	Fan	1
4	121408-01	Outer Shell Cylinder Assembly, Red (RLP125VA)	1
	121408-02	Outer Shell Cylinder Assembly, Red (125-FA)	1
	121408-03	Outer Shell Cylinder Assembly, Yellow (BLP125VA)	1
	121408-04	Outer Shell Cylinder Assembly, Black (REM125PVA)	1
	121408-05	Outer Shell Cylinder Assembly, Orange (SPC-125A)	1
5	121216-01	Handle	1
6	121217-01	Clip Handle Mounting	2
7	113931-01	Male Elbow Fitting	1
8	121213-02	Spark Plug, 1/8 (3.18 mm) Gap	1
9	121244-02	High Limit Switch Control Assembly	1
10	113923-01	Thermocouple Bracket	1
11	121248-01	Thermocouple Spacer	1
12	121245-02	Orifice, LP Assembly	1
13	**	Middle Cylinder Assembly	1
14	113886-01	Nut, Spark Plug	2
15	121225-01	Flame Holder Assembly	1
16	113888-02	Nut orifice Mounting	1
17	121212-02	Fuel Tube Assembly	1
18	113884-01	Thermocouple	1
19	113924-01	Bracket Ignition Relay	1
20	113872-01	Terminal Board	1
21	114150-01	Steel Spacer	1
22	113875-01	Relay Assembly	1
23	121235-02	Ignitor	1
24	114151-01	Spacer, PC Standoff Nylon	3
25	121230-02	Control Valve Assembly	1
	114153-01	Elbow Street Fitting	2
	114159-01	Ball Valve, Variable Rate	1
	113929-01	Female Connector Fitting	1
	113869-01	Coupling Fitting	1
	113868-01	Male Connector Fitting	1
	113871-01	Valve	1
26	114158-01	Flat Washer	1
27	121410-02	Control Box Assembly	1
28	113865-01	Strain Relief Bushing	1
29	113864-01	Power Cord	1
30	121205-01	Hose/Regulator Assembly	1
31	121411-02	Access Panel	1
PARTS AVAILABLE - NOT SHOWN			
	121238-01	Pressure Ignition Wire	1
	121237-03	High Limit Wire	1
	121236-01	Ground Wire	1
	121215-01	Knob	

** Not a field replaceable part.