

MAXair Premium Air Compressor part breakdown sheet - Single Stage Stationary Units P90G25H1-MAP

Revised 5/15/17

Item	Description	
1	Compressor w/ Flywheel	PT03AHP
2	Discharge Tube	TU-20-AL
3	Engine	GX-270UT1QA2-B
4	Pulley - Engine	MA38X1
5	V-Belt	A54
6	Belt Guard	TT-GUARD
7	Air Receiver (tank)	25HEPORT-Y
8	Pressure Gauge	PGLF200-2.5BM1/4
9	Drain Cock	240-B
10	Safety Valve	PSV1/4-200
11	Unloader	LMV100F-125-150
12a	Handle (Long)	PT-HANDLE-25L
12b	Handle (Short)	PT-HANDLE-24HS
13	Wheel	PT-WHEEL- FF
14	Vibration Dampner	TT-FOOT
15	Engine Control w/ Cable	TCLP-36-3104
16	Coupler	CPL-TRI
	Eagle Compressor Oil	EAOIL10
	Eagle Engine Oil	EAOIL10W30

MAXair

PREMIUM

