

**121600**

# Illustrated Parts List

## Model Series

# 121600

TYPE NUMBERS  
0015 through 0662.

### TABLE OF CONTENTS


Air Cleaner .....	6
Blower Housing/Shrouds .....	7
Camshaft .....	2
Carburetor .....	4
Controls .....	5
Crankshaft .....	2
Cylinder .....	2
Cylinder Head .....	3
Electric Starter .....	7
Engine Sump .....	2
Exhaust System .....	6
Flywheel .....	7
Flywheel Brake .....	5
Fuel Supply .....	4
Governor Spring .....	5
Ignition .....	5
Kits/Gaskets Sets .....	8
Lubrication .....	2
Piston Group .....	2
Rewind Starter .....	7




PRINTED IN U.S.A.

COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.






# 121600

















**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**  
 2143-2 Assemblies include all parts shown in frames. 07/01/2004


















Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 2143-3 Assemblies include all parts shown in frames.













Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 2143-5 Assemblies include all parts shown in frames.







**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**  
 2143-6 Assemblies include all parts shown in frames. 07/01/2004



1036 Emission Label







REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
<b>1</b>	<b>790363</b>	Cylinder Assembly (Used After Code Date 04040400). <b>Note</b> ——— <b>499678</b> Cylinder–Assembly (Used Before Code Date 04040500). <b>790363</b> Cylinder Assembly (Used After Code Date 04040400). Used on Type No(s). 0324, 0333, 0343, 0365, 0372, 0373. <b>697639</b> Cylinder Assembly (Used Before Code Date 04040500). Used on Type No(s). 0324, 0333, 0343, 0365, 0372, 0373.	<b>5</b>	<b>695276</b>	Head–Cylinder	<b>16</b>	<b>691457</b>	Crankshaft
			<b>7</b>	<b>★Δ695166</b>	Gasket–Cylinder Head			<b>Note</b> ———
			<b>8</b>	<b>495786</b>	Breather Assembly			<b>691456</b> Crankshaft
			<b>9</b>	<b>★272481</b>	Gasket–Breather			Used on Type No(s).
			<b>10</b>	<b>691125</b>	Screw (Breather Assembly)			0025,0058,0126,0133, 0137,0158,0163,0167, 0169,0171,0199,0204, 0228,0255,0266,0269, 0270,0271,0273,0307, 0320,0335,0336,0349, 0358,0363,0369,0370, 0373,0376,0377,0525, 0527,0528,0662.
			<b>11A</b>	<b>499675</b>	Tube–Breather			<b>693291</b> Crankshaft
			<b>12</b>	<b>★692232</b>	Gasket–Crankcase			Used on Type No(s).
			<b>13</b>	<b>691137</b>	Screw (Cylinder Head)			0021,0143,0166,0172, 0185,0187,0195,0197, 0206,0222,0234,0259, 0283,0305,0315,0323, 0325,0329,0331,0355, 0384,0521,0621.
			<b>15</b>	<b>691680</b>	Plug–Oil Drain (Square Socket)			<b>691458</b> Crankshaft
			<b>15A</b>	<b>691093</b>	Plug–Oil Drain (Hex Socket)			Used on Type No(s).
<b>2</b>	<b>399269</b>	Kit–Bushing/Seal (Magneto Side)						0150,0153,0256,0319.
<b>3</b>	<b>★299819</b>	Seal–Oil (Magneto Side)						<b>692716</b> Crankshaft
<b>4</b>	<b>493279</b>	Sump–Engine <b>Note</b> ———						Used on Type No(s).
		<b>498983</b> Sump–Engine Used on Type No(s). 0030, 0045, 0142, 0188, 0189, 0235, 0313, 0545.						0174,0201,0202,0215, 0220,0264,0272,0311, 0314,0360.
		<b>696294</b> Sump–Engine Used on Type No(s). 0288, 0295, 0323, 0325, 0329, 0345, 0347.						<b>692803</b> Crankshaft
		<b>696340</b> Sump–Engine Used on Type No(s). 0359.						Used on Type No(s).
<b>4A</b>	<b>493365</b>	Sump–Engine (Auxiliary PTO)						0045,0188,0235,0545.
<b>4B</b>	<b>692509</b>	Sump–Engine Used on Type No(s). 0270.						<b>692823</b> Crankshaft
								Used on Type No(s).
								0016,0022,0193,0194, 0227,0240,0241,0301, 0522,0622.
								<b>692824</b> Crankshaft
								Used on Type No(s).
								0142.
								<b>694491</b> Crankshaft
								Used on Type No(s).
								0026,0374,0375,0526.
								<b>695860</b> Crankshaft
								Used on Type No(s).
								0281.
								<b>696607</b> Crankshaft
								Used on Type No(s).
								0291, 0293.
								<b>790156</b> Crankshaft
								Used on Type No(s).
								0379, 0383.

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

Δ Included in Valve Gasket Set–Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

# 121600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
17	692517	Bearing–Ball	24	222698	Key–Flywheel	45	690977	Tappet–Valve
20	★399781	Seal–Oil (PTO Side)	25	499627	Piston Assembly (Standard)	46	694039	Camshaft (Used After Code Date 99030700).
20A	★691952	Seal–Oil (PTO Side) (Auxiliary PTO)			<b>Note</b> _____			<b>Note</b> _____
22	691092	Screw (Crankcase Cover/Sump)			692788 Piston Assembly (.010" Oversize)			694035 Camshaft (Used Before Code Date 99030800).
23	696569	Flywheel			692789 Piston Assembly (.020" Oversize)			<b>Note</b> _____
		<b>Note</b> _____			692790 Piston Assembly (.030" Oversize)			694040 Camshaft (Used After Code Date 99030700). Used on Type No(s). 0270.
		692693 Flywheel Used on Type No(s). 0016, 0030, 0061, 0117, 0119, 0120, 0135, 0142, 0149, 0152, 0160, 0172, 0174, 0183, 0186, 0187, 0189, 0193, 0194, 0197, 0198, 0200, 0201, 0202, 0206, 0207, 0209, 0211, 0217, 0218, 0220, 0222, 0242, 0253, 0254, 0260, 0261, 0262, 0266, 0275, 0281, 0289, 0293, 0296, 0298, 0302, 0303, 0313, 0314, 0316, 0317, 0318, 0327, 0330, 0334, 0335, 0348, 0350, 0354, 0357, 0369, 0379, 0383, 0384, 0505, 0561, 0562.	26	499631	Ring Set (Standard)	46A	694038	Camshaft (Clockwise) (Used After Code Date 99030700).
		692987 Flywheel Used on Type No(s). 0045, 0188, 0235, 0545.			<b>Note</b> _____			<b>Note</b> _____
		697271 Flywheel Used on Type No(s). 0288, 0295, 0323, 0325, 0329, 0345, 0347.	27	691866	Lock–Piston Pin			694034 Camshaft (Clockwise) (Used Before Code Date 99030800).
		697637 Flywheel Used on Type No(s). 0324, 0333, 0343, 0351, 0365, 0372, 0373.	28	499423	Pin–Piston			694037 Camshaft (Counterclockwise) (Used After Code Date 99030700).
			29	499424	Rod–Connecting			694033 Camshaft (Counterclockwise) (Used Before Code Date 99030800).
			32	691664	Screw (Connecting Rod)	51★♦♦△692799		Gasket–Intake
			32A	695759	Screw (Connecting Rod) (Used After Code Date 00042200).	55	691421	Housing–Rewind Starter
			33	499642	Valve–Exhaust	58	697316	Rope–Starter (Cut To Required Length)
			34	499641	Valve–Intake	59	396892	Insert–Grip
			35	691304	Spring–Valve (Intake)	60	281434	Grip–Starter Rope
			36	691304	Spring–Valve (Exhaust)	60A	393152	Grip–Starter Rope
			37	694086	Guard–Flywheel	65	690837	Screw (Rewind Starter)
			40	692194	Retainer–Valve			
			43	691997	Slinger–Governor/Oil			
					<b>Note</b> _____			
					691486 Slinger– Governor/Oil Used on Type No(s). 0030, 0045, 0142, 0188, 0189, 0235, 0545.			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

♦ Included in Carburetor Gasket Set–Ref. No. 977.

△ Included in Valve Gasket Set–Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
73	691221	Screen—Rotating	117	498981	Jet—Main (Standard) (Used After Code Date 03110600).	125	694202	Carburetor (Primer System)
78	691108	Screw (Flywheel Guard)				125B	698056	Carburetor (Choke System) (Used After Code Date 02051200).
83	691778	Shaft—Auxiliary Drive <b>Note</b> 690522 Shaft—Auxiliary Drive Used on Type No(s). 0150, 0153, 0158, 0343, 0371. 690527 Shaft—Auxiliary Drive Used on Type No(s). 0122, 0241.						Used on Type No(s). 0149,0152,0160,0161, 0162,0197,0199,0200, 0201,0202,0211,0220, 0243,0247,0259,0265, 0293,0296,0311,0314, 0327,0348,0369,0372, 0373,0379,0383.
95	691636	Screw (Throttle Valve)	117A	694250	Jet—Main (Standard) (Used After Code Date 02050500).			<b>Note</b> 694205 Carburetor (Choke System) (Used Before Code Date 02051300). Used on Type No(s). 0149,0197,0199,0200, 0201,0202,0211,0220, 0247,0259,0265,0293, 0296,0311,0314,0327.
97	499682	Shaft—Throttle (Metal) <b>Note</b> 790121 Shaft—Throttle (Plastic)						698055 Carburetor (Choke System) (Used After Code Date 02050500). Used on Type No(s). 0016,0030,0045,0142, 0183,0188,0189,0194, 0198,0206,0222,0235, 0275,0301,0313,0324, 0350,0351.
98	398185	Kit—Idle Speed	118	497466	Jet—Main (High Altitude) (Used After Code Date 03110600).			694203 Carburetor (Choke System) (Used Before Code Date 02050600). Used on Type No(s). 0016,0030,0045,0142, 0183,0188,0189,0194, 0198,0206,0222,0227, 0235,0275,0301,0313, 0324.
101	691623	Pin—Shaft						694206 Carburetor (Choke System) Used on Type No(s). 0152, 0207, 0262, 0298, 0303.
104	691242	Pin—Float Hinge						697914 Carburetor (Choke System) Used on Type No(s). 0317, 0318, 0343.
108	691182	Valve—Choke (Used After Code Date 97080300). <b>Note</b> 224783 Valve—Choke (Used Before Code Date 97080400). Used on Type No(s). 0152.						
109A	499681	Shaft—Choke <b>Note</b> 499779 Shaft—Choke Used on Type No(s). 0149, 0152, 0160, 0161, 0162, 0197, 0199, 0200, 0201, 0202, 0211, 0220, 0243, 0247, 0259, 0265, 0293, 0296, 0311, 0314, 0327, 0348, 0369, 0372, 0373, 0379, 0383.	118A	497466	Jet—Main (High Altitude) (Used After Code Date 02050500). <b>Note</b> 498975 Jet—Main (High Altitude) (Used Before Code Date 02050600).			
			121	692703	Kit—Carburetor Overhaul			
			122	692799	Spacer—Carburetor			

★ Included in Engine Gasket Set—Ref. No.358.

● Included in Carburetor Overhaul Kit—Ref. No. 121.

◆ Included in Carburetor Gasket Set—Ref. No. 977.

△ Included in Valve Gasket Set—Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

# 121600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
127	●694468	Plug–Welch	209A	690319	Spring–Governor			
127A	●691739	Plug–Welch			<b>Note</b>			692906 Spring–Governor
130	691203	Valve–Throttle			691290 Spring–Governor			Used on Type No(s). 0149, 0160, 0161, 0162, 0197, 0199, 0200, 0211, 0247, 0259, 0261, 0262, 0265, 0293, 0296, 0303, 0314, 0318, 0327, 0379, 0383.
		<b>Note</b>			Used on Type No(s). 0016, 0030, 0142, 0183, 0189, 0193, 0194, 0198, 0206, 0215, 0219, 0222, 0275, 0289, 0295, 0301, 0306, 0324, 0359, 0360.			692433 Spring–Governor
		696564 Valve–Throttle (Used With Plastic Throttle Shaft)			691291 Spring–Governor			Used on Type No(s). 0201, 0202, 0220, 0311, 0365, 0369, 0373.
130A	691181	Valve–Throttle			Used on Type No(s). 0019, 0133, 0137, 0154, 0155, 0158, 0167, 0168, 0169, 0173, 0174, 0204, 0205, 0217, 0218, 0221, 0228, 0253, 0254, 0255, 0269, 0270, 0271, 0273, 0291, 0292, 0297, 0320, 0336, 0350, 0351, 0370, 0527, 0528.			693031 Spring–Governor
		<b>Note</b>			Used on Type No(s). 0015, 0018, 0021, 0022, 0023, 0025, 0026, 0050, 0051, 0058, 0060, 0061, 0100, 0105, 0115, 0117, 0118, 0121, 0122, 0137, 0172, 0175, 0190, 0191, 0195, 0240, 0241, 0265, 0279, 0286, 0288, 0331, 0332, 0338, 0339, 0340, 0349, 0358, 0363, 0371, 0376, 0505, 0515, 0521, 0522, 0525, 0526, 0550, 0551, 0560, 0561, 0562, 0615, 0621, 0622, 0625, 0662.			Used on Type No(s). 0152, 0207, 0298, 0317, 0318, 0343, 0348, 0372.
		691203 Valve–Throttle						693032 Spring–Governor
		Used on Type No(s). 0016, 0030, 0045, 0142, 0183, 0188, 0189, 0194, 0198, 0206, 0222, 0235, 0275, 0301.						Used on Type No(s). 0045, 0188, 0545.
133	398187	Float–Carburetor			691851 Spring–Governor			Used on Type No(s). 0302, 0315, 0316, 0320, 0322, 0328, 0329, 0330, 0375, 0377, 0384.
134	●398188	Kit–Needle/Seat						211 692434 Spring–Governed Idle
137	●693981	Gasket–Float Bowl						217 690354 Spring–Choke Return
146	690979	Key–Timing						
163	◆◆691894	Gasket–Air Cleaner						
163A	◆◆692667	Gasket–Air Cleaner						
187	691050	Line–Fuel (Cut To Required Length)						
188	693168	Screw (Control Bracket)						
190	690940	Screw (Fuel Tank)						
192	694543	Adjuster–Rocker Arm						
202	691303	Link–Mechanical Governor						

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

△ Included in Valve Gasket Set–Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
<b>222C</b>	<b>692618</b>	Bracket—Control —— <b>Note</b> —— <b>692617</b> Bracket—Control (Used After Code Date 98031500). Used on Type No(s). 0018, 0023, 0100, 0101, 0118, 0121, 0122, 0165, 0166, 0171, 0175, 0190, 0191, 0195, 0221, 0227, 0240, 0241, 0249, 0251, 0256, 0263, 0270, 0271, 0283, 0286, 0291, 0297, 0301, 0305, 0307, 0315, 0319, 0320, 0321, 0328, 0331, 0332, 0336, 0344, 0346, 0349, 0350, 0351, 0355, 0358, 0374, 0375 <b>691461</b> Bracket—Control (Used Before Code Date 98031600). Used on Type No(s). 0018, 0100, 0101, 0105, 0115, 0118, 0121, 0122, 0136, 0155, 0163, 0165, 0166, 0168, 0171, 0175, 0189, 0190, 0191, 0195.	<b>227</b>	<b>691467</b>	Lever—Governor Control	<b>304</b>	<b>499677</b>	Housing—Blower —— <b>Note</b> —— <b>499676</b> Housing—Blower Used on Type No(s). 0016, 0030, 0117, 0119, 0120, 0133, 0135, 0137, 0142, 0149, 0150, 0152, 0153, 0154, 0167, 0169, 0172, 0173, 0174, 0182, 0183, 0186, 0187, 0188, 0189, 0193, 0194, 0197, 0198, 0200, 0201, 0202, 0204, 0205, 0206, 0207, 0209, 0211, 0217, 0218, 0235, 0242, 0253, 0254, 0255, 0260, 0262, 0266, 0281, 0289, 0293, 0296, 0298, 0302, 0303, 0308, 0311, 0313, 0314, 0316, 0317, 0318, 0324, 0327, 0330, 0333, 0334, 0335, 0343, 0348, 0350, 0351, 0360, 0369, 0372, 0373, 0379, 0383, 0384, 0505, 0561, 0562. <b>695976</b> Housing—Blower Used on Type No(s). 0100, 0279, 0291, 0297, 0307, 0331, 0332, 0338, 0346, 0358, 0370, 0377, 0528. <b>697270</b> Housing—Blower Used on Type No(s). 0288, 0295, 0323, 0325, 0329, 0345, 0347.
<b>222E</b>	<b>697614</b>	Bracket—Control	<b>236</b>	<b>691826</b>	Link—Lockout			
<b>222G</b>	<b>692615</b>	Bracket—Control —— <b>Note</b> —— <b>692616</b> Bracket—Control Used on Type No(s). 0152, 0207, 0262, 0298, 0303, 0317, 0318, 0343. <b>692722</b> Bracket—Control Used on Type No(s). 0161, 0162, 0199, 0201, 0202, 0247, 0259, 0264, 0265, 0311, 0314, 0348, 0372.	<b>238</b>	<b>691300</b>	Cap—Valve			
			<b>240</b>	<b>298090</b>	Filter—Fuel			
			<b>259</b>	<b>691189</b>	Bracket—Casing Clamp			
			<b>265</b>	<b>690798</b>	Clamp—Casing			
			<b>265A</b>	<b>691024</b>	Clamp—Casing			
			<b>267</b>	<b>691044</b>	Screw (Casing Clamp)			
			<b>268</b>	<b>691072</b>	Casing—Control Wire (Cut To Required Length)			
			<b>269</b>	<b>691589</b>	Wire—Control (Cut To Required Length)			
			<b>270</b>	<b>691027</b>	Nut (Control Wire Casing)			
			<b>271</b>	<b>691028</b>	Lever—Control			
			<b>276</b>	<b>271716</b>	Washer—Sealing			
			<b>287</b>	<b>690940</b>	Screw (Dipstick Tube)			
			<b>300</b>	<b>692275</b>	Muffler (Super Quiet Lo Tone)			
			<b>300A</b>	<b>692276</b>	Muffler (Quiet Lo Tone)			
			<b>300B</b>	<b>699769</b>	Muffler (Square Lo Tone)			
			<b>300C</b>	<b>694248</b>	Muffler (Super Quiet Power Lo Tone)			

★ Included in Engine Gasket Set—Ref. No.358.

● Included in Carburetor Overhaul Kit—Ref. No. 121.

◆ Included in Carburetor Gasket Set—Ref. No. 977.

△ Included in Valve Gasket Set—Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

# 121600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
305	691108	Screw (Blower Housing)	455	695161	Cup-Flywheel	604A	693807	Cover-Control
306	691232	Shield-Cylinder	456	692299	Plate-Pawl Friction			<b>Note</b>
307	690345	Screw (Cylinder Shield)	459	281505	Ratchet-Pawl			692669 Cover-Control
309	695550	Motor-Starter	472	693809	Knob-Choke Shaft			Used on Type No(s). 0137.
310	692327	Bolt (Starter Motor)	474	691991	Alternator	608	497680	Starter-Rewind
332	690662	Nut (Flywheel)			<b>Note</b>	613	691108	Screw (Muffler)
333	802574	Armature-Magneto			695730 Alternator	613A	691140	Screw (Muffler)
334	691061	Screw (Magneto Armature)	493	692877	Bracket-Mounting			Used on Type No(s). 0324, 0333, 0343, 0351, 0365, 0372, 0373.
337	692051	Plug-Spark (Resistor)	505	691251	Nut (Governor Control Lever)	615	690340	Retainer-Governor Shaft
		<b>Note</b>	510	494147	Drive-Starter	616	698801	Crank-Governor
		692720 Plug-Spark (EMS)	513	692358	Clutch-Drive	619	691108	Screw (Cylinder Head Plate)
341	690368	Stud (Mounting Bracket)	523	499621	Dipstick	621	692310	Switch-Stop
346	690661	Screw (Spark Arrestor)	524	*692296	Seal-Dipstick Tube	633	◆693867	Seal-Choke/Throttle Shaft (Choke Shaft)
347	691396	Switch-Rocker	525	495265	Tube-Dipstick	633A	◆691321	Seal-Choke/Throttle Shaft (Throttle Shaft)
356	692390	Wire-Stop	529	692937	Grommet	635	66538	Boot-Spark Plug
356A	499690	Wire-Stop	532	692851	Nut (Mounting Bracket)	651	691660	Screw (Starter Gear Cover)
356B	692151	Wire-Stop	544	690786	Armature-Starter	670	692294	Spacer-Fuel Tank
356C	693010	Wire-Stop	545	492919	Washer Set (Starter Motor)	676	397931	Deflector-Muffler (Direct Out) (3/4" Diameter)
356D	691418	Wire-Stop	562	691119	Bolt (Governor Control Lever)	676A	393756	Deflector-Muffler (Flanged Side Out)
357	692191	Key-Drive Pulley	564A	693808	Screw (Control Cover)			<b>Note</b>
358	694090	Gasket Set-Engine	578	398153	Wire Assembly			393760 Deflector- Muffler (Side Out)
363	19069	Puller-Flywheel	584	697734	Cover-Breather Passage			Used on Type No(s). 0317, 0318, 0348, 0372.
365	691136	Screw (Carburetor)	585	*691879	Gasket-Breather Passage	676B	396548	Deflector-Muffler (Single Louver)
374	691074	Washer (Camshaft)	592	690800	Nut (Rewind Starter)	676C	497682	Deflector-Muffler (Direct Out) (1 3/16" Diameter)
383	19374	Wrench-Spark Plug	597	691696	Screw (Pawl Friction Plate)	676D	697915	Deflector-Muffler (Square Lo Tone)
404	690272	Washer (Governor Crank)	601	95162	Clamp-Hose (Green)			
425A	690244	Screw (Air Cleaner Cover)	601A	691038	Clamp-Hose (Black)			
443B	690255	Screw (Air Cleaner Primer Base)						
445A	697029	Filter-Air Cleaner Cartridge						

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
677	690661	Screw (Muffler Deflector)	789	696547	Harness–Wiring (Used After Code Date 00040600).	801	690782	Cap–Drive
684	690345	Screw (Breather Passage Cover)			<b>Note</b> _____	802	695267	Cap–End (Used After Code Date 00040600).
689	691855	Spring–Friction			691372 Harness– Wiring			<b>Note</b> _____
692	690572	Spring–Friction			(Used Before Code Date 00040700).			695975 Cap–End (Used Before Code Date 00040700).
697	691127	Screw (Drive Cap)			696546 Harness– Wiring	803	695266	Housing–Starter (Used After Code Date 00040600).
715	691147	Screw (Shaft Stop)			Used on Type No(s). 0298, 0303, 0311, 0314, 0324, 0343, 0351, 0365, 0372, 0373, 0562.			<b>Note</b> _____
718	690959	Pin–Locating						695975 Housing– Starter
721	690449	Stop–Shaft						(Used Before Code Date 00040700).
727	692934	Cover–Starter Drive	789A	696546	Harness–Wiring (Used After Code Date 00040600).	830	694544	Stud–Rocker Arm
737	692511	Screw (Oil Filter Adapter)			<b>Note</b> _____	832	691466	Guard–Muffler (Super Lo Tone)
741	790345	Gear–Timing (Use Without Woodruff Key)			690790 Harness– Wiring	832A	692984	Guard Muffler (Quiet Lo Tone)
		<b>Note</b> _____			(Used Before Code Date 00040700).	832C	695593	Guard Muffler (Square Lo Tone)
		691830 Gear–Timing (Uses Woodruff Key)				836	691147	Screw (Muffler Guard)
742	93941	Retainer–E-Ring			696545 Harness– Wiring	836A	697551	Screw (Muffler Guard)
743	690516	Gear–Drive (Clockwise)			Used on Type No(s). 0302, 0330, 0333, 0334.	836B	692198	Screw (Muffler Guard)
		<b>Note</b> _____	789B	695553	Harness–Wiring (Used After Code Date 00040300).	842	★691031	Seal–O Ring (Dipstick Tube)
		691772 Gear–Drive (Counterclockwise) Used on Type No(s). 0122, 0150, 0158, 0160, 0161, 0162, 0205, 0236, 0241, 0251, 0328, 0343, 0375.			Used on Type No(s). 0260.	843	691884	Sleeve–Lever
745	691648	Screw (Brake)			<b>Note</b> _____	847	692047	Dipstick/Tube Assembly
750	691683	Screw (Oil Pump Cover)			694497 Harness– Wiring	851	493880	Terminal–Spark Plug
783	691918	Gear–Pinion (19 Teeth) (Starter Drive)			(Used Before Code Date 00040400).	853	695268	Adaptor–Wire
783A	691269	Gear–Pinion (12 Teeth)			Used on Type No(s). 0260.			<b>Note</b> _____
784	692341	Cover–Starter Gear	789C	694498	Harness–Wiring Used on Type No(s). 0302, 0330, 0333, 0334.	868	★△692044	Seal–Valve
785	692352	Gasket–Starter Cover				883	★△691893	Gasket–Exhaust
						886	696268	Gasket Kit–Cylinder Head/Plate

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

△ Included in Valve Gasket Set–Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**

# 121600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
910	691094	Stud (Alternator)	958	698183	Valve–Fuel Shut–Off (Plastic)	1027	692513	Filter–Oil
914	691108	Screw (Rocker Cover)	965	692507	Cover–Oil Pump	1028	692516	Adapter–Oil Filter
921A	699633	Cover–Blower Housing	966B	690243	Base–Air Cleaner Primer	1029	691230	Arm–Rocker
922	691831	Spring–Brake ———— <b>Note</b> ———— <b>692135</b> Spring–Brake Used on Type No(s). 0100, 0279, 0291, 0297, 0307, 0331, 0332, 0338, 0346, 0358, 0370, 0377, 0528.	967A	273356	Filter–Pre Cleaner	1034	691343	Guide–Push Rod
923	691994	Brake ———— <b>Note</b> ———— <b>695891</b> Brake Used on Type No(s). 0100, 0279, 0291, 0297, 0307, 0331, 0332, 0338, 0346, 0358, 0370, 0377, 0528.	968A	691342	Cover–Air Cleaner	1036	790635	Label–Emission (Used After Code Date 04063000). ———— <b>Note</b> ———— <b>696767</b> Label– Emission (Used Before Code Date 04070100 and After Code Date 01070100). <b>695109</b> Label– Emission (Used After Code Date 99093000 and Before Code Date 01070200). <b>694507</b> Label– Emission (Used After Code Date 98123100 and Before Code Date 99100100). <b>499343</b> Label– Emission (Used Before Code Date 99010100).
925	690595	Cover–Linkage	972	693377	Tank–Fuel (Plastic)	1055	692623	Tube–Oil Pump
930	691919	Guard–Rewind ———— <b>Note</b> ———— <b>499679</b> Guard– Rewind Used on Type No(s). 0298, 0303, 0324, 0365.	972B	695960	Tank–Fuel (Plastic) Used on Type No(s). 0288, 0295, 0323, 0325, 0329, 0345, 0347.	1058	274979	Owner's Manual ———— <b>Note</b> ———— <b>275054</b> Owner's Manual (Touch N Mow)
930A	692675	Guard–Rewind	975	493640	Bowl–Float	1059	692311	Kit–Screw/Washer ———— <b>Note</b> ———— <b>696293</b> Kit–Screw/ Washer (Touch N Mow)
935	499421	Switch–Interlock	976	694395	Primer–Carburetor	1095	694091	Gasket Set–Valve
937	691325	Spline–Starter	977	692704	Gasket Set–Carburetor			
943	692514	Seal–O Ring (Oil Pump Cover)	978	692515	Gasket–Oil Adapter			
946	396526	Guide–Rope	990	695951	Key Set (Touch N Mow)			
957	692046	Cap–Fuel Tank (Plastic)	993	★△694088	Gasket–Cylinder Head Plate			
957A	397974	Cap–Fuel Tank (Plastic)	994	692957	Arrestor–Spark			
			994A	398067	Arrestor–Spark			
			1005	691346	Fan–Flywheel			
			1009	696255	Screw (Starter Motor)			
			1019	499691	Kit–Label ———— <b>Note</b> ———— <b>790231</b> Kit–Label (Touch N Mow)			
			1022	★△691890	Gasket–Rocker Cover			
			1023	499624	Cover–Rocker			
			1024	692508	Pump–Oil			
			1026	692045	Rod–Push			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

◆ Included in Carburetor Gasket Set–Ref. No. 977.

△ Included in Valve Gasket Set–Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**



REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1102	691255	Pilot-Guide Used on Type No(s). 0045, 0189, 0235, 0313, 0545.	1119	692979	Screw (Alternator) ———— <b>Note</b> ———— <b>691183</b> Screw (Alternator) Used on Type No(s). 0324, 0333, 0343, 0351, 0365, 0372, 0373.	1160	691627	Screw (Interlock Switch)
1102A	691266	Pilot-Guide Used on Type No(s). 0030, 0142, 0188.				1210	498144	Pulley/Spring Assembly (Pulley)
						1211	498144	Pulley/Spring Assembly (Spring)
						1236	695959	Starter-Mechanical
						1330	272147	Manual-Repair

★ Included in Engine Gasket Set-Ref. No.358.  
● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.  
△ Included in Valve Gasket Set-Ref. No 1095.

**Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.**