

Item	Description	C4160V1	C5160V1	C5(3/5)60V1	C7*80V1
1	Compressor w/ Flywheel	PV02A	PT03A	PT03A	PV05A
2	Discharge Tube	TU-25-AL	TU-23-AL	TU-23-AL	TU-2634-1A
3	Pressure Gauge	PG200-2.5R	PG200-2.5R	PG200-2.5R	PG200-2.5R
4	Outlet Valve	BV1/2MF	BV1/2MF	BV1/2MF	BV3/4MF
5	Air Receiver	60V20X48BR-B	60V20X48BR-B	60V20X48BR-B	80VE20X63-B
6	Drain Cock	DC1/4	DC1/4	DC1/4	DC1/4
7	V-Belt	4L530	4L530	A48	A73 (2)
8	Belt Guard	BGC	BGC	BGC	BG80GAL
9	Motor - 1 Phase, 208/230V	EM05.0-36-10SPL	EM05.0-36-10	N/A	EM07.5-18-10
	- 3 Phase, 208/230-460V	N/A	N/A	EM05.0-36-30	EM07.5-18-30
	- 3 Phase, 575V	N/A	N/A	EM05.0-36-50	EM07.5-18-50
10	Wiring Harness	12/3-24-C4	12/3-24-C5	N/A	N/A
11	Check Valve	CTF1/2X1/2	CTF1/2X1/2	CTF1/2X1/2	P1010S-T
*12	Pressure Switch	21UCBDB	3BEHD	21UCBDB	21UCBDB
13	Pulley - Motor	MA38X5/8	MA38X7/8	MA38X11/8	2MAL82
	Hub or Bushing	N/A	N/A	N/A	LX13/8
14	Unloader Tube w/ Fittings	TU1/4BLK & 68-4A	TU1/4BLK & 68-4A	TU1/4BLK & 68-4A	TU-1/4-CU & 68-4A
15	Safety Valve	PSV1/4-150	PSV1/4-150	PSV1/4-150	PSV1/4-150
	Eagle Compressor Oil	EAOIL10	EAOIL10	EAOIL10	EAOIL10

* For C5360V1-CS2 (208-230V) substitute part #12 to CS-10/16A


* For C5360V1-CS4 or C5560V1-CS (460V or 575V) substitute part #12 to CS-6.3/10A

* For C7180V1-MS - add Magnetic Starter part # MS60981104 * For C7380V1-CS2 - substitute part #12 for CS-20/24A

* For C7380V1-CS4 - substitute part #12 for CS-10/16A * For C7580V1-CS - substitute part #12 for CS-6.3/10A

MODELS

C4160V1 C7180V1
 C5160V1 C7180V1-MS
 C5360V1 C7380V1-CS2
 C5360V1-CS2 C7380V1-CS4
 C5360V1-CS4 C7580V1
 C5560V1 C7580V1-CS
 C5560V1-CS



Call 1-800-551-2406 for
 Customer Service.

