
www.allpartsinc.com 1-269-685-4123 customerservice@allpartsinc.com

## **BLACK WIRE** from power supply connects to L2.

(Top terminal next to red On/Off lever)



These terminals are not used for the D26613 pressure switch application

**BLACK WIRE** from motor goes on T2.

(Bottom terminal)