

LED DIAGNOSTIC CODES

Steady ON Normal Operation, Power is On to the Control.

2 Flashes Lockout due to unsuccessful Ignition Trial(s)

3 Flashes Lockout from flame loss count exceeding the number specified Steady Flash Lockout from Flame being detected out of specified sequence

Customer Specified Variables

Prepurge Interval: 0 seconds Ignition Trial Interval: 30 seconds

Interpurge Interval: 5 seconds

of Ignition Trials: 1 # of Flame Losses: 3 Auto Lockout Reset: none

Note

A Lockout due to Flame Detected Out of Sequence (Steady LED Flashing) will not Auto Reset. To manually reset lockout interrupt power or open thermostat for 10 seconds, minimum.