

Installation Instructions for GTRC

- 1.) Disconnect the 2 wire harnesses from your old receiver.
- 2.) Unplug the red and black wires from the TPTH & TH terminals on the gas valve.
- 3.) Plug the black, 4 pin connector, removed from your old receiver, into the new harness connector labeled "MOTOR"
- 4.) Plug the Green wire from the new harness onto the TH terminal of the gas valve.
- 5.) Plug the White wire from the new harness onto the TPTH terminal of the gas valve.
- 6.) Plug the white harness connector labeled "RECEIVER" into the back of the new receiver.

WIRING DIAGRAM

Note: For proper operation of remote control, wires from thermopile to control receiver must be connected exactly as shown.

