

Eagle Air Compressor part breakdown - IHHP1065L

Item	Description	Part	Item	Description	Part
1	Head Bolt M6x55	IH30551	43	Bolt M5*15	IH1727
2	Spring washer 6	IH1211	44	Pressure switch	IH2025
3	Cylinder head	IH1343	45	Connector	IH1045
4	Exhaust elbow	IH1086A	46	Connector	IH0004
5	Gasket	IH1051	47	Pressure gauge	IH1177
6	Valve assembly		48	Connector	IH0003
7	Gasket	IH1053	49	Regulator	IH1952
8	Cylinder	IH2034B	50	Quick connect	IH0001T
9	Piston	IH2038B	51	Safety valve	IH1090
10	Piston air ring	IH2039M	52	Strain relief	IH2206
11	Piston oil ring	IH2039N	53	Power cord	IH1841
12	Piston pin clip	IH1420B	54	Terminal (O)	
13	Piston pin	IH1534B	55	Terminal (Y)	
14	Connecting rod	IH1066B	56	Drain valve	IH1850
15	Gasket	IH1225	57	Check valve	IH2026A
16	Bolt M8*25	IH2035	58	Handle	IH1527
17	Spring washer 8	IH1212	59	Exhaust pipe/w fitting	IH1169
18	Crankshaft	IH1068A	60	Nut	IH1169
19	Bolt M8*22-LH	IH1802	61	Tube w/fitting	IH1314
20	Crank case gasket	IH2019	62	Nut	IH1314
21	Crank case cover	IH2021	63	Bolt	IH3023
21a	Bolt M6*10	IH2207	64	Wheel	IH3024
22	Seal	IH1591	65	Nut	IH3026
23	Oil sight glass	IH1519	66	Bolt	IH2205
24	Bolt M6*18	IH0621	67	Custion foot	IH2200
25	Breather	IH1071	68	Washer	IH2202
26	Crank case	IH2020	69	Nut	IH2204
27	Oil seal	IH0530	70	Tank	IH3022
28	Bearing	IH0140	71	Overload protector	IH2000
29	Rotator	IH1919	72	Air filter	IH1072
30	Bearing	IH0150	6a	Valve Plate	IH1064
31	Stator	IH1918A	6b	Reed Valve	IH1052
32	Spring washer wave	IH2209	6c	Middle vlc gasket	IH1049
33	Rear cap	IH1046			
34	Spring washer 5	IH2210			
35	Bolt M5	IH1048			
36	Fan	IH1044			
37	Circlips	IH1101			
38	Capacitor	IH2250			
39	Washer 3	IH1039			
40	Spring washer 3	IH1040			
41	Bolt M3*6	IH1041			
42	Shroud	IH2024			


IRON HORSE

HORIZONTAL
PORTABLE



Wood
INDUSTRIES
INCORPORATED

IHHP1065L



Call 1-800-551-2406 for the Customer Service Department.