






LENNOX HEARTH PRODUCTS

Service Replacement Parts List

BBV-36RMN (66L36), BBV-36RMP (66L37), BBV-36REN (66L38)

LBASE - GAS FP

MODEL YEARS: 2005 - present

Items in italics are not available 6 months after end of model production.

Item	Part/Cat.No	Description	Qty.	Where Used
1	62L49	Log Set	1	All Models
2	75L83	Log Support	1	All Models
*	27M30	Glass Enclosure Panel Black	1	All Models
*	27M31	Glass Enclosure Panel Brass	1	All Models
3	H3675	Gas Burner	1	All Models
4	62L02	Burner Brass Fitting	1	All Models
5	93L32	Flex Gas Line with Shut-off	1	All Models
6	H3654	Front Lintel	1	All Models
7	See Burner	Grate	1	All Models
8	H3689	Air Shutter	1	All Models
9	H3688	Air Shutter Rod	1	All Models
10	62L16	Heat Limit Switch Kit	1	All Models
**	H0576	Refractory Kit	1	All Models
11	88L58	Refractory, Back	1	All Models
12	88L59	Refractory Left Side	1	All Models
13	88L59	Refractory Right Side	1	All Models
14	H3655	Refractory Base Left	1	All Models
15	H3657	Refractory Base Right	1	All Models
16	H3612	Damper Handle	1	All Models
17	H3702	Door Track	1	All Models
**	H3616	Damper Microswitch	1	All Models
**	H3616	Damper Spring Repair Kit	1	All Models
**	H4167	Screen, Pull	2	All Models
**	H3610	Screen Rod	2	All Models
**	6" B-Vent	Vent System		All Models
**	81L88	Outside Air Kit Less Duct	1	All Models
**	81L87	Outside Air Kit With Duct	1	All Models
**	H3656	Gas Control Inside Access Panel	1	All Models
**	80L42	Volcanic Stone	1	All Models
**	88L53	Embers	1	All Models
**	90L73	Touch Up Paint	1	All Models

Item	Part/Cat.No	Description	Qty.	Where Used
GAS CONTROLS - SIT MILLIVOLT				
18	H1658	Gas Valve NG SIT	1	BBV-36RMN
**	62L05	Gas Valve NG Honeywell	1	BBV-36RMN
**	H1659	Gas Valve LP SIT	1	BBV-36RMP
**	62L05	Gas Valve LP Honeywell	1	BBV-36RMP
19	10K86	Piezo Igniter SIT	1	BBV-36RMN, BBV-36RMP
**	56L21	Piezo Igniter wire	1	BBV-36RMN, BBV-36RMP
**	H3630	Piezo Igniter Bracket	1	BBV-36RMN, BBV-36RMP
20	H3229	Gas Train Assembly	1	BBV-36RMN
20	H3230	Gas Train Assembly	1	BBV-36RMP
21	21L63	Gas Valve Brass Fitting	1	BBV-36RMN, BBV-36RMP
22	H3627	Gas Line Valve to Burner	1	BBV-36RMN, BBV-36RMP
23	62L12	Pilot Assy SIT	1	BBV-36RMN
23	62L13	Pilot Assy SIT	1	BBV-36RMP
**	62L12	Pilot Assy Honeywell	1	BBV-36RMN
24	74L56	Pilot Tube w/ Fitting SIT	1	BBV-36RMN, BBV-36RMP
25	H3625	Valve Support Bracket	1	BBV-36RMN, BBV-36RMP
26	H3721	Burner Orifice	1	BBV-36RMN
26	67L28	Burner Orifice	1	BBV-36RMP
**	H3659	Burner Orifice Bracket	1	BBV-36RMN, BBV-36RMP
**	H2017	Gas Conversion NG to LP SIT	1	BBV-36RMN
**	75L01	Gas Conversion NG to LP Honeywell	1	BBV-36RMN
**	H2018	Gas Conversion LP to NG SIT	1	BBV-36RMP
**	75L02	Gas Conversion LP to NG Honeywell	1	BBV-36RMP
27	60J79	Thermopile	1	BBV-36RMN, BBV-36RMP
**	74L58	Igniter Electrode & Cable SIT	1	BBV-36RMN, BBV-36RMP
**	H5047	Ignition Cable	1	BBV-36RMN, BBV-36RMP
**	H3942	Thermostat Wire Assembly	1	BBV-36RMN, BBV-36RMP
Item	Part/Cat.No	Description	Qty.	Where Used
GAS CONTROLS - HONEYWELL ELECTRONIC				
28	H3661	Gas Train Assembly	1	BBV-36REN
29	62L07	Gas Valve Brass Fitting	1	BBV-36REN
30	H3658	Valve Support Bracket	1	BBV-36REN
31	62L18	Gas Valve NG Honeywell	1	BBV-36REN
31	62L19	Gas Valve LP Honeywell	1	BBV-36REN
32	H3721	Burner Orifice	1	BBV-36REN
**	H3660	Burner Orifice Bracket	1	BBV-36REN
33	62L14	Pilot Assy Honeywell	1	BBV-36REN
34	H3663	Gas Line Valve to Burner	1	BBV-36REN
35	H3662	Pilot Tube w/ Fitting SIT	1	BBV-36REN
**	75L03	Gas Conversion NG to LP SIT	1	BBV-36REN
**	75L04	Gas Conversion LP to NG SIT	1	BBV-36REN
**	42J32	Transformer 110V to 24V	1	BBV-36REN
**	74L21	110V Wire Lead to Transformer	1	BBV-36REN
**	H3942	Thermostat Wire Assembly	1	BBV-36REN