


ACSL530RVP



L530RVP

Key No.	Part Number	Description
1	D23574	BOLT SHOULDER
2	D23067	WHEEL PNEUMATIC 10" OD
3	SSN-631	WASHER BELLEVILLE
4	SSF-8080-ZN	NUT HEX 3/8-16UNC-2B
5	AC-0699	TOOL BASKET
6	SSP-554	PLUG PIPE, 1/2 - 14 NPT
7	AC-0764	MANIFOLD, 2"NPT ALUMINUM
8	TIA-4150	VALVE SAFETY
9	H-2099	ADAPTER, 1/4NPT X 1/4 NPSM
10	SSP-551	FITTING, 1/4 TO 1/4 NPT SW
11	SS-1215	PLUG PIPE, 1/8
12	AC-0698	REGULATOR
13	SSP-550	FITTING, 1/4 TO 1/8 NPT
14	GA-360-B	GAUGE
15	SSF-634	SCREW, 5/16 - 18 X 2 HEX
16	SSF-8150	NUT HEX WIZ LOCK LG FLANGE
17	CAC-4205	CORD ASSEMBLY
18	SUDL-9-1	SCREW, 8-32X.375/.344
19	MO-3021-1	MOTOR
20	SSF-3121-ZN	SCREW, 5/16-18X1 3/4 WHIZ
21	SSW-8241	SPACER, 1 OD X.328ID
22	SSP-543	NIPPLE, 1/4 X 4
23	CAC-1279	REDUCER BUSHING
24	AC-0700	PRESSURE RELIEF TUBE
25	SSP-7811	NUT SLEEVE ASSEMBLY 1/4
26	SS-8553	CONNECTOR BODY
27	CAC-4337-1	VALVE CHECK, NPT - 1/2
28	AC-0693	SWITCH PRESSURE
29	SSP-7812	NUT SLEEVE ASSEMBLY 1/2
30	AC-0556	PRESSURE SWITCH COVER
31	91895680	SCREW, 1/4 - 20 X .75
32	AC-0694	OUTLET TUBE
33	DAC-225	CONNECTOR MALE 1/2 OD
34	SSF-569	NUT HEX, 1/4-20
35	SSF-953-ZN	SCREW SELF TAPPING, 10X5/8
36	AC-0467	BRACKET BELTGUARD
37	CAC-1392	STRAIN RELIEF
38	SSF-556	SCREW, #10 - 32x1 HEX HEAD
39	SUDL-413-2	POWER CORD ASSEMBLY
40	*BAL-T16	PUMP ASSEMBLY
41	SSF-3159	SCREW, 3/8-16X2 HEX WASHER
42	AC-0697	HANDLE
43	SSF-646	SCREW, M8 X 1.25 X 18
44	AC-0710	ADAPTER
45	AC-0712	GASKET INLET
46	AC-0485	BRACKET BELTGUARD
47	AC-0433	GUARD BELT, INSIDE
48	BT-319	BELT V A56
49	SSN-1014-ZN	WASHER .339/.344 ID 1 1/2
50	PU-2909	PULLEY A SECT V-BELT 2.8
51	AC-0713	FINGER GUARD
52	SSF-8131	NUT SPEED, 8AB "U" TYPE
53	AC-0434	GUARD BELT, OUTSIDE
54	AC-0711	RETAINER
55	SST-107	RUBBER FEET
56	SSF-630	SCREW
57	AC-0696	INTAKE FILTER
58	SSP-555	NIPPLE

****See the Pumps Tab.***