



BSI550



KEY

NO.	PART NUMBER	DESCRIPTION
1	91895680	SCREW 1/4 - 20 X .75
2	SSN-632	WASHER .875 OD .375 ID .0
4	Z-D23670	ASSY FRAME GENERATOR
6	Z-GS-0795	TANK FUEL 7G
7	-----	ENGINE 10HP B&S INTEK (B&S # 205412-0130-E1
8	-----	ASSY GENERATOR -see individual parts
9	GS-0118	STRAP GROUND
10	SSF-605	SCREW .313-18X1.25 HEX CA
11	GS-0433	ISOLATOR
12	SSN-1619-ZN	WASHER LOCK EXTERNAL TOOTH
13	SS-12-CD	SCREW .313-18X.750 HEX
14	GS-0117	LUG GROUND
15	GS-0033	ISOLATOR VIBRATION 1.5OD
16	D22311	SCREW .313-18X.875 UNC
18	SSF-553-1	SCREW #10-24X.563
19	GS-0077	COVER END
20	GS-0437	DRAIN COCK
21	GS-0227	CLAMP FUEL .50
22	GS-0446	GROMMET DRAIN COCK
24	GS-0863	CAP FUEL W/GAUGE
25	GS-0199	BUSHING SNAP 1" OD
38	D24363	GASKET MANIFOLD B&S
39	D24362	SCREW .312-18 TORX SOCKET

BSI550 (con't)




KEY

<u>NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	91895680	SCREW 1/4 - 20 X .75
10	SSF-605	SCREW .313-18X1.25 HEX CA
27	-----	ASSY PANEL -see individual parts
29	D23686	MUFFLER ENGINE B&S 10HP I
30	SSF-8150	NUT .312-18 UNC HEX FLANGE
31	Z-GS-0225	HOSE FUEL
33	SSF-621	SCREW .250-20X.625 HHW SE

BSI550 (con't)


D23403 Generator Assembly



KEY NO.	PART NUMBER	DESCRIPTION
1	GS-0076	ADAPTOR DRIVE END
2	SSN-619	WASHER 3/8 SPLIT LOCK
3	SSF-577	SCREW 3/8" - 16X1 HHS CAP
4	Z-GS-0883	ASSY ROTOR
5	GS-0110	BOLT STATOR THRU
6	Z-D23404	ASSY STATOR
7	SS-6506-CD	WASHER FLAT 11/16 OD X 11
8	SSF-576	NUT 5/16-24 HEX W/KEPS
9	GS-0419-1	BOLT ROTOR THRU
10	Z-GS-0861	BEARING SUPPORT O RING
12	SSF-575	NUT 1/4"-20 HEX W/KEPS
13	GS-0748	CAPACITOR
16	GS-0595	BRACKET CAPACITOR
17	SSF-553-1	SCREW 10-24 X 9/16
21	GS-0862	O-RING ROTOR BEARING

BSI550 (con't)

D23920 Panel Assembly



KEY

<u>NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	D23680	PANEL CONTROL BSI550
2	SSF-583	SCREW #6-32X.500 PAN HD T
3	SSF-584	NUT #6-32 SPEED
4	Z-D20573	BREAKER CIRCUIT 125/250V 25A
6	SSF-595	NUT .438-28 HEX JAM
7	GS-0598	COVER PANEL
8	SSF-3156	SCREW #10-9X.500 THREAD FORM
9	GS-0605	PANEL WIRE HARNESS
10	GS-0455	RECEPTACLE, 4 PRONG 30A
11	GS-0019	RECEPTACLE, 120V 20A DUPLEX

Not Shown

D23665	OPERATORS MANUAL
D23664	PARTS MANUAL
D23909	ENGINE MANUAL