


CH350CS-2



KEY


NO.	Part Number	DESCRIPTION
1	-----	ENGINE (model GX2000VGG2)
2	*Z-D26593	GENERATOR ASSEMBLY
3	GS-0077	COVER END BLANK
4	GS-0117	LUG GROUND
5	GS-0118	STRAP GROUND
6	Z-D26731	ASSEMBLY FRAME
7	GS-0033	ISOLATOR VIBRATION 1.5OD
14	SSN-632	WASHER .875 OD .375 ID .0
15	SSF-8150	NUT HEX WIZ LOCK LG FLANG
17	SS-12-CD	SCREW CAP 5/16-18 X 3/4
18	SSF-605	SCREW HEX CAP 5/16-18 X 1
19	SSF-553-1	SCREW 10-24 X 9/16
20	SSN-1619-ZN	WASHER LOCK EXTERNAL TOOT
22	Z-GS-0650-1	TANK FUEL 4 GAL
23	GS-0443	CAP FUEL TANK
25	GS-0227	FUEL CLAMP
26	91895680	SCREW 1/4 - 20 X .75
27	GS-0446	GROMMET DRAIN COCK
28	GS-0437	FUEL SHUTOFF VALVE

KEY

NO.	Part Number	DESCRIPTION
29	D20885	BRACKET GX200 IC SOLENOID
30	D20886	SOLENOID GX200 IC
32	D26696	ASSY PANEL
33	SSN-626	WASHER LOCKING #10
34	SSF-1001-1	SCREW 10-32
36	D21337	BOLT 1/4-20X1.25 UNC HEX
40	GS-0560	HOSE CLAMP
41	SSN-1014-ZN	WASHER .339/.344 ID 1 1/2
42	SSF-549	SCREW 5/16-18X.50 HEX WIZ
49	SSF-575	NUT 1/4"-20 HEX W/KEPS
50	GS-0763	CLIP SNAP-IN FUEL LINE
51	SS-6506-CD	WASHER, 1/4"
52	D21355	PIN ROLL .094 DIA X .75
55	GS-0925	SPACER .32ID X 1.50OD X.2
56	D22681	BAR SPREADER
57	SSF-3152	SCREW 5/16-18X3/4
58	GS-0816-1	SHIELD HEAT


* order complete generator assembly, individual parts not available.

CH350CS-2 (cont'd)



KEY NO.	Part Number	DESCRIPTION
16	Z-GS-0225	HOSE FUEL
24	Z-GS-0225	HOSE FUEL
25	GS-0227	CLAMP FUEL .50
31	D20888	WIRE FORM
36	D21337	BOLT 1/4-20X1.25 UNC HEX
40	GS-0560	CLAMP HOSE .301 ID
44	GS-0199	BUSHING SNAP 1" OD
46	GS-0459	FILTER FUEL
47	SSP-510	CLIP FUEL LINE TUBE
48	GS-0535	UNION REDUCER 1/4 X 3/8
49	SSF-575	NUT 1/4"-20 HEX W/KEPS
61	D21999	ASSY, FUEL LINE

CH350CS-2 (cont'd)



KEY NO.

PART NUMBER

DESCRIPTION

1	D20863	PANEL CONTROL
2	D26376	COVER PANEL
3	SSF-3156	SCREW 10-9X.50 PLASTITE
4	SSF-583	SCREW #6-32 x .5 TORX
5	SSF-584	NUT SPEED #6-32
6	D26362	ASSEMBLY WIRE PANEL
7	GS-0735	HOUR METER
9	GS-0663	ASSEMBLY BOARD CIRCUIT IDLE
10	SSF-595	NUT HEX JAM 7/16
11	GS-0728	ASSEMBLY BINDING POST
13	GS-0835	ASSEMBLY RESISTOR
14	GS-0019	RECEPTACLE 120V 20A DUPL
15	GS-0445	RECEPTACLE 4 PRONG TWIST
16	GS-0045	SWITCH FULL POWER
17	GS-0679	SWITCH IDLE CONTROL
18	Z-GS-0024	BREAKER CIRCUIT 125/250V 15 AMP
19	GS-0681	BREAKER CIRCUIT 125/250V 10 AMP

Not Shown

D26799	OPERATORS MANUAL
D26823	PARTS MANUAL
D20868	ENGINE MANUAL