


# CH350IS-1



## KEY


| NO. | Part Number | DESCRIPTION               |
|-----|-------------|---------------------------|
| 1   | -----       | ENGINE (model GX2000VGG2) |
| 2   | *Z-D26593   | GENERATOR ASSEMBLY        |
| 3   | GS-0077     | COVER END BLANK           |
| 4   | GS-0117     | LUG GROUND                |
| 5   | GS-0118     | STRAP GROUND              |
| 6   | Z-D28433    | ASSEMBLY FRAME            |
| 7   | GS-0033     | ISOLATOR VIBRATION 1.5OD  |
| 14  | SSN-632     | WASHER .875 OD .375 ID .0 |
| 15  | SSF-8150    | NUT HEX WIZ LOCK LG FLANG |
| 17  | D22311      | SCREW CAP 5/16-18 X .875  |
| 18  | SSF-605     | SCREW HEX CAP 5/16-18 X 1 |
| 19  | SSF-553-1   | SCREW 10-24 X 9/16        |
| 20  | SSN-1619-ZN | WASHER LOCK EXTERNAL TOOT |
| 22  | Z-GS-0650-1 | TANK FUEL 4 GAL           |
| 23  | GS-0443     | CAP FUEL TANK             |
| 25  | GS-0227     | FUEL CLAMP                |
| 26  | 91895680    | SCREW 1/4 - 20 X .75      |
| 27  | GS-0446     | GROMMET DRAIN COCK        |
| 28  | GS-0437     | FUEL SHUTOFF VALVE        |

## KEY

| NO. | Part Number | DESCRIPTION               |
|-----|-------------|---------------------------|
| 29  | D30141      | BRACKET GX200 IC SOLENOID |
| 30  | D20886      | SOLENOID GX200 IC         |
| 32  | D29859      | ASSY PANEL                |
| 33  | SSN-626     | WASHER LOCKING #10        |
| 34  | SSF-1001-1  | SCREW 10-32               |
| 36  | D21337      | BOLT 1/4-20X1.25 UNC HEX  |
| 40  | GS-0560     | HOSE CLAMP                |
| 41  | SSN-1014-ZN | WASHER .339/.344 ID 1 1/2 |
| 42  | SSF-549     | SCREW 5/16-18X.50 HEX WIZ |
| 49  | SSF-575     | NUT 1/4"-20 HEX W/KEPS    |
| 50  | GS-0763     | CLIP SNAP-IN FUEL LINE    |
| 51  | SS-6506-CD  | WASHER, 1/4"              |
| 52  | D21355      | PIN ROLL .094 DIA X .75   |
| 55  | GS-0925     | SPACER .32ID X 1.50OD X.2 |
| 56  | D22681      | BAR SPREADER              |
| 57  | SSF-3152    | SCREW 5/16-18X3/4         |
| 58  | D30142      | SHIELD HEAT               |


\* order complete generator assembly, individual parts not available.

## CH350IS-1-1 (cont'd)



| KEY NO. | Part Number | DESCRIPTION               |
|---------|-------------|---------------------------|
| 16      | Z-GS-0225   | HOSE FUEL                 |
| 24      | Z-GS-0225   | HOSE FUEL                 |
| 25      | GS-0227     | CLAMP FUEL .50            |
| 31      | D20888      | WIRE FORM                 |
| 36      | D21337      | BOLT 1/4"-20X1.25 UNC HEX |
| 40      | GS-0560     | CLAMP HOSE .301 ID        |
| 44      | GS-0199     | BUSHING SNAP 1" OD        |
| 46      | GS-0459     | FILTER FUEL               |
| 47      | SSP-510     | CLIP FUEL LINE TUBE       |
| 48      | GS-0535     | UNION REDUCER 1/4 X 3/8   |
| 49      | SSF-575     | NUT 1/4"-20 HEX W/KEPS    |

## CH350IS-1 (cont'd)



### KEY NO.

### PART NUMBER

### DESCRIPTION

|      |           |                                 |
|------|-----------|---------------------------------|
| 1    | D29860    | PANEL CONTROL                   |
| 2    | D26376    | COVER PANEL                     |
| 3    | SSF-3156  | SCREW #10-9X.500                |
| 4    | SSF-583   | SCREW #6-32X.500 PAN HEAD       |
| 5    | SSF-584   | NUT #6-32 SPEED SELF            |
| 6    | D29862    | ASSY WIRE HARNESS               |
| 6-1  | GS-0644   | RECEPTACLE 120V GFCI            |
| 6-3  | GS-0445   | RECEPTACLE 4 PRONG TWIST        |
| 6-9  | Z-GS-0024 | BREAKER CIRCUIT 125/250V 15 AMP |
| 6-10 | GS-0681   | BREAKER CIRCUIT 125/250V 10 AMP |
| 7    | GS-0735   | METER HOUR                      |
| 8    | D26377    | CLAMP MOLDED STRAIN RELIEF      |
| 9    | GS-0663   | ASSY BOARD CIRCUIT IDLE CONTROL |
| 10   | SSF-595   | NUT .438-28 UNEF HEX JAM        |
| 11   | GS-0728   | ASSY BINDING POST               |
| 13   | GS-0835   | ASSY RESISTOR DC SHUNT          |
| 14   | D27808    | SWITCH FULL POWER               |
| 15   | D27260    | SWITCH IDLE CONTROL             |

### Not Shown

|        |                  |
|--------|------------------|
| D29851 | OPERATORS MANUAL |
| D29850 | PARTS MANUAL     |
| D20868 | ENGINE MANUAL    |