





Ref. No.	Part No.	Description	Qty
1	5140187-57	Shroud Left	1
2	5140187-58	Shroud Right	1
3	5140153-35	Screw	5
4	5140156-25	Bolt	2
5	5140186-91	Screw	4
6	5140235-30	Pump/Motor Assy.	1
7	5140119-17	Nut	2
8	5140187-60	Transfer Tube	1
9	5140119-21	Valve	1
10	5140119-20	Elbow	1
11	5140187-61	Grommet	3
12a	5140187-62	Wheel	2
12b	5140119-11	Hub Cap	2
12c	5140119-06	Pad Vibration	2
12d	5140119-07	Bushing	1
12e	5140119-09	Valve	1
12f	5140119-12	Pipe Plug	1
12g	5140119-05	Handle Grip	1
12h	5140119-08	O-Ring	2
13	5140119-13	Warning Label	1
14	5140119-14	Warning Label	1
15	5140156-26	Nipple	1
16	5140119-56	Pressure Switch	1
17	5140119-19	Tube	1
20	5140187-63	Shoulder Bolt	3
21	5140119-61	Splash Coupler	1
22	5140172-21	Regulator	1
23	5140119-59	Gauge	1
24	5140187-64	Strain Relief	1
25	5140187-65	Screw	1
26	5170047-09	Pressure Gauge	1
27	5140153-98	Nipple	1
28	5140119-54	Valve	1
29	5140119-60	Bleeder Valve	1
30	5140177-69	Nut	2
31	5140153-34	Washer	2
32	5140235-31	Screw	2
33	5140176-45	Washer	2



Ref. No.	Part No.	Description	Qty
101	5140187-08	Filter	1
102	5140187-09	Intake	1
103	5140187-10	Screw	4
104	5140187-11	Head	1
105	5140187-12	Gasket	1
106	5140187-13	Valve Plate Assy.	1
107	5140187-14	O-Ring	1
110	5140206-87	Screw	1
111	5140187-17	Crankshaft Kit	1
114	5140187-19	Piston/Cylinder Kit	1
116	5140187-21	Plastic Fan	1
117	5140187-22	Washer	1
118	5140187-23	Screw	1
119	5140187-67	Start Capacitor	1
121	5140187-68	Run Capacitor	1
122	5140121-35	Cover	1
123	5140187-15	Filter Screen	1
124	5140187-69	Grommet	1