




GBVE7500-WK



KEY NO.	PART NUMBER	DESCRIPTION
1	Z-GS-0795	TANK FUEL
4	Z-GS-0225	HOSE FUEL
7	-----	ASSY GENERATOR (see individual parts)
8	D24275	COVER ENGINE
9	95829230	SCREW .313-18X1.50 HEX
10	GS-0118	STRAP GROUND
11	GS-0033	ISOLATOR VIBRATION
12	SSF-8150	NUT .312-18 UNC HEX FLANG
13	SSN-1619-ZN	WASHER LOCK EXTERNAL TOOTH
14	SS-12-CD	SCREW .313-18X.750 HEX
16	-----	ENGINE B&S #245437-0559-E1
17	GS-0117	LUG GROUND
18	GS-0492	SPACER 5/16
20	D24273	SHIELD HEAT


KEY NO.	PART NUMBER	DESCRIPTION
21	SSF-553-1	SCREW #10-24X.563 THD
23	SSN-632	WASHER .875 OD .375 ID
24	91895680	SCREW .250-20X.750
25	GS-0863	CAP FUEL W/GAUGE
26	SSF-641-ZN	SCREW M6X1X12 HHW THD FRM
29	Z-D26961	ASSY FRAME
31	GS-0227	CLAMP FUEL .50
33	D26431	ASSY PANEL
34	GS-0446	GROMMET DRAIN COCK
35	GS-0437	DRAIN COCK
39	SSN-60-ZN	WASHER STEEL TYPE A
40	SSF-549	SCREW .313-18X.50 HEX CAP
44	D24393	BAR SPREADER BSV750

GBVE7500-WK



KEY NO.	PART NUMBER	DESCRIPTION
2	GS-0199	BUSHING SNAP
3	D25928	ASSY WIRE HARNESS
22	GS-0077	COVER END
46	SSF-575	NUT .250-20 HEX W/KEPS
47	D20540	ASSY CABLE SELENOID TO STARTER


GBVE7500-WK



KEY

NO.	PART NUMBER	DESCRIPTION
1	GS-0076	ADAPTOR DRIVE END
2	SSN-619	WASHER .375 SPRING LOCK
3	SSF-577	SCREW .375-16X1.00 HEX
4	Z-D24137	ASSY ROTOR
5	GS-0273	BOLT STATOR THRU
6	Z-D24138	ASSY STATOR
7	SS-6506-CD	WASHER FLAT 11/16 OD X 11
8	SSF-576	NUT .313-24 HEX W/KEPS
9	GS-0315-1	BOLT ROTOR THRU
10	Z-GS-0861	BEARING SUPPORT O RING
11	SSF-3158-1	SCREW #10-24X.750 THD ROL
12	SSF-575	NUT .250-20 HEX W/KEPS
13	GS-0748	CAPACITOR
16	GS-0595	BRACKET CAPACITOR
17	SSF-553-1	SCREW #10-24X.563
18	GS-0767	RECTIFIER
21	GS-0862	O-RING ROTOR BEARING

GBVE7500-WK



KEY

NO.	PART NUMBER	DESCRIPTION
1	D24144	PANEL CONTROL
2	D26112	COVER PANEL
3	SSF-3156	SCREW #10-9X.500 THD FORM
4	SSF-583	SCREW #6-32X.500 PAN HD
5	SSF-584	NUT #6-32 SPEED SELF RET
6	D26928	ASSY WIRE PANEL
6-1	GS-0644	RECEP GFCI 120V 20A
6-2	GS-0021	RECEPTACLE 125V 30A SINGL
6-3	GS-0455	RECEPTACLE 4 PRONG 30A
6-4	GS-0679	SWITCH IDLE CONTROL
6-5	GS-0046	SWITCH OFF - ON / START
6-9	Z-GS-0026	CIRCUIT BREAKER 125/250V
6-10	Z-GS-0025	CIRCUIT BREAKER 125/250V
6-11	Z-GS-0681	BREAKER CIRCUIT 125/250V
7	GS-0663	ASSY BOARD CIRCUIT IDLE
8	SSF-595	NUT .438-28 UNEF HEX JAM
9	GS-0728	ASSY BINDING POST
10	GS-0835	ASSY RESISTOR DC SHUNT
11	D26113	CLAMP MOLDED STRESS RELIEF

Not Shown

D26563	OPERATORS MANUAL
D26959	PARTS MANUAL
D24128	ENGINE MANUAL