



←FR.

Ref #	Part Number	Qty	Description
1	15721-ZM1-000	1	TUBE, BREATHER (Honda Code 5720289).
2	17211-ZL8-000	1	SEE PART DETAILS - SUP; ELEMENT, AIR CLEANER Use up to Engine SN 1622339. (Honda Code 5580402).
2	17211-ZL8-003	1	SEE PART DETAILS - PRI; ELEMENT, AIR CLEANER (Honda Code 6718159).
3	17220-ZM0-000	1	CASE ASSY., AIR CLEANER (Honda Code 5580410).
5	17228-ZM0-000	1	GASKET, AIR CLEANER (Honda Code 5664560).
6	17231-ZM0-000	1	SEE PART DETAILS - SUP; COVER, AIR CLEANER Use up to Engine SN 1623839. (Honda Code 5580444).
6	17231-ZM0-020	1	COVER, AIR CLEANER Use from Engine SN 1623840. (Honda Code 7450901).
6	17231-Z0L-000	1	SEE PART DETAILS - SUP; COVER, AIR CLEANER Use up to Engine SN 1623839. (Honda Code 6673255).
6	17231-Z0L-020	1	SEE PART DETAILS - PRI; COVER, AIR CLEANER (Honda Code 7399397).
7	90003-ZM0-000	2	BOLT, FLANGE (6X86) (CT200) (Honda Code 5580964).
8	95701-06014-08	1	SEE PART DETAILS - PRI; BOLT, FLANGE (6X14) (Honda Code 2374742).



ZM00-E1000A


Ref #	Part Number	Qty	Description
1	14320-ZL8-000	1	SEE PART DETAILS - SUP; PULLEY, CAMSHAFT (Honda Code 5580055).
1	14320-ZL8-010	1	SEE PART DETAILS - PRI; PULLEY, CAMSHAFT (Honda Code 7049679).
2	14324-ZL8-000	1	SHAFT, CAM PULLEY (Honda Code 5580063).
3	14400-ZL9-003	1	SEE PART DETAILS - SUP; BELT, TIMING (79HU7 G-200) (Honda Code 5720271).
3	14400-ZL9-013	1	SEE PART DETAILS - PRI; BELT, TIMING (79HU7 G-200) (Honda Code 7050727).
4	14431-ZL8-000	1	ARM, IN. VALVE ROCKER (Honda Code 5580089).
5	14441-ZL8-000	1	ARM, EX. VALVE ROCKER (Honda Code 5580097).
6	14461-ZL8-000	2	SHAFT, ROCKER ARM (Honda Code 5580105).
7	14711-ZL8-000	1	VALVE, IN. (Honda Code 5580113).
8	14721-ZL8-000	1	VALVE, EX. (Honda Code 5580121).
9	14751-ZL8-000	2	SPRING, VALVE (Honda Code 5580139).
10	14771-ZE1-000	2	SEE PART DETAILS - PRI; RETAINER, IN. VALVE SPRING (Honda Code 1426980).
11	90012-333-000	2	SCREW, TAPPET ADJ. (Honda Code 0294819).
12	90206-001-000	2	NUT, TAPPET ADJ. (Honda Code 0004598).
13	91301-ZM0-V31	1	O-RING (6.8X1.9) (Honda Code 6315873).
14	12209-ZM0-003	1	SEAL, VALVE STEM Use from Engine SN 1623460. (Honda Code 6839831).



FR. ←

ZM00-E1400B


Ref #	Part Number	Qty	Description
1	16010-883-015	1	SEE PART DETAILS - PRI; GASKET SET (Honda Code 3088416).
2	16013-ZL1-003	1	FLOAT SET (Honda Code 5580162).
3	16015-887-782	1	SEE PART DETAILS - PRI; CHAMBER SET, FLOAT (Honda Code 3465879).
4	16016-ZG0-W00	1	SCREW SET (Honda Code 4481818).
5	16028-ZE0-005	1	SEE PART DETAILS - PRI; SCREW SET B (Honda Code 1441518).
6	16029-ZG0-901	1	SCREW SET (Honda Code 5580170).
7	16100-ZM1-822	1	SEE PART DETAILS - PRI; CARBURETOR ASSY. (BB64F A) (Honda Code 6529168).
8	16155-ZM0-003	1	VALVE, FLOAT (Honda Code 5580212).
9	16166-ZM1-003	1	NOZZLE, MAIN (Honda Code 5723150).
10	16211-ZL8-000	1	INSULATOR, CARBURETOR (Honda Code 5580238).
11	16212-ZL8-000	1	GASKET, INSULATOR (Honda Code 5580246).
12	16221-883-800	2	SEE PART DETAILS - PRI; GASKET, CARBURETOR (Honda Code 4581120).
13	16228-ZL8-000	1	GASKET, CARBURETOR (CHOKE SIDE) (Honda Code 5580253).
14	19650-ZM0-000	1	GUIDE, AIR (Honda Code 5580535).
15	93500-05006-0H	1	SEE PART DETAILS - PRI; SCREW, PAN (5X6) (Honda Code 0639419).
16	99101-124-0550	1	JET, MAIN (#55) (Optional). Use up to Engine SN BB64B C. (Honda Code 0635458).
16	99101-124-0580	1	JET, MAIN (#58) (Optional). Use up to Engine SN BB64B C. (Honda Code 0635466).
16	99101-124-0580	1	JET, MAIN (#58) (Optional). Use from Engine SN BB64F A. (Honda Code 0635466).
16	99101-124-0600	1	JET, MAIN (#60) Use up to Engine SN BB64B C. (Honda Code 0635474).
16	99101-124-0600	1	JET, MAIN (#60) (Optional). Use from Engine SN BB64F A. (Honda Code 0635474).
16	99101-124-0620	1	JET, MAIN (#62) Use from Engine SN BB64F A. (Honda Code 0635482).
17	16024-ZE1-811	1	SCREW SET, DRAIN (Honda Code 1672187).




FR.

ZM00-E2201B


Ref #	Part Number	Qty	Description
1	16551-ZM0-010	1	SEE PART DETAILS - PRI; ARM, GOVERNOR (Honda Code 6869630).
2	16555-ZM1-000	1	ROD, GOVERNOR (Honda Code 5720305).
3	16561-ZM1-V30	1	SPRING, GOVERNOR (Honda Code 6315733).
4	16562-ZM1-000	1	SPRING, THROTTLE RETURN (Honda Code 5720321).
5	16574-ZE1-000	1	SPRING, LEVER (Honda Code 1427384).
6	16575-ZE2-W00	1	WASHER, CONTROL LEVER (Honda Code 3678679).
7	16577-ZM0-V30	1	PLATE, LEVER CENTER (Honda Code 6315741).
8	16578-ZE1-000	1	SPACER, CONTROL LEVER (Honda Code 1427400).
9	16580-ZM0-V30	1	BASE, CONTROL (Honda Code 6315758).
10	16612-ZM0-V30	1	LEVER, CHOKE (Honda Code 6315766).
11	16674-ZM0-V30	1	ROD, CHOKE (Honda Code 6315774).
12	17272-ZC3-300	1	COLLAR, IN. JOINT (Honda Code 2730919).
13	35120-ZL8-003	1	SWITCH ASSY., ENGINE STOP (N.O) (Honda Code 5611520).
14	87532-ZM0-V30	1	MARK, THROTTLE INDICATION (Honda Code 6315832).
15	90015-ZE5-010	1	SEE PART DETAILS - PRI; BOLT, GOVERNOR ARM (Honda Code 2418671).
16	90016-ZE8-000	1	BOLT, FLANGE (6X45) (Honda Code 2488187).
17	90016-ZM0-V30	1	BOLT, SPECIAL (6X45) (Honda Code 6315840).
18	90114-SA0-000	1	NUT, SELF-LOCK (6MM) (Honda Code 1410182).
19	90136-SM4-901	1	NUT, SELF-LOCK (5MM) (Honda Code 3596095).
20	93892-04012-00	1	SEE PART DETAILS - PRI; SCREW-WASHER (4X12) (Honda Code 0485946).
21	94050-06000	1	SEE PART DETAILS - PRI; NUT, FLANGE (6MM) (Honda Code 0471623).
22	94103-04000	1	WASHER, PLAIN (4MM) (Honda Code 1510361).




Ref #	Part Number	Qty	Description
2	13310-ZM1-600	1	CRANKSHAFT (Honda Code 5720263).
5	90402-ZL8-000	1	WASHER, THRUST (Honda Code 5581012).




Ref #	Part Number	Qty	Description
1	12000-ZL9-415	1	SEE PART DETAILS - PRI; CYLINDER ASSY. (010) (Honda Code 6842421).
3	12311-ZL8-000	1	COVER, HEAD (Honda Code 5579990).
4	12355-ZL8-000	1	COVER, BREATHER (BREATHER VALVE ASSY.) (Honda Code 5580006).
5	90013-883-000	4	SEE PART DETAILS - PRI; BOLT, FLANGE (6X12) (CT200) (Honda Code 0636845).
6	90014-952-000	1	BOLT, FLANGE (6X14) (Honda Code 0803619).
7	91201-ZL8-003	1	OIL SEAL (25.4X62X6) (Honda Code 5581038).
8	98079-56846	1	SEE PART DETAILS - PRI; SPARK PLUG (BPR6ES) (NGK) (Honda Code 1441112).




Ref #	Part Number	Qty	Description
1	16854-ZH8-000	1	SEE PART DETAILS - PRI; RUBBER, SUPPORTER (107MM) (Honda Code 3683646).
2	16950-ZG9-M03	1	PETCOCK ASSY. Use up to Engine SN 1623712. (Honda Code 7357379).
3	16956-ZM0-000	1	BRACKET, PETCOCK Use up to Engine SN 1623712. (Honda Code 5580394).
4	17620-ZL8-003	1	SEE PART DETAILS - SUP; CAP ASSY., FUEL TANK Use up to Engine SN 1622109. (Honda Code 5580451).
4	17620-ZL8-013	1	SEE PART DETAILS - PRI; CAP ASSY., FUEL TANK (Honda Code 6673289).
5	17702-ZM0-000	1	TUBE, FUEL Use up to Engine SN 1623712. (Honda Code 5580469).
6	19610-ZM1-010ZA	1	COVER, FAN *NH1* (BLACK) (Honda Code 6186373).
8	33609-GK4-620	1	COLLAR, FR. TURN SIGNAL (Honda Code 2499440).
9	90041-ZL9-000	3	BOLT, STUD (FAN/C) (Honda Code 5720446).
10	93891-05010-08	1	SCREW-WASHER (5X10) (Honda Code 0671636).
11	95001-55008-60M	1	SEE PART DETAILS - PRI; BULK HOSE, FUEL (5.5X8000) (5.5X135) (Honda Code 4260352).
12	95002-02080	1	CLIP, TUBE (B8) (Honda Code 0250647).
13	95002-02100	2	SEE PART DETAILS - PRI; CLIP, TUBE (B10) (Honda Code 0250985).
14	95002-50000	1	SEE PART DETAILS - PRI; CLIP, TUBE (C9) Use up to Engine SN 1623712. (Honda Code 0053447).
31	16950-ZM0-003	1	PETCOCK ASSY. Use from Engine SN 1623713. (Honda Code 7425770).
32	17702-ZM0-800	1	TUBE, FUEL Use from Engine SN 1623713. (Honda Code 7425804).
33	95002-02080	1	CLIP, TUBE (B8) Use from Engine SN 1623713. (Honda Code 0250647).



Ref #	Part Number	Qty	Description
1	13331-357-000	1	KEY, SPECIAL WOODRUFF (25X18) (Honda Code 0348433).
2	19612-ZM0-J20	1	PLATE, SIDE Use from Engine SN 1623728. (Honda Code 6648182).
2	19612-ZM0-000	1	PLATE, SIDE Use up to Engine SN 1623727. (Honda Code 6315782).
3	30500-ZL8-004	1	COIL ASSY., IGNITION (Honda Code 5580659).
5	32195-ZM0-800	1	WIRE, STOP SWITCH (Honda Code 6315816).
9	90013-883-000	2	SEE PART DETAILS - PRI; BOLT, FLANGE (6X12) (CT200) (Honda Code 0636845).
12	90022-888-010	1	BOLT, FLANGE (6X20) (CT200) (Honda Code 0671552).
13	90201-878-003	1	NUT, SPECIAL (14MM) (Honda Code 0442038).
14	90681-959-003	1	CLIP, CABLE (A) (Honda Code 1824630).
17	31110-ZL9-003	1	FLYWHEEL (Honda Code 5819644).




Ref #	Part Number	Qty	Description
2	87101-ZM1-000	1	MARK, EMBLEM (GCV135 4.5) (Honda Code 5720438).
2	87101-ZM1-010	1	EMBLEM (GCV135 4.5) Use from Engine SN 1623910. (Honda Code 7426141).




ZM00-E1600E

Ref #	Part Number	Qty	Description
1	18310-ZM0-000	1	MUFFLER (Honda Code 5580485).
2	18321-ZL8-000	1	PROTECTOR, MUFFLER (Honda Code 5580501).
3	90004-ZL8-000	2	BOLT, FLANGE (6X79) (CT200) (Honda Code 5580972).
4	90013-883-000	3	SEE PART DETAILS - PRI; BOLT, FLANGE (6X12) (CT200) (Honda Code 0636845).
5	18381-ZL8-305	1	GASKET, MUFFLER (Optional). (Honda Code 5737457).
9	18350-ZL8-000	1	ARRESTER, SPARK (Optional). (Honda Code 5656012).
10	18356-ZL8-000	1	PLATE, ARRESTER NUMBER (Optional). (Honda Code 5611397).
11	90055-ZE1-000	1	SCREW, TAPPING (4X6) (Optional). (Honda Code 1431121).





Ref #	Part Number	Qty	Description
1	11300-ZM0-V30	1	PAN ASSY., OIL (Honda Code 6315667).
3	15625-ZE1-003	1	GASKET, OIL FILLER CAP (Honda Code 4497947).
7	15650-ZM0-003	1	DIPSTICK, OIL (Honda Code 5722996).
8	16508-ZM0-000	1	SHAFT, GOVERNOR HOLDER Use up to Engine SN 1449200. (Honda Code 5580261).
8	16508-ZM0-010	1	SHAFT, GOVERNOR HOLDER Use from Engine SN 1449201. (Honda Code 6384341).
9	16510-ZM0-010	1	SEE PART DETAILS - PRI; GOVERNOR ASSY. (Honda Code 6384333).
10	16511-ZL8-000	2	WEIGHT, GOVERNOR (Honda Code 5580287).
11	16512-ZM0-000	1	HOLDER, GOVERNOR WEIGHT (Honda Code 5580295).
12	16513-ZE1-000	2	PIN, GOVERNOR WEIGHT (Honda Code 1427244).
13	16531-ZE1-000	1	SLIDER, GOVERNOR (Honda Code 1427251).
14	16541-ZM0-000	1	SHAFT, GOVERNOR ARM (Honda Code 5580303).
15	90014-952-000	1	BOLT, FLANGE (6X14) (Honda Code 0803619).
16	90121-952-000	8	BOLT, FLANGE (6X25) (Honda Code 0748111).
17	90451-ZE1-000	1	SEE PART DETAILS - PRI; WASHER, THRUST (6MM) (Honda Code 2413862).
18	90602-ZE1-000	1	SEE PART DETAILS - PRI; CLIP, GOVERNOR HOLDER (Honda Code 2456697).
19	91202-ZM0-V31	1	OIL SEAL (28X41.25X6) (Honda Code 6315865).
21	94101-06800	1	SEE PART DETAILS - PRI; WASHER, PLAIN (6MM) (Honda Code 0345900).
22	94251-08000	1	SEE PART DETAILS - PRI; PIN, LOCK (8MM) (Honda Code 0115527).
23	94301-08200	2	SEE PART DETAILS - PRI; PIN, DOWEL (8X20) (Honda Code 1417369).



ZM00-E0800A

Ref #	Part Number	Qty	Description
1	13101-ZL8-000	1	PISTON (Honda Code 5580014).
2	13111-ZE0-000	1	PIN, PISTON (Honda Code 1426576).
3	13200-ZL9-000	1	ROD ASSY., CONNECTING (Honda Code 5720248).
4	90001-ZE1-000	2	BOLT, CONNECTING ROD (Honda Code 1431055).
5	90551-ZE0-000	2	SEE PART DETAILS - PRI; CLIP, PISTON PIN (13MM) (Honda Code 2605517).
6	13010-ZL8-003	1	SEE PART DETAILS - PRI; RING SET, PISTON (RIKEN) (Honda Code 5655949).
6	13010-ZL8-024	1	RING SET, PISTON (TEIKOKU) (Honda Code 7154727).



ZM00-E1100C

Ref #	Part Number	Qty	Description
1	28400-ZL8-013ZA	1	SEE PART DETAILS - PRI; STARTER ASSY., RECOIL *NH1* (BLACK) Use from Engine SN 1614892. (Honda Code 6061204).
1	28400-ZL8-013ZC	1	SEE PART DETAILS - PRI; STARTER ASSY., RECOIL *R280* (POWER RED) (Honda Code 7451024).
1	28400-ZM0-013ZA	1	STARTER ASSY., RECOIL *NH1* (BLACK) Use up to Engine SN 1614891. (Honda Code 6315790).
8	28461-ZL8-003	1	KNOB, RECOIL STARTER (Honda Code 5580634).
9	28462-ZL8-003	1	ROPE, RECOIL STARTER (#3.5X52") (Honda Code 5611454).
11	90201-ZM0-000	3	NUT, FLANGE (6MM) (Honda Code 6478812).