




Ref #	Part Number	Qty	Description
1	16271-ZE1-000	1	GASKET, ELBOW (Honda Code 1427194).
2	17210-ZE1-505	1	ELEMENT, AIR CLEANER (DUAL) (Honda Code 5247408).
3	17218-ZE1-505	1	SEE PART DETAILS - SUP; FILTER (OUTER) (Honda Code 5272802).
3	17218-ZE1-821	1	SEE PART DETAILS - SUP; FILTER (OUTER) (Honda Code 2535029).
4	17230-ZE1-820	1	COVER, AIR CLEANER (DUAL) (Honda Code 1445790).
5	17232-891-000	1	GROMMET, AIR CLEANER (Honda Code 0999763).
6	17235-ZE1-831	1	SEE PART DETAILS - PRI; NOSE, MUFFLER (Honda Code 4755260).
7	17238-ZE7-010	2	COLLAR, AIR CLEANER (Honda Code 2455673).
8	17239-ZE1-000	1	COLLAR B, AIR CLEANER (Honda Code 1427533).
9	17410-ZE1-020	1	ELBOW, AIR CLEANER (Honda Code 2481653).
10	90325-044-000	2	SEE PART DETAILS - PRI; WINGNUT, TOOL BOX SETTING (Honda Code 0127720).
11	94050-06000	2	SEE PART DETAILS - PRI; NUT, FLANGE (6MM) (Honda Code 0471623).
12	95701-06020-00	1	SEE PART DETAILS - PRI; BOLT, FLANGE (6X20) (Honda Code 2105815).




ZL00-E0900A

FR.




Ref #	Part Number	Qty	Description
1	12209-ZH8-003	1	SEAL, VALVE STEM Use from Engine SN 1646761. (Honda Code 6854335).
1	12209-ZL0-003	1	SEAL, VALVE STEM Use up to Engine SN 1646760. (Honda Code 4742748).
2	14100-ZL0-000	1	CAMSHAFT ASSY. (Honda Code 4742920).
4	14410-ZE1-010	2	SEE PART DETAILS - PRI; ROD, PUSH (Honda Code 3352655).
6	14431-ZE1-000	2	ARM, VALVE ROCKER (Honda Code 1426824).
7	14451-ZE1-013	2	SEE PART DETAILS - PRI; PIVOT, ROCKER ARM (Honda Code 4300901).
8	14568-ZE1-000	1	SPRING, WEIGHT RETURN (Honda Code 1426907).
9	14711-ZF1-000	1	SEE PART DETAILS - PRI; VALVE, IN. (Honda Code 3683455).
10	14721-ZF1-000	1	VALVE, EX. (Honda Code 3683463).
11	14731-ZL0-000	2	LIFTER, VALVE (Honda Code 4742946).
12	14751-ZF1-000	2	SPRING, VALVE (Honda Code 3683489).
13	14771-ZE1-000	1	SEE PART DETAILS - PRI; RETAINER, IN. VALVE SPRING (Honda Code 1426980).
14	14773-ZE1-000	1	RETAINER, EX. VALVE SPRING (Honda Code 1426998).
15	14781-ZE1-000	1	ROTATOR, VALVE (Honda Code 1427004).
16	14791-ZE1-010	1	PLATE, PUSH ROD GUIDE (Honda Code 1899947).
17	90012-ZE0-010	2	BOLT, PIVOT (8MM) (Honda Code 1756964).
18	90206-ZE1-000	2	NUT, PIVOT ADJ. (Honda Code 1431287).













Ref #	Part Number	Qty	Description
1	16010-ZE1-812	1	SEE PART DETAILS - PRI; GASKET SET (Honda Code 3477171).
2	16011-ZE0-005	1	VALVE SET, FLOAT (Honda Code 1441476).
3	16013-ZE0-005	1	FLOAT SET (Honda Code 1441492).
4	16015-ZE0-831	1	CHAMBER SET, FLOAT (Honda Code 2455608).
6	16016-ZH7-W01	1	SEE PART DETAILS - PRI; SCREW SET (Honda Code 4219879).
7	16024-ZE1-811	1	SCREW SET, DRAIN (Honda Code 1672187).
8	16028-ZE0-005	1	SEE PART DETAILS - PRI; SCREW SET B (Honda Code 1441518).
9	16044-ZE0-005	1	CHOKE SET (Honda Code 1441526).
10	16100-ZL0-U21	1	CARBURETOR ASSY. (BE64N A) (Honda Code 5317383).
11	16124-ZE0-005	1	SCREW, THROTTLE STOP (Honda Code 1441559).
12	16166-ZL0-000	1	NOZZLE, MAIN (Honda Code 4743050).
13	16173-001-004	1	GASKET, FUEL STRAINER CUP (Honda Code 0005652).
14	16211-ZL0-000	1	INSULATOR, CARBURETOR (Honda Code 4743068).
15	16212-ZH8-800	1	SEE PART DETAILS - PRI; GASKET, INSULATOR (Honda Code 3683547).
16	16220-ZE1-020	1	SEE PART DETAILS - PRI; SPACER, CARBURETOR (Honda Code 2534055).
17	16221-ZH8-801	1	SEE PART DETAILS - PRI; GASKET, CARBURETOR (Honda Code 4725289).
18	16610-ZE1-000	1	LEVER, CHOKE (STD) (Honda Code 1440114).
19	16953-ZE1-812	1	LEVER, VALVE (Honda Code 5140876).
20	16954-ZE1-812	1	SEE PART DETAILS - PRI; PLATE, LEVER SETTING (Honda Code 5148135).
21	16956-ZE1-811	1	SPRING, VALVE LEVER (Honda Code 1807809).
22	16957-ZE1-812	1	SEE PART DETAILS - PRI; GASKET, VALVE (Honda Code 3440708).
23	16967-ZE0-811	1	CUP, FUEL STRAINER (Honda Code 1441583).
24	93500-03006-0H	2	SEE PART DETAILS - PRI; SCREW, PAN (3X6) (Honda Code 0561654).
25	94305-20122	1	PIN, SPRING (2X12) (Honda Code 1441591).
26	99101-ZH8-0680	1	JET, MAIN (#68) (Optional). (Honda Code 5519996).
26	99101-ZH8-0700	1	JET, MAIN (#70) (Optional). (Honda Code 5427505).
26	99101-ZH8-0720	1	JET, MAIN (#72) (Honda Code 6056139).
27	99204-ZA0-0450	1	JET SET, PILOT (#45) (Honda Code 2060465).



Ref #	Part Number	Qty	Description
3	16551-ZL0-000	1	ARM, GOVERNOR (Honda Code 4743084).
4	16555-ZE1-000	1	ROD, GOVERNOR (Honda Code 1427319).
6	16561-ZL0-000	1	SPRING, GOVERNOR (Honda Code 4743092).
7	16562-ZE1-020	1	SEE PART DETAILS - PRI; SPRING, THROTTLE RETURN (Honda Code 1950625).
8	16571-ZH8-000	1	SEE PART DETAILS - SUP; LEVER, CONTROL Use up to Engine SN 1180377. (Honda Code 3683596).
8	16571-ZH8-020	1	SEE PART DETAILS - PRI; LEVER, CONTROL Use up to Engine SN 1180377. (Honda Code 6145338).
8	16571-ZH8-020	1	SEE PART DETAILS - PRI; LEVER, CONTROL Use from Engine SN 1180378. (Honda Code 6145338).
9	16574-ZE1-000	1	SPRING, LEVER (Honda Code 1427384).
10	16575-ZH8-000	1	SEE PART DETAILS - PRI; WASHER, CONTROL LEVER (Honda Code 3683604).
12	16578-ZE1-000	1	SPACER, CONTROL LEVER (Honda Code 1427400).
13	16580-ZH8-020	1	SEE PART DETAILS - SUP; BASE, CONTROL Use up to Engine SN 1288955. (Honda Code 6094833).
13	16580-ZH8-030	1	SEE PART DETAILS - PRI; BASE, CONTROL (Honda Code 6356760).
14	16584-883-300	1	SPRING, CONTROL ADJUSTING (Honda Code 0636431).
17	90013-883-000	2	SEE PART DETAILS - PRI; BOLT, FLANGE (6X12) (CT200) (Honda Code 0636845).
18	90015-ZE5-010	1	SEE PART DETAILS - PRI; BOLT, GOVERNOR ARM (Honda Code 2418671).
19	90114-SA0-000	1	NUT, SELF-LOCK (6MM) (Honda Code 1410182).
23	93500-05025-0A	1	SEE PART DETAILS - PRI; SCREW, PAN (5X25) (Honda Code 0145565).
24	94050-06000	1	SEE PART DETAILS - PRI; NUT, FLANGE (6MM) (Honda Code 0471623).
34	16500-ZH8-010	1	SEE PART DETAILS - SUP; CONTROL ASSY. Use up to Engine SN 1180377. (Honda Code 4725297).
34	16500-ZH8-020	1	SEE PART DETAILS - SUP; CONTROL ASSY. Use up to Engine SN 1288955. (Honda Code 5989736).
34	16500-ZH8-030	1	SEE PART DETAILS - PRI; CONTROL ASSY. (Honda Code 6262299).




Ref #	Part Number	Qty	Description
2	11300-ZE1-641	1	SEE PART DETAILS - PRI; COVER ASSY., CRANKCASE (U-TYPE) (Honda Code 4731568).
4	11381-ZL0-000	1	GASKET, CASE COVER (Honda Code 4917720).
5	15600-ZE1-003	1	SEE PART DETAILS - PRI; CAP ASSY., OIL FILLER (Honda Code 4500146).
6	15600-ZG4-003	1	CAP ASSY., OIL FILLER (Honda Code 4497921).
7	15625-ZE1-003	2	GASKET, OIL FILLER CAP (Honda Code 4497947).
9	91202-883-005	1	OIL SEAL (25X41X6) (Honda Code 0636936).
10	94301-08140	2	SEE PART DETAILS - PRI; PIN A, DOWEL (8X14) (Honda Code 0069310).
11	95701-08032-00	6	SEE PART DETAILS - PRI; BOLT, FLANGE (8X32) (Honda Code 2751725).
12	96100-62050-00	1	SEE PART DETAILS - PRI; BEARING, RADIAL BALL (6205) (Honda Code 0636977).




ZL00-E0700A

Ref #	Part Number	Qty	Description
8	13310-ZL0-670	1	CRANKSHAFT (V-TYPE) (Honda Code 4742912).




ZL00-E0300A **FR.**

Ref #	Part Number	Qty	Description
1	12000-ZL0-811	1	SEE PART DETAILS - PRI; CYLINDER ASSY. (Honda Code 6841050).
2	15510-ZE1-033	1	SEE PART DETAILS - PRI; SWITCH ASSY., OIL LEVEL (Honda Code 5962063).
3	16506-ZL0-000	1	GOVERNOR ASSY. (Honda Code 4743076).
4	16531-ZE1-000	1	SLIDER, GOVERNOR (Honda Code 1427251).
5	16541-ZE1-000	1	SHAFT, GOVERNOR ARM (Honda Code 1427277).
6	90131-ZE1-000	2	BOLT, DRAIN PLUG (Honda Code 1431246).
7	90451-ZE1-000	1	SEE PART DETAILS - PRI; WASHER, THRUST (6MM) (Honda Code 2413862).
8	90601-ZE1-000	2	WASHER, DRAIN PLUG (10.2MM) (Honda Code 1436583).
9	90602-ZE1-000	1	SEE PART DETAILS - PRI; CLIP, GOVERNOR HOLDER (Honda Code 2456697).
10	91001-ZF1-003	1	SEE PART DETAILS - PRI; BEARING, RADIAL BALL (6205) (Honda Code 3684248).
11	91202-883-005	1	OIL SEAL (25X41X6) (Honda Code 0636936).
12	91353-671-003	1	SEE PART DETAILS - PRI; O-RING (13.5X1.5) (ARAI) (Honda Code 0949883).
13	94050-10000	1	SEE PART DETAILS - PRI; NUT, FLANGE (10MM) (Honda Code 0483867).
14	94101-06800	2	SEE PART DETAILS - PRI; WASHER, PLAIN (6MM) (Honda Code 0345900).
15	94251-08000	1	SEE PART DETAILS - PRI; PIN, LOCK (8MM) (Honda Code 0115527).
16	95701-06012-00	2	SEE PART DETAILS - PRI; BOLT, FLANGE (6X12) (Honda Code 2105799).




Ref #	Part Number	Qty	Description
1	12204-ZE1-306	1	GUIDE, VALVE (OS) (Optional). (Honda Code 4165874).
2	12205-ZE1-315	1	SEE PART DETAILS - PRI; GUIDE, EX. VALVE (OS) (Optional). (Honda Code 1899848).
3	12210-ZL0-000	1	SEE PART DETAILS - SUP; CYLINDER HEAD (Honda Code 4742755).
3	12210-ZL0-010	1	SEE PART DETAILS - PRI; CYLINDER HEAD (Honda Code 6762868).
4	12216-ZE5-300	1	CLIP, VALVE GUIDE (Honda Code 2399780).
5	12251-ZL0-003	1	GASKET, CYLINDER HEAD (Honda Code 4742763).
6	12310-ZE1-010	1	SEE PART DETAILS - PRI; COVER, HEAD Use up to Engine SN 1627995. (Honda Code 4725248).
6	12310-ZE1-020	1	COVER, HEAD Use from Engine SN 1627996. (Honda Code 6854921).
7	12391-ZE1-000	1	GASKET, CYLINDER HEAD COVER (Honda Code 1426527).
8	15721-ZH8-000	1	TUBE, BREATHER (Honda Code 3683497).
9	90013-883-000	4	SEE PART DETAILS - PRI; BOLT, FLANGE (6X12) (CT200) (Honda Code 0636845).
10	90043-ZE1-020	2	SEE PART DETAILS - PRI; BOLT, STUD (6X109) (Honda Code 4588323).
11	90047-ZE1-000	2	BOLT, STUD (8X32) (Honda Code 1431097).
12	94301-10160	2	SEE PART DETAILS - PRI; PIN A, DOWEL (10X16) (Honda Code 0058206).
14	95723-08060-00	4	BOLT, FLANGE (8X60) (Honda Code 1436591).
15	98079-56846	1	SEE PART DETAILS - PRI; SPARK PLUG (BPR6ES) (NGK) (Honda Code 1441112).
15	98079-56855	1	SPARK PLUG (W20EPR-U) (DENSO) (Honda Code 1441120).






ZL00-E1200A


Ref #	Part Number	Qty	Description
2	19610-ZL0-000ZB	1	COVER, FAN *R8* (BRIGHT RED) (Honda Code 4743167).
3	19611-ZH8-810	1	PLATE, SIDE (OIL ALERT) Use from Engine SN 1156171. (Honda Code 5891528).
3	19612-ZH8-810	1	PLATE, SIDE (STD) Use up to Engine SN 1110329. (Honda Code 3683778).
3	19612-ZH8-811	1	SEE PART DETAILS - SUP; PLATE, SIDE (OIL ALERT) Use from Engine SN 1110330 to 1127340. (Honda Code 5425624).
3	19612-ZH8-812	1	SEE PART DETAILS - PRI; PLATE, SIDE Use from Engine SN 1110330 to 1156170. (Honda Code 5891536).
4	19613-ZE1-000	1	SEE PART DETAILS - SUP; CLAMP, WIRE Use up to Engine SN 1061455. (Honda Code 1441385).
4	19613-ZE1-010	1	SEE PART DETAILS - PRI; CLAMP, CORD Use up to Engine SN 1061455. (Honda Code 5891544).
6	19630-ZH8-000	1	SHROUD (Honda Code 3683802).
7	32197-ZH8-003	1	SUB-HARNESS (Honda Code 4193082).
8	36100-ZE1-015	1	SEE PART DETAILS - PRI; SWITCH ASSY., ENGINE STOP Use up to Engine SN 1061455. (Honda Code 2787869).
8	36100-ZH7-003	1	SWITCH ASSY., ENGINE STOP Use from Engine SN 1061456. (Honda Code 5266184).
9	36101-ZE1-010	1	WIRE, STOP SWITCH (370MM) (Honda Code 3684032).
10	90013-883-000	6	SEE PART DETAILS - PRI; BOLT, FLANGE (6X12) (CT200) (Honda Code 0636845).
11	90022-888-010	1	BOLT, FLANGE (6X20) (CT200) (Honda Code 0671552).
13	90601-ZH7-013	1	SEE PART DETAILS - PRI; CLIP, HARNESS Use from Engine SN 1061456. (Honda Code 5263934).
19	34150-ZH7-003	1	ALERT UNIT, OIL Use from Engine SN 1156171. (Honda Code 5858444).
21	95701-06008-00	1	SEE PART DETAILS - PRI; BOLT, FLANGE (6X8) Use from Engine SN 1156171. (Honda Code 2581353).



ZL00-E1900

Ref #	Part Number	Qty	Description
1	13331-357-000	1	KEY, SPECIAL WOODRUFF (25X18) (Honda Code 0348433).
2	19511-ZE1-000	1	FAN, COOLING (Honda Code 1428051).
4	28451-ZL0-000	1	PULLEY, STARTER (Honda Code 4743233).
5	31100-ZE7-010	1	FLYWHEEL (STD) (Honda Code 5317417).
7	90201-878-003	1	NUT, SPECIAL (14MM) (Honda Code 0442038).




ZL00-E1700A 

Ref #	Part Number	Qty	Description
3	16854-ZH8-000	1	SEE PART DETAILS - PRI; RUBBER, SUPPORTER (107MM) (Honda Code 3683646).
21	95001-45003-60M	1	BULK HOSE, FUEL (4.5X3000) (4.5X140) (Honda Code 5137104).
22	95002-02080	2	CLIP, TUBE (B8) (Honda Code 0250647).

**No Artwork
Available**


Ref #	Part Number	Qty	Description
1	06111-ZL0-000	1	GASKET KIT (Honda Code 5148085).



ZL00-E2000A





Ref #	Part Number	Qty	Description
1	30500-ZE1-033	1	SEE PART DETAILS - SUP; COIL ASSY., IGNITION (Honda Code 4589693).
1	30500-ZE1-043	1	SEE PART DETAILS - PRI; COIL ASSY., IGNITION (Honda Code 7120405).
2	30700-ZE1-013	1	SEE PART DETAILS - PRI; CAP ASSY., NOISE SUPPRESSOR (Honda Code 3526837).
9	90121-952-000	2	BOLT, FLANGE (6X25) (Honda Code 0748111).




ZL00-E2800 A

Ref #	Part Number	Qty	Description
3	87521-ZL0-000	1	SEE PART DETAILS - SUP; EMBLEM Use up to Engine SN 1593165. (Honda Code 4743621).
3	87521-ZL0-010	1	SEE PART DETAILS - PRI; EMBLEM Use up to Engine SN 1812502. (Honda Code 6762934).
3	87521-ZL0-020	1	EMBLEM Use from Engine SN 1812503. (Honda Code 7352370).
6	87522-ZH9-010	1	LABEL, CAUTION (Honda Code 7005820).
8	87528-ZE1-810	1	MARK, CHOKE (Honda Code 1696715).
10	87532-ZH8-810	1	MARK, OIL ALERT (E) (Honda Code 4193355).




Ref #	Part Number	Qty	Description
2	18310-ZL0-800	1	MUFFLER (ARRESTER) (Honda Code 4743118).
3	18315-ZE1-000	1	STAY, MUFFLER (Honda Code 1540830).
4	18320-ZF1-H51	1	SEE PART DETAILS - PRI; PROTECTOR, MUFFLER (Honda Code 4640850).
6	18355-ZL0-000	1	ARRESTER, SPARK (Honda Code 4743126).
8	18381-ZH8-800	1	GASKET, MUFFLER (Honda Code 3683745).
13	90016-ZE1-000	1	BOLT, FLANGE (6X13) (Honda Code 1541002).
14	90050-ZE1-000	4	SCREW, TAPPING (5X8) (Honda Code 1431105).
17	90056-ZL0-000	1	SCREW, TAPPING (4X6) (Honda Code 7227622).
20	94001-08000-0S	2	SEE PART DETAILS - PRI; NUT, HEX. (8MM) (Honda Code 0167338).
22	95701-06012-00	1	SEE PART DETAILS - PRI; BOLT, FLANGE (6X12) (Honda Code 2105799).



ZL00-E0800A



Ref #	Part Number	Qty	Description
1	13010-ZL0-003	1	RING SET, PISTON (STD) (Honda Code 4742771).
1	13011-ZL0-003	1	RING SET, PISTON (OS 0.25) (Optional). (Honda Code 4742789).
1	13012-ZL0-003	1	RING SET, PISTON (OS 0.50) (Optional). (Honda Code 4742797).
1	13013-ZL0-003	1	RING SET, PISTON (0.75) (Optional). (Honda Code 4742805).
2	13101-ZL0-010	1	SEE PART DETAILS - PRI; PISTON (STD) (Honda Code 6873533).
2	13102-ZL0-010	1	PISTON (OS 0.25) (Optional). (Honda Code 6858203).
2	13103-ZL0-010	1	PISTON (OS 0.50) (Optional). (Honda Code 6873541).
2	13104-ZL0-010	1	PISTON (0.75) (Optional). (Honda Code 6873558).
3	13111-ZE1-000	1	PIN, PISTON (Honda Code 1426584).
4	13200-ZE1-010	1	SEE PART DETAILS - PRI; ROD ASSY., CONNECTING (Honda Code 4725255).
5	90001-ZE1-000	2	BOLT, CONNECTING ROD (Honda Code 1431055).
6	90551-ZE1-000	2	CLIP, PISTON PIN (18MM) (Honda Code 2539120).



Ref #	Part Number	Qty	Description
1	28400-ZH8-013ZA	1	SEE PART DETAILS - PRI; STARTER ASSY., RECOIL *R8* (BRIGHT RED) (Honda Code 4193033).
2	28405-ZL0-000ZB	1	SPACER, RECOIL STARTER MOUNTING *R8* (BRIGHT RED) (Honda Code 4743217).
3	28410-ZH8-003ZA	1	CASE, RECOIL STARTER *R8* (BRIGHT RED) (Honda Code 3683869).
4	28420-ZH8-013	1	SEE PART DETAILS - PRI; REEL, RECOIL STARTER (Honda Code 4193066).
5	28422-ZH8-013	2	SEE PART DETAILS - PRI; RATCHET, STARTER (Honda Code 4193074).
6	28433-ZH8-003	1	GUIDE, RATCHET (Honda Code 3683893).
7	28441-ZH8-003	1	SPRING, FRICTION (Honda Code 3683901).
8	28442-ZH8-003	1	SPRING, RECOIL STARTER (Honda Code 3683919).
9	28443-ZH8-003	2	SPRING, RETURN (Honda Code 3683927).
10	28461-ZH8-003	1	KNOB, RECOIL STARTER (Honda Code 3683950).
11	28462-ZH8-003	1	SEE PART DETAILS - PRI; ROPE, RECOIL STARTER (#5X55") (NA USE ALT:08550-ZG921-11) (Honda Code 3683968).
12	90003-ZH8-003	1	SCREW, SETTING (Honda Code 3684222).
13	95700-06018-00	3	SEE PART DETAILS - PRI; BOLT, FLANGE (6X18) (Honda Code 0481184).
13	95701-06018-00	3	SEE PART DETAILS - PRI; BOLT, FLANGE (6X18) (Honda Code 2410900).