



H1000-1



NOTE: TORQUE 120-144 IN-LBS FOR ALL NUTS

<u>KEY NO.</u>	<u>DESCRIPTION</u>	<u>PART NUMBER</u>
1	Z-GS-0795	TANK FUEL 7G
2	Z-D27179	ASSY FRAME
3	Z-GS-0225	HOSE FUEL
4	SSP-510	CLIP FUEL LINE TUBE
5	GS-0863	CAP FUEL TANK
6	91895680	SCREW 1/4 - 20 X .75
7	SSN-632	WASHER .875 OD .375 ID .083 THK
8	GS-0227	CLAMP FUEL .50
9	GS-0033	ISOLATOR VIBRATION
10	SSF-8150	NUT HEX WIZ LOCK LG FLANGE
11	GS-0492	SPACER 5/16
12	D27271	BAR SPREADER
13	SS-12-CD	SCREW CAP 5/16-18 X 3/4
14	D27181	ASSY PANEL
16	Z-D27164	GENERATOR ASSY
19	SSN-1619-ZN	WASHER LOCK EXTERNAL TOOTH
23	GS-0117	LUG GROUND
24	SSF-605	SCREW HEX CAP 5/16-18 X 1.25
46	D21901	MUFFLER ASSEMBLY
47	D21947	CABLE BATTERY NEGATIVE 20"
51	D22691	SHIELD HEAT, TIRE
56	SSF-553-1	SCREW#10-24X.563 THD ROLLING
57	D27261	END COVER. BLANK

H1000-1 (cont'd)




KEY NO.

DESCRIPTION

PART NUMBER

9	GS-0033	ISOLATOR VIBRATION
10	SSF-8150	NUT, HEX WHIZ LOCK FLANGE
13	SS-12-CD	SCREW CAP 5/16-18 X 3/4
19	SSN-1619-ZN	WASHER LOCK EXTERNAL TOOTH
20	GS-0118	STRAP GROUND
21	SS-6506-CD	WASHER FLAT 11/16 OD X 11
22	SSF-999-1	SCREW .313-18X1.75
25	-----	ENGINE ASSY 20 HP GX620 HONDA
26	GS-0446	GROMMET DRAIN COCK
27	GS-0437	DRAIN COCK
37	SSF-574	NUT WING 1/4-20
38	D21952	BRACKET BATTERY
39	D21849	BATTERY 12V
40	D21953	BOLT J BATTERY
44	D22070	POSITIVE BATTERY CABLE ASSMBLY
46	D21901	MUFFLER ASSEMBLY
48	D27861	PLATE SPREADER
49	SSF-549	SCREW 5/16-18X.50 HEX WIZ

H1000-1 (cont'd)




KEY NO.

DESCRIPTION

PART NUMBER

4	SSP-510	CLIP FUEL LINE TUBE
29	D21846	SHIELD HEAT GX620 ENGINE
30	SSF-641-ZN	SCREW HEX WASHER M6X14
31	D21829	SCREW M8 X 1.25 X 25 HEX
32	D22868	BRACKET HEAT SHIELD
33	D21844	SPACER HEAT SHIELD BRACKET
42	D21948	ASSY WIRE ENGINE ADAPTER
43	D22053	SCREW M8X1.25X16 HEX
44	D22070	ASSY BATTERY CABLE POSITIVE 38"




**SEE NEXT
PAGE FOR
PARTS LIST**

H1000-1 (cont'd)

PANEL ASSEMBLY PARTS LIST

KEY NO.	DESCRIPTION	PART NUMBER
1	D27182	PANEL CONTROL
3	SSF-595	NUT HEX JAM 7/16
4	SSF-583	SCREW #6-32 x .5 TORX
5	D27186	ASSY WIRE PANEL
5-1	D22273	RECEPTACLE 14-50R 120/240 50 AMP
5-2	GS-0455	RECEPTACLE 4 PRONG 30A
5-3	GS-0021	RECEPTACLE 125V 30A SINGLE
5-4	GS-0480	RECEPTACLE 125V 20A SINGLE
5-5	GS-0644	RECEP GFCI 120V 20A
5-6	Z-D21943	BREAKER CIRCUIT 40A
5-7	Z-GS-0026	CIRCUIT BREAKER 125/250V 30 AMP
5-8	Z-GS-0025	CIRCUIT BREAKER 125/250V 20 AMP
5-9	Z-GS-0681	BREAKER CIRCUIT 125/250V 10 AMP
6	GS-0728	ASSY BINDING POST
7	SSF-584	NUT SPEED #6-32
8	GS-0735	METER HOUR
9	GS-0835	ASSY RESISTOR DC SHUNT
10	D27578	IDLE CONTROL BOARD
11	D26112	PANEL COVER
12	D27260	SWITCH IDLE CONTROL
13	D27259	SWITCH OFF - ON / START
14	SSF-3156	SCREW#10-9X.500 THD FORM
15	D26113	CLAMP
16	GS-0756	CAPACITOR CLAMP
17	GS-0732	CAPACITOR

H1000-1 (cont'd)



KEY **NO.**

PART NO.

DESCRIPTION

1	GS-0220	HANDLE GRIP
2	GS-0584	HANDLE ASSEMBLY
3	91890228	5/8" WASHER
4	GS-0221	END CAPS
5	SSF-8150	NUT, HEX WHIZ LOCK
6	SSF-999-1	SCREW
7	D21720	WHEEL BRACKET
8	SS-12-CD	CAP SCREW, 5/16-18 X 3/4
9	SSN-622	COTTER PIN
10	D21722	AXLE
11	GS-0213-1	AXLE SPACER
12	D21721	WHEEL
13	SSF-591	5/8" AXLE CAP
14	SSN-623	FLAT STEEL WASHER

NOT SHOWN

D27191	OPERATOR MANUAL
D27192	PARTS MANUAL
D21736	ENGINE MANUAL
GS-0914	TWISTLOCK PLUG L5-20P
GS-0868	TWISTLOCK PLUG L5-30P
GS-0849	TWISTLOCK PLUG 14-30P
D22697	PLUG 14-50P 50A
GS-0747	BATTERY CHARGING CABLE
D25570	CAPACITOR