


***Parts Instructions
for Gasoline Compressor Outfits***

**MODEL NO.
L1130GH2-1**

DIAGRAM / PARTS LIST

Air Compressor Diagram

Key No.	Torque
* 12	145-165 in. -lb.
13	8 to 15 ft. - lb.
16	20 to 25 ft. - lb.
19	20 to 25 ft. - lb.
*Pulley Set Screw	




Parts List

<u>Key No.</u>	<u>Part Number</u>	<u>Description</u>
1	Z-D21381	Two-Stage Compressor Pump
2	AC-0421	11 Hp Robin Engine
3	CAC-1334-1	Inside Beltguard
4	CAC-1335	Outside Beltguard
5	AC-0509	Unloader Valve
6	AC-0422	Outlet Tube 5/8"
7	AC-0485	Beltguard Bracket
8	AC-0530	Beltguard Bracket
9	BT-310	Belt (2 used)
10	SSP-6461	Elbow
11	D21354	Bushing
12	PU-2903	Pulley
13	91895680	Screw 1/4-20 x 0.75
14	CAC-1011	Elastomer Bushing
15	SSP-535	Elbow
16	SSF-3159	Pump Bolt (4 used) - 3/8"-16 x 2"
17	AC-0528	Stiffener Plate
18	SSF-8111-ZN	Engine Nut (4 used) - 3/8"-16
19	SSF-628	Engine bolt (4 used) - 3/8"-16 x 2.5"
20	GA-359-B	Gauge
21	SSP-6820	Tee
22	TIA-4200	Safety Valve
23	AC-0510	Throttle Control Assembly
24	SSP-454	Nipple - 1/2 NPT x 2 1/2"
25	SSP-7824	Nut/Sleeve Assembly 5/8" (2 used)
26	CAC-1343-1	Strap
27	SSN-51	Washer (5 used)

Not Shown

SS-2707	Drain Valve
KK-4877	Isolator Kit
SSF-8131	Beltguard Nut(4 used)
SSF-953-ZN	Beltguard Screw (4 used)
SST-100	Engine Pulley Key

Compressor Pump Diagram



Parts List

Key No.	Part Number	Description
1	AC-0454	AIR INLET ELBOW
2	BAL-1000345	VALVE PLATE
3	BAL-1000306	OILSIGHT GLASS
4	BAL-1000519	OIL FILL PLUG
5	BAL-1000269	OIL PLUG GASKET
6	BAL-1000112	OIL BREATHER ASSEMBLY
7	SSP-525	DRAIN PLUG
8	AC-0436	FLYWHEEL
9	BAL-1000587	FLYWHEEL BOLT
10	BAL-1000417	FLYWHEEL WASHER
11	AC-0469	SAFETY VALVE (AFTERCOOLER)
12	AC-0437	INLET FILTER ASSEMBLY
13	AC-0438	AIR FILTER ELEMENT

KITS AVAILABLE

BAL-8226021	RING KIT
BAL-8226022	GASKET KIT
BAL-8226024	VALVE KIT
BAL-8226023	RUNNING GEAR KIT